

Honeywell

VISTA-128FBPT

VISTA-250FBPT

***Commercial Fire and Burglary
Partitioned Security System with Scheduling***

Programming Guide

Table of Contents

Programming Field Settings for UL864 Compliance	2	Expert Mode Zone Programming	38
Programming Field Settings for ULC304 Compliance	4	Report Code Programming	40
Recommended Programming Procedure	6	Alpha Descriptors Programming	44
Program Field Index	7	Alpha Descriptor Vocabulary	47
VISTA-128FBPT/VISTA-250FBPT Programming	8	Device Programming	48
Programming With #93 Menu Mode	26	Output Programming	51
Zone Programming	27	Relay Voice Descriptors	56
Zone Number Designations	27	System Layout Worksheets	58
Zone Response Type Definitions	30	Output Devices Worksheets	74
Zone Input Type Definitions	31	Scheduling	80
5800 Series Transmitters Loop Designations	37	Scheduling Menu Mode	83

Programming Field Settings for UL864 Compliance

NOTICE TO USERS, INSTALLERS, AUTHORITIES HAVING JURISDICTION, AND OTHER INVOLVED PARTIES			
This product incorporates field-programmable software. In order for the product to comply with the requirements in the Standard for Control Units and Accessories for Fire Alarm Systems, UL 864, certain programming features or options must be limited to specific values or not used at all as indicated below.			
Program feature or option	Permitted in UL864? Y/N	Possible settings	Settings permitted in UL 864
*08 TEMPORAL SIREN PULSE	N	0 = disable 1 = enable	Not used at this time. Must be set to "0" (disable).
*13 BELL 1 TIMEOUT	Y	Enter 01-15 multiplied by 2 minutes. 00 = no timeout.	Must be set to "3" (Minimum of 6 minutes).
*14 RS232 comm.	N	0 = no 1 = yes	Must be set to "0".
*17 AC LOSS KEYPAD SOUNDING	N	0 = disable 1 = enable	Must be set to "1" (enabled).
*19 RANDOMIZE AC LOSS REPORT	Y	0 = within 2 minutes 1 = 10-40 minutes 2 = 1-3 hours 3 = 6-12 hours without Type 13, 1-3 hours with Type 13	Must be set to "2".
*20 TELEPHONE MODULE PHONE CODE	N	1-9 = first digit of access code * or # = second digit of access code (enter # +11 for "*", or # +12 for "#") To disable enter 00 for the 1 st digit	Not Used. Must be set to "00".
*22 KEYPAD PANIC ENABLES (PARTITION SPECIFIC)	N	0 = disable 1 = enable	Must be set to "000" for partition 1 in fire systems.
*23 MULTIPLE ALARMS (PARTITION SPECIFIC)	N	0 = disable 1 = enable	Must be set to "1" (enabled).
*24 IGNORE EXPANSION ZONE TAMPER	N	0 = disable (tamper detection) 1 = enable (no tamper detection)	Must be set to "0" (enabled).
*26 INTELLIGENT TEST REPORTING	N	0 = disable 1 = enable	Must be set to "0" (disable).
*27 TEST REPORT INTERVAL	Y	Enter 0001-9999 for the test report interval in hours. Enter 0000 for test reporting.	Must be set to "0024" (Maximum 24 hours)
*28 POWER-UP IN PREV. STATE	Y	0 = disable 1 = enable	Must be set to "1" (enable).
*37 DOWNLOAD COMMAND ENABLES	N	0 = disable 1 = enable	Must be set to "0" for all entries (disable).
*41 NORMALLY CLOSED OR EOLR (ZONES 3-8)	N	0 = EOLR supervision 1 = N.C. loops	Must be set to "0" (EOLR Supervision).
*42 DIAL TONE PAUSE	Y	Enter the wait time for dial tone detection: 0 = 5 seconds; 1 = 11 seconds; 2 = 30 seconds.	Must be set to "0" (5 seconds).

Program feature or option	Permitted in UL864? Y/N	Possible settings	Settings permitted in UL 864
*44 RING DETECTION COUNT	N	Enter 00 to disable ring detection. Enter 01-14 for ring counts of 1-14. Enter 15 to select Answering Machine Defeat Mode	Must be set to "00" (disable).
*56 DYNAMIC SIGNAL DELAY	Y	Enter 00-15 times 15 seconds.	Must be set to "6" (90 seconds).
*77 AUTO TRBL RSTR	Y	0 = disable 1 = enable	Must be set to "1" (enable).
*80 ZONE TYPE 9 -10, 14 RESTORE	N	0 = disable 1 = enable	Must be set to "1" (enable) for zone type 9.
*84 SWINGER SUPPRESS. (PARTITION – SPECIFIC)	N	Enter 01-14, Enter 00 for unlimited reports	Must be set to "00" (disable).
1*12 PROGRAM NOTIFICATION	Y	0 = no 1 = yes	Must be set to "1" (yes).
1*13 SYS. SENSOR REV. RELAY	N	0=use neither Zone 1 or Zone 2 inputs 1=use Zone 1 input; 2=use Zone 2 input; 3=use Zone 1 and Zone 2 inputs.	Not Used. Must be set to "0".
1*18 AFFECTS LOBBY (PARTITION – SPECIFIC)	N	0 = disable 1 = enable	Must be set to "0" (disabled) for partition 1.
1*19 ARMS LOBBY (PARTITION – SPECIFIC)	N	0 = disable 1 = enable	Must be set to "0" (disabled) for partition 1.
1*22 thru 1*25 CROSS-ZONING PAIRS (1 – 4)	N	Enter 001-250 Enter 000,000 to disable	Must be set to "000,000" (disabled) for fire zones.
1*28 RF TX LOW BATTERY SOUND	N	0 = disarmed state only 1 = both armed and disarmed states	Must be set to "1" (both armed and disarmed states).
1*29 RF TX LOW BATTERY REPORTING	N	0 = disable 1 = enable	Must be set to "1" (enable).
1*30 RF RCVR CHECK-IN INTERVAL	N	Enter 02–15 times 2 hours (4–30 hours) Enter 00 to disable receiver supervision	Maximum is 02 (4 hours) for fire installations.
1*31 RF TX CHECK-IN INTERVAL	N	Enter 02–15 times 2 hours (4–30 hours) Enter 00 to disable transmitter supervision	Maximum is 02 (4 hours) for fire installations.
1*35 ACS DLR ENABLES	N	0 = disable 1 = enable	Not used. Must be set to "0".
1*44 RF KEYPAD TAMPER DETECTION	N	0 = disable 1 = enable	Not used. Must be set to "0".
1*45 EXIT DELAY SOUNDING (PARTITION SPECIFIC)	N	0 = disable 1 = enable	Must be set to "0" (disable) for partition 1.
1*48 RF KEYPAD ASSIGN 1-8=PART. 0=NO	N	0 = none 1-8 = partition number	Not used. Must be set to "0".
1*49 SUPPRESS TX SUPERV. SOUND	N	0 = disable 1 = enable	Must be set to "0" (disable).
1*53 DOWNLOAD CALLBACK	N	0 = callback required 1 = no callback required	Must be set to "0" (callback required).
1*57 ENABLE 5800 RF BUTTON GLOBAL ARM	N	0 = disable 1 = enable	Must be set to "0" (disable).
1*58 ENABLE 5800 RF FORCE ARM	N	0 = disable 1 = enable	Must be set to "0" (disable).
1*60 ZONE 5/AUDIO ALARM VER.	N	0 = disable 1 = enable	Must be set to "0" (disable).
1*72 PRINTER ON-LINE MODE	N	0 = disable 1 = enable	Not used. Must be set to "0".
1*76 ACCESS RELAY # (PARTITION SPECIFIC)	N	01-96 = relay number 00 = relay not used.	Must be set to "00" (relay not used) for partition 1.
1*78 EXT. HOME CONTROL EVT	N	1 = extended 0 = limited	Not used. Must be set to "0".
1*79 HOME CONTROL EVENTS	N	0 = disable 1 = enable	Not used. Must be set to "0" in each entry.
1*80 LOG-FAULTS & RESTORES	N	0 = disable 1 = enable	Not used. Must be set to "0".

Program feature or option	Permitted in UL864? Y/N	Possible settings	Settings permitted in UL 864
2*07 AUTO-DISARM DELAY (PARTITION SPECIFIC)	N	00 = no delay. 01-14 times 4 minutes (04-56) delay. 15 = no auto disarming.	Must be set to "15" (no auto disarming) for partition 1.
2*18 ENABLE GOTO FOR PARTITION (PARTITION SPECIFIC)	N	0 = disable 1 = enable	Must be set to "0" (disable) for partition 1.
2*21 SUPERVISION PULSES FOR COMMUNICATIONS DEVICE	N	0 = disable 1 = enable	Not Used. Must be set to "00000" (disable).
2*22 DISPLAY OTHER FIRE ALARMS (PARTITION SPECIFIC)	N	0 = disable 1 = enable	Must be set to "0" (disable) for partition 1.
2*23 DISPLAY OTHER BURG & PANIC (INCLUDING CO ALARMS) (PARTITION SPECIFIC)	N	0 = disable 1 = enable	Must be set to "0" (disable) for partition 1.
2*24 DISPLAY TROUBLES OF OTHER PARTITIONS (PARTITION SPECIFIC)	N	0 = disable 1 = enable	Must be set to "0" (disable) for partition 1.
3*01 EVENT DISPLAY LOCK	N	0 = disable 1 = enable	Must be set to "1" (enable).
3*12 ZN TYPE 18 DELAY USE	N	0 = disable 1 = enable	Must be set to "0" (disable).
3*13 "SUPV" ON OPEN AND SHORT (APPLIES TO ZONE TYPE 18)	N	0 = Trouble on open/Supv on short 1 = Supv on open/Supv on short	Must be set to "0".
3*14 W.F. ALARM SILENCE OPT.	N	0 = Silenced by User Code + OFF 1 = Silenced when zone restores	Must be set to "0" (Silenced by User Code + OFF).
3*16 ZONE TYP 17/18 DLY	N	Enter 01-15 times 2 seconds Enter 00 for no delay	Must be set to 00 (no delay).
3*18 EXTENDED DLY FOR TYP 17/18	N	0 = no extended delay 1 = multiply delay by 4	Must be set to 0 (no extended delay).
3*20 TRIG OUTS FUNC SEL (ONLY APPLIES TO VISTA-128FBPT)	N	0 = remote keypad sounder 1 = keyswitch LEDs	Must be set to 0 (remote keypad sounder).
3*21 MAX ATEMPTS	Y	1-8	Must be set at 3, 4 or 5.
3*50 ZONE TYPES 16-18 REST.	N	0 = disable 1 = enable	Must be set to "1" (enable).
3*55 RESET ON 2 ND OFF FOR BELL 1	N	0 = disable 1 = enable	Must be set to "0" (disable).
3*56 RESET ON 2 ND OFF FOR BELL 2	N	0 = disable 1 = enable	Must be set to "0" (disable).
3*57 CONFIRM ARM BELL 2, AUX	N	0 = disable 1 = enable	Must be set to "0, 0" (disable).
3*59 CHIME ON BELL 2, AUX	N	0 = disable 1 = enable	Must be set to "0" (disable) if Bell 2 or Aux Relay is used for Fire.
3*60 BELL 2, AUX RLY TIMEOUT	Y	Enter 01-15 multiplied by 2 minutes. 00 = no timeout.	Must be set to "3" (Minimum of 6 minutes).
3*82 BURG FEATURES ENABLED	N	0 = disable 1 = enable	Must be set to "0" (disable).
RESTRICTION FOR FIRE RELAYS	Y	Yes No	Restriction for # 70 must be set to Yes when programming fire relays.

Programming Field Settings for ULC304 Compliance

NOTICE TO USERS, INSTALLERS, AUTHORITIES HAVING JURISDICTION, AND OTHER INVOLVED PARTIES

This product incorporates field-programmable software. In order for the product to comply with the requirements in the Standard for Signal Receiving Centre and Premise Burglar Alarm Control Units, ULC S304, certain programming features or options must be limited to specific values or not used at all as indicated below.

Program feature or option	Possible settings	Settings permitted in ULC S304
*38 PREVENT ZONE XXX BYPASS (PARTITION SPECIFIC)	Enter a zone number (001-250). Enter 000 if all zones can be bypassed.	Must be set to "000" (all zones can be bypassed).
1*58 ENABLE 5800 RF FORCE ARM	0 = disable, 1 = enable	Must be set to "0" (disable).
2*03 ULC S304 ENABLE	0 = disable, 1 = enable	Must be set to "1" (enabled).
2*08 FORCE-ARM ENABLE (PARTITION SPECIFIC)	0 = disable, 1 = enable	Must be set to "0" (disable).

NOTE: All references in this manual for number of zones, number of user codes, number of access cards, and the event log capacity, use the VISTA-250FBPT's features. The following table lists the differences between the VISTA-128FBPT and the VISTA-250FBPT control panels. All other features are identical.

Feature	VISTA-128FBPT	VISTA-250FBPT
Number of Zones	128	250
Number of User Codes	150	250
Event Log Capacity	512	1000
Vistakey Modules	8	15
Number of Access Cards	250	500

The purpose of this document is to provide a quick and easy way to program your entire system. A recommended programming procedure is included, followed by a list of program fields with the corresponding program group they belong to (system-wide, partition-specific, scheduling, etc.). Two program forms are included. One contains all the programming fields, and the other contains the partition-specific fields. If you are setting up a single-partition system, the partition-specific fields become system-wide fields.

Following the program forms are system layout worksheets. We recommend that you use these sheets to plan your system before programming is performed. If you need further information about specific programming options, see the *VISTA-128FBPT/VISTA-250FBPT Installation and Setup Guide*.

Make sure that one two-line alpha keypad is connected to the control and is set to device address "00."

Single-Partition System

The system default is for a single-partition system. Use the VISTA-128FBPT/VISTA-250FBPT SINGLE PARTITION PROGRAMMING FORM when programming for single-partition usage. Follow the steps outlined in RECOMMENDED PROGRAMMING PROCEDURE of this document for proper programming procedure.

Multiple-Partition System

You must enter the number of partitions you are using in data field 2*00 to set the system for multiple partitions. Use the VISTA-128FBPT/VISTA-250FBPT SINGLE PARTITION and the PARTITION-SPECIFIC PROGRAM FORMS when programming the system for multiple partitions. Follow the steps outlined in RECOMMENDED PROGRAMMING PROCEDURE of this document for proper programming procedure.

SUMMARY OF PROGRAMMING COMMANDS

- **To enter program mode**, enter installer code + [8] + [0] + [0] + [0]
- **To set standard defaults**, press *97
- **To change to next page of program fields**, press *94
- **To return to previous set of fields**, press *99
- **To erase account and phone number field entries**, press [*] + field number + [*]
- **To assign zone descriptors**, press #93 + follow menu prompts
- **To add custom words**, press #93 + follow menu prompts
- **To enter Installer's Message**, press #93 + follow menu prompts
- **To exit program mode**, enter *99 OR *98: *99 allows re-access to programming mode by installer code. *98 prevents re-access to programming mode by installer code. The only way to re-access programming mode is by depressing both the [*] and [#] keys at the same time within 30 seconds of power-up.

Standard default (*97) values are shown in brackets [], otherwise default = 0.

Recommended Programming Procedure

The following is a step-by-step procedure recommended for programming your VISTA-128FBPT/VISTA-250FBPT system.

1. Set the keypads (and other peripheral devices) to the appropriate addresses.

2. Set factory defaults by pressing *97.

This will automatically enable keypad addresses 00-01, so be sure at least one keypad is set to one of these addresses.

3. Program system-wide (global) data fields.

Using the programming form as a guide, enter program mode and program all system-wide programming fields. These options affect the entire system, regardless of partitions. They include control options, downloader and dialer options, RF options, event logging options, etc. Refer to the *Program Field Index* for a listing of the program fields and their function.

Note that field 2*00 (number of partitions) must be programmed before continuing.

4. Program partition-specific fields.

When the system-wide fields have been programmed, program all partition-specific programming fields by first pressing *91 to select a partition (while still in data field program mode). Then enter the first partition-specific field number *09. When you are finished, the next partition-specific field is automatically displayed. Partition-specific fields can have different values for each partition. To program the fields for the next partition, press *91, enter the desired partition number, then enter field *09.

5. Use #93 Menu Mode for device programming.

Refer to *Device Programming* in this guide to assign keypad ID numbers and default partitions for each keypad, and to selectively suppress certain keypad sounding options. Also use this mode to assign RF receivers, relay modules, and Communicators (7847i, GSMV/GSMHS, IGSMV/IGSMHS).

6. Use #93 Menu Mode for zone programming.

Refer to *Zone Programming* in this guide to program zone response types, assign right loop zones and wireless zones, assign zones to partitions, and to program alarm report codes.

7. Use #93 Menu Mode for programming outputs.

Refer to *Output Programming* in this guide to program desired output operation.

8. Program Communication options.

Refer to *System Communication* section in the *VISTA-128FBPT/VISTA-250FBPT Installation and Setup Guide* for detailed instructions. Then use #93 menu mode to program report codes.

9. Use #93 Menu Mode for programming alpha descriptors.

Refer to *Alpha Programming* in this guide to enter zone and partition descriptors and a custom installer's message.

10. Use #80 Mode for programming schedules.

Refer to the *Scheduling Menu Prompts* in this guide to program open/close schedules, temporary and holiday schedules, limitation of access schedules, and time-driven events.

11. Define user access codes.

Refer to *User Access Codes* in the *VISTA-128FBPT/VISTA-250FBPT Installation and Setup Guide* to program authority level, O/C reporting option, partition assignments, and wireless key assignments for each user.

12. Exit Programming Mode.

Exit programming mode by pressing either *98 or *99. Additional entries of *99 are required if the exit is being done from fields 1*00 and above.

To prevent re-access to programming mode using the Installer's code, use *98. The only way to re-access programming mode is by depressing both the [*] and [#] keys at the same time within 30 seconds of power-up.

Exiting by using *99 always allows reentry into programming mode using the Installer code. Either way of exiting allows access via downloading. Note that if local programming lockout is set via downloading, programming mode cannot be entered at the keypad. Alternatively, if the "Installer Lockout Time" option is enabled in Compass, then the installer can only enter programming either within 24 hours of exiting programming, or when a Master Code opens up a 24-hour window by entering their code + #65.

Program Field Index

On the following pages, the programming fields have been arranged in numerical order. Use this index to cross-reference the fields on the programming form.

Field	Group	Field	Group	Field	Group
*00	System-Wide	*80	Communications	1*72	System-Wide
*04	System-Wide	*83	Communications	1*74	System-Wide
*05	System-Wide	*84	Partition-Specific	1*75	System-Wide
*06	Partition-Specific	*85	Partition-Specific	1*76	Partition-Specific
*08	System-Wide	*88	Partition-Specific	1*77	System-Wide
*09	Partition-Specific	*89	Communications	1*78	System-Wide
*10	Partition-Specific	*90	Partition-Specific	1*79	System-Wide
*11	Partition-Specific	1*11	System-Wide	1*80	System-Wide
*12	Partition-Specific	1*12	System-Wide	2*00	System-Wide
*13	Partition-Specific	1*13	System-Wide	2*01	System-Wide
*14	System-Wide	1*15	Communications	2*02	System-Wide
*15	System-Wide	1*17	System-Wide	2*03	System-Wide
*16	Partition-Specific	1*18	Partition-Specific	2*05	Partition-Specific
*17	System-Wide	1*19	Partition-Specific	2*06	Partition-Specific
*19	System-Wide	1*20	System-Wide	2*07	Partition-Specific
*20	System-Wide	1*21	System-Wide	2*08	Partition-Specific
*22	Partition-Specific	1*22	System-Wide	2*09	Partition-Specific
*23	Partition-Specific	1*23	System-Wide	2*10	Partition-Specific
*24	System-Wide	1*24	System-Wide	2*11	System-Wide
*25	System-Wide	1*25	System-Wide	2*18	Partition-Specific
*26	Communications	1*26	Partition-Specific	2*19	Partitioning
*27	Communications	1*28	System-Wide	2*22	Partition-Specific
*28	System-Wide	1*29	System-Wide	2*23	Partition-Specific
*29	Partition-Specific	1*30	System-Wide	2*24	Partition-Specific
*31	Communications	1*31	System-Wide	3*00	System-Wide
*32	Partition-Specific	1*34	Communications	3*01	System-Wide
*33	Communications	1*35	Communications	3*12	System-Wide
*34	Communications	1*42	Communications	3*13	System-Wide
*35	System-Wide	1*43	Partition-Specific	3*14	System-Wide
*36	System-Wide	1*44	System-Wide	3*16	System-Wide
*37	System-Wide	1*45	Partition-Specific	3*17	System-Wide
*38	Partition-Specific	1*47	Partition-Specific	3*18	System-Wide
*39	Partition-Specific	1*48	System-Wide	3*20	System-Wide
*40	Communications	1*49	System-Wide	3*21	System-Wide
*41	System-Wide	1*50	System-Wide	3*30	System-Wide
*42	Communications	1*51	System-Wide	3*50	System-Wide
*44	Communications	1*52	Partition-Specific	3*55	System-Wide
*45	Communications	1*53	System-Wide	3*56	System-Wide
*47	Communications	1*54	System-Wide	3*57	Partition-Specific
*51	Communications	1*55	System-Wide	3*59	Partition-Specific
*56	Communications	1*56	System-Wide	3*60	Partition-Specific
*57	Communications	1*57	System-Wide	3*61	System-Wide
*58	Communications	1*58	System-Wide	3*82	System-Wide
*59	Communications	1*60	System-Wide	3*85	System-Wide
*77	Communications	1*70	System-Wide		
*79	Communications	1*71	System-Wide		

VISTA-128FBPT/VISTA-250FBPT Programming

Some fields are programmed for each partition (shown as shaded fields). If you are programming a multiple-partition system, see the *Partition-Specific Fields* section for programming these fields. Standard default (*97) values are shown in brackets []; otherwise, default = 0.

Data field programming involves making the appropriate entries for each of the data fields. Start Data Field programming by entering the installer code + 8 + 0 + 0 + 0.



All Fire zones should be assigned to partition 1.

***00**

Installer Code

Enter 4 digits, 0-9

[5140]

The Installer Code is a 4-digit code reserved for installation company use. This is the only code that can be used to enter the Program Mode from the keypad. This code cannot be used to disarm the system if it isn't used to arm the system. This code cannot be used to re-enter Program Mode if Program Mode is exited by the *98 command.

***04**

Enable Random Timers (for partitions 1-8)

0 = disable
1 = enable

1 2 3 4 5 6 7 8

Enter 1 to make available the randomizing of pre-programmed time driven events for each partition. [0=disable].

If enabled, the activation time of the window is randomized up to 30 minutes and is initialized by either of two methods:

User Code + [#] + [41] Initiates the random schedule for all devices in the partition.

User Code + [#] + [42] Initiates the random schedule for all devices in the partition with a time window within 6 PM and 5 AM.

NOTES: Must be "0" for Commercial Burglary installations.

***05**

System Events Notify

0 = disable
1 = enable

[0]

If enabled the system sends notification messages via the RS232 port to interface with Home Control type software.

1=enable, (messages sent via the RS232 port).

0=disable, (no messages sent).

NOTES:

While in a communication session with Compass, system events will not operate.

If enabled, the system also sends fault and restore messages via the RS232 port.

***06**

Quick Exit (partition-specific)

0 = disable
1 = enable

[1]

If enabled, allows users to exit the armed partition without disarming and then rearming the partition.

Quick Exit is initiated by entering [#] + [9]. This restarts the exit delay. All rules of exit apply, including exit error logic.

***08**

Temporal Siren Pulse

Not used at this time.

***09**

Entry Delay 1 (partition-specific)

Enter 02-15 multiplied by 15 seconds.
00 = no delay.

[02]

Entry delay defines the delay time that allows users to re-enter the premises through a door that has been programmed as an entry delay door and disarm the system without sounding an alarm. The system must be disarmed within this period or an alarm will occur.

NOTE: The delay may not exceed 45 seconds ("03") for Commercial Burglary installations.

*10	Exit Delay 1 (partition-specific) Enter 03-15 multiplied by 15 seconds. 00 = no delay.	<input type="checkbox"/> <input type="checkbox"/> [04] Exit delay defines the delay period that allows users to leave the premises through a door that has been programmed as an entry/exit delay door after arming the system without setting off the alarm. NOTE: The delay may not exceed 1 minute ("04") for Commercial Burglary installations.
*11	Entry Delay 2 (partition-specific) Enter 02-15 multiplied by 15 seconds. 00 = no delay. (Must be longer than Entry Delay #1.)	<input type="checkbox"/> <input type="checkbox"/> [02] Entry Delay #2 is used for a secondary door requiring a longer delay than those assigned to Entry Delay #1. NOTE: The delay may not exceed 45 seconds ("03") for Commercial Burglary installations.
*12	Exit Delay 2 (partition-specific) Enter 03-15 multiplied by 15 seconds. 00 = no delay. (Must be longer than Exit Delay #1).	<input type="checkbox"/> <input type="checkbox"/> [08] Exit Delay #2 is used for a secondary door requiring a longer delay than those assigned to Exit Delay #1. NOTE: The delay may not exceed 1 minute ("04") for Commercial Burglary installations.
*13	Bell 1 Timeout Enter 01-15 multiplied by 2 minutes. 00 = no timeout.	<input type="checkbox"/> <input type="checkbox"/> [03] Defines the length of time the Bell 1 Output and the keypad's sounder will sound for all audible alarms. NOTES: Must be minimum 16 minutes for Commercial Burglary installations. Must be minimum 6 minutes for Commercial Fire installations.
*14	RS232 comm. 0 = No 1 = Yes	<input type="checkbox"/> [0] Enter 1 to enable (9600 baud). Enter 0 to disable. NOTE: Must be set to "0" for Commercial Fire installations.
*15	Keyswitch 1-8 = Ptn 9 = Bell 0 = no Enter 1-8 partition keyswitch is being used. Enter 9 if the keyswitch is being used to silence fire Notification Appliance Circuits in the event of a fire alarm. Enter 0 if the keyswitch is not used.	<input type="checkbox"/> [0] Enter partition in which keyswitch used, 1-8; 9=silences Notification Appliance Circuit if fire present; 0=disable The keyswitch requires the use of zone 7 wired loop (zone 7 is no longer available as protection zone). The fire and panic alarm voltage triggers (J2) can become ARMING and READY status outputs for the Keyswitch LEDs if programmed in 3*20. Openings/closing report as user "0" if enabled in field *40.
*16	Bell 1 Confirm Arm (partition-specific) 0 = disable 1 = enable	<input type="checkbox"/> [1] If enabled, produces ½-second external alarm sounding ("ding") at the end of exit delay (or after kiss-off from the central station, if sending closing reports). NOTES: If using a keyfob, when the button is pressed for arming, the bell will ding indicating that the button is working. Must be 1 for UL Commercial Burglary installations.
*17	AC Loss Keypad Sounding 0 = disable 1 = enable	<input type="checkbox"/> [1] If enabled, sounding at the keypad (rapid beeping) occurs when AC power is lost (sounding occurs about 2 minutes after actual AC loss). NOTE: Must be "1" for Commercial Fire installations.

*19	Randomize AC Loss Report 0 = within 2 minutes 1 = 10-40 minutes 2 = 1-3 hours 3 = 6-12 hours without Type 13, 1-3 hours with Type 13	<input type="checkbox"/> [2] If enabled, randomizes AC loss reporting within the selected time after an actual AC loss. If disabled (0), AC loss reporting about 2 minutes after actual AC loss. Selecting this option helps prevent an overload of AC loss messages at the central station during a community blackout. NOTE: Must be 2 for Commercial Fire installations.
*20	Telephone Module Phone Code 1-9 = first digit of access code * or # = second digit of access code (enter 11 for "*", or 12 for "#") To disable enter 00 for the 1 st digit	<input type="checkbox"/> <input type="checkbox"/> [00] <input type="checkbox"/> <input type="checkbox"/> [00] NOT USED. Must be set to "00, 00" for Commercial Fire and Commercial Burglary installations.
*22	Keypad Panic Enables (partition-specific) 0 = disable 1 = enable	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> [001] 995 996 999 If enabled, the keypad panics (zones 995, 996, and 999) may be used in this partition. There are three entries in this field, one for each panic. NOTES: Use for Burglary panic types only. Do not use on partition 1 on fire systems.
*23	Multiple Alarms (partition-specific) 0 = disable 1 = enable	<input type="checkbox"/> [1] If enabled, allows more than one alarm sounding for a given zone during an armed period. Pertains to Burglary zones. NOTES: Multiple alarm soundings will not occur more frequently than allowed by the programmed alarm sounder duration. This has no impact on the number of communication messages transmitted. Must be "1" for Commercial Fire and UL Commercial Burglary installations.
*24	Ignore Expansion Zone Tamper 0 = disable (tamper detection) 1 = enable (no tamper detection)	<input type="checkbox"/> [0] If disabled, the system monitors the tampers on expansion zones for RF and V-plex device. NOTES: Only applicable to certain polling loop sensors with tamper switches or 5800 Series transmitters. Must be "0" for Commercial Burglary and Commercial Fire installations if using these devices.
*25	LRR Burg. Trigger for type 8 0 = disable 1 = enable	<input type="checkbox"/> [1] If enabled, allows triggering of Output 3 (pin 3) of the J2 header to include zone response type 8 (24-hr. auxiliary).
*26	Intelligent Test Report 0 = disable 1 = enable	If enabled, no test report is sent if any other type of report was sent since the last test report. If disabled, test reports are sent at the programmed intervals (field *27), regardless of whether or not any other report has been sent. NOTE: Must be "0" for Commercial Fire and UL Commercial Burglary installations.
*27	Test Report Interval Enter 0001-9999 for the test report interval in hours. Enter 0000 for no test reporting.	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> [0024] If a test report is desired, enter a test code in Report Code Programming in #93 Menu Mode. Set first test report time in field *83. NOTE: Maximum Test report interval is "0024" for Commercial Fire and Commercial Burglary installations.

***28**

Power-Up in Prev. State

0 = disable
1 = enable

[1]

If enabled, the system, upon power-up, reverts to its status prior to a complete power loss.

If disabled, the system always powers up in a disarmed state.

NOTES:

Neither authority level 0 nor 5 can be used to disarm the system if the control powers up armed.

When Power Up in Previous State is enabled, if the panel powers up armed, it may take up to 3 minutes before an alarm is recognized and initiated.

Must be "1" for Commercial Burglary and Commercial Fire installations.

***29**

Quick Arm (partition-specific)

0 = disable
1 = enable

[1]

If enabled, allows arming of the burglary system in AWAY, STAY, INSTANT, or MAXIMUM mode by using the [#] key instead of the user code.

NOTES:

When armed, the system reports closing as User 0 if Open/Close reporting for User #2 (typically a Master level user) was enabled for a given partition.

If Quick Arm is used, the Installer Code and Authority Level 5 codes cannot disarm the system.

***31**

PABX (Access Code)

Enter 00-09; B-F (11-15)

[00] [00] [00] [00]

This field is used to enter up to four 2-digit numbers representing the prefix needed to obtain an outside telco line. If not required, enter nothing and proceed to next field.

***32**

Prim. Sub. Acc # (partition-specific)

Enter 00-09; B-F (11-15)

[15] [15] [15] [15] [15]

[15] [15] [15] [15] [15]

Enter a 4- or 10-digit (depending on report format) primary subscriber account number. Each number requires a 2-digit entry so as to allow entry of hexadecimal digits (B-F). If a 4-digit account number is to be used, enter data only in the first four locations, and enter * in the fifth location.

***33**

Primary Phone

Enter 0-9; #11 for *, #12 for #, #13 for a 2-second pause.

Enter the primary central station phone number, up to 17 digits. This is the phone number the control will use to transmit Alarm and status messages to the central station. Do not fill unused spaces.

NOTE: Backup reporting is automatic only if a secondary phone number is entered.

NOTE: Ensure that the phone number entered is to the Central Station, not a Police Station, as the call will not go through to the Police Station.

***34**

Secondary Phone

Enter 0-9; #11 for *, #12 for #, #13 for a 2-second pause.

Enter the secondary phone number, up to 17 digits. The secondary phone number is used if communication on the primary number is unsuccessful, or if split/dual reporting is desired. Do not fill unused spaces.

NOTE: If this field is programmed, a secondary subscriber account number (field *90) *must* also be programmed.

NOTE: Ensure that the phone number entered is to the Central Station, not a Police Station, as the call will not go through to the Police Station.

***35**

Download Phone

Enter 0-9; #11 for *, #12 for #, #13 for a 2-second pause.

Enter the downloading phone number, up to 17 digits. Do not fill unused spaces.

NOTE: This field is applicable only if downloading is utilized.

***36**

Download ID No.

Make entries as 2-digit numbers as follows:

00=0 01=1 02=2 03=3 04=4
05=5 06=6 07=7 08=8 09=9
10=A 11=B 12=C 13=D 14=E
15=F

[15] [15] [15] [15] [15]

[15] [15] [15]

Enter eight digits.

NOTE: This field is applicable only if downloading is utilized.

37*Download Command Enables**0 = disable
1 = enable [1] [1] [1] [1] [1] [1] [1] [1]

Dir Shtdwn Sys Shtdwn Not Used Rmt Byp Rmt Disarm Rmt Arm Upld Pgm Dwnld Pgm

Enabling a function means that you are able to perform that function via the Honeywell Compass Downloading software. See field 1*53 for Callback disable function.

Functions are as follows: Dialer Shutdown; System Shutdown; Not Used; Remote Bypass; Remote Disarm; Remote Arm; Upload Program; Download Program.

NOTE: For Commercial Burglary and Fire installations, all entries must be 0.

38*Prevent Zone XXX Bypass (partition-specific)**Enter a zone number (001-250).
Enter 000 if all zones can be bypassed. [000]

Enter three digits for zone that cannot be bypassed by the user.

NOTES:

The actions manual bypass, group bypass, auto-stay, and STAY/INSTANT arming modes cannot bypass any zone programmed in this field.

The system will not arm if the zone is programmed with the vent zone or force arm fault attributes.

ULC

Force Arming is not a ULC Listed feature and must be disabled for ULC installations.

39*Open/Close Rep. Installer (partition-specific)**0 = disable
1 = enable [1]

If enabled, whenever the Installer Code is used to arm or disarm the partition, an open/close report is sent to the central station.

40*Enable Open/Close report for Keyswitch**0 = disable
1 = enable [0]

If enabled, whenever the keyswitch is used to arm or disarm the partition, an open/close report is sent to the central station.

41*Normally Closed or EOLR (Zones 3-8)**0 = EOLR supervision
1 = N.C. loops [0]

If EOLR supervision is selected, end-of-line resistors must be used on zones 3-8.

If N.C. loops is selected, end-of-line resistors cannot be used and only **normally closed** devices must be used.**NOTE:** Must be "0" for Commercial Fire and Burglary installations.

42*Dial Tone Pause**Enter the wait time for dial tone detection:
0 = 5 seconds; 1 = 11 seconds; 2 = 30 seconds. [0]

Enter the time the system waits for dial tone before dialing.

NOTE: Must be "0" for Commercial Fire and Burglary installations.

44*Ring Detection Count**Enter 00 to disable ring detection.
Enter 01-14 for ring counts of 1-14.
Enter 15 to select Answering Machine Defeat Mode [00]

Only applicable if station-initiated downloading will be used.

NOTES:

In the Answering Machine Mode, the caller should let the phone ring once, then hang up, and call again within 30 seconds. The system, upon hearing one ring followed by nothing, does not answer the first call, but readies itself to pick up on the first ring of the next incoming call that is received within 30 seconds (i.e., the downloader calling again).

Must be set to "00" for Commercial Fire and Burglary installations.

45*Primary Format**1 = Contact ID; 2 = 10-Digit Contact ID;
3 = 4 + 2 Express [1]

Enter the reporting format for the primary telephone number.

47*Secondary Format**1 = Contact ID; 2 = 10-Digit Contact ID;
3 = 4 + 2 Express [1]

Enter the reporting format for the secondary telephone number.

51*Dual Reporting**0 = disable
1 = enable [0]

If enabled, all reports are to be sent to both primary and secondary phone numbers.

NOTES:

If used with Split Reporting "1" option (1*34), alarms and alarm restores go to both primary and secondary numbers, while all other reports go to secondary only. If used with Split Reporting "2" option, alarms and alarm restores go to both, open/close and test messages go to secondary only, while all other reports go to primary. If used with Split Reporting "3" option, fire alarms and fire restore signals go to both, all other reports go to secondary only.

For Remote Station Applications, where separate transmission circuits are required for Fire, Supervisory (when applicable), and Trouble signals, option 3 must be enabled.

56*Dynamic Signal Delay**

Enter 00-15 times 15 seconds.

 [03]

Select the time the panel should wait for acknowledgment from the first reporting destination before it attempts to send a message to the second destination (first and second destinations are determined in field *57).

NOTES:

A minimum of 45 seconds is recommended when the Communicator is set to be the primary report path. If the delay is short (30 seconds or less), the communications device does not have enough time to sent the acknowledgement back to the panel, therefore the report would be sent out via the dialer.

When a Communicator is used as a backup to the dialer, the Dynamic Signaling Delay (*56) should be set to a minimum of 1 minute.

If the acknowledgment is received before the delay time expires, no message is sent to the second destination.

57*Dynamic Signal Priority**0 = Primary Dialer
1 = Communicator [0]

Select the initial reporting path for central station messages.

58*LRR CS #1 Category En.**0 = disable
1 = enable [000000]

Alarm Trbl Byp O/C Syst Test

This field has six entries as follows: Alarm, Trouble, Bypass, Open/Close, System, and Test. If enabled, the reports are sent to the primary subscriber ID of the Communicator.

59*LRR CS #2 Category En.**0 = disable
1 = enable [000000]

Alarm Trbl Byp O/C Syst Test

This field has six entries as follows: Alarm, Trouble, Bypass, Open/Close, System, and Test. If enabled, the reports are sent to the secondary subscriber ID of the Communicator.

77*Auto Trbl Rstr**0 = disable
1 = enable [1]

If enabled, each trouble and supervisory condition automatically clears the keypad display and stops the keypad beeping when the zone returns to a "ready/normal" state. This applies to ALL trouble and supervisory types. The system also sends the Trouble/Supervisory Restore report to the central station, if programmed.

If a partition has more than one trouble/supervisory condition present at the same time, the system automatically clears the keypad display of each zone as it restores, but the keypad continues to beep until all the zones restore.

NOTES:

If this option is set to 0 (disable) then the operation is that restore reports will be sent to the CS when the actual restoral on the zone occurs, however the keypad display will remain showing the condition until a valid code is entered. Must be "1" for Commercial Fire installations.

***79**

Zone Type 1-8 Restore

0 = disable
1 = enable

[00000000]
1 2 3 4 5 6 7 8

This field has eight entries, one for each zone type. Select the zone types that will send Restore reports.

***80**

Zone Type 9-10, 14 Restore

0 = disable
1 = enable

[000]
9 10 14

This field has three entries, one for each zone type. Select the zone types that will send Restore reports.

NOTE: Restores must be set to "1" for Commercial Fire installations.

***83**

1ST Test Report

Enter **00-07** the for day (01 = Monday)
Enter **00-23** for the hour
Enter **00-59** for the minutes

[00] [12] [00]

Enter the day and time that the first Test report shall be transmitted. Enter **00** in all locations if the Test report is to be sent immediately upon exiting. Enter **00** in the day location if the report is to be sent at the next occurrence of the time that is set.

***84**

Swinger Suppress. (partition-specific)

Enter **01-14**.
Enter **00** for unlimited reports

[01]

This option limits the number of messages (alarms or troubles) sent for a specific zone in an armed period.

NOTE: Must be "00" (disabled) for Commercial Fire and Burglary installations.

***85**

Keypad Panic and Duress Rep. (partition-specific)

0 = disable
1 = enable

[0000]
995 996 999 Duress

This field has four entries as follows: Zone 995, 996, 999, Duress Enable for each partition that the panics and duress reporting is desired.

NOTE: Non-zero report code must be assigned to zone 992 (duress) to enable Duress reporting.

***88**

Abort Window (partition-specific)

0 = no delay
1 = 30-second delay

[1]

Select the delay, if any, for the abort window.

NOTE: Must be "0" for Commercial Burglary installations.

***89**

Restore Report Timing

0 = Restore is sent when zone is restored or at disarming, whichever occurs first.
1 = Restore is sent at disarming whether zone is restored or not, or at bell timeout, but only if restored.
2 = Restore is sent at disarming, whether the zone is restored or not.

[0]

Select the time when restore reports are sent after an alarm.

This field applies only to Burglary zone types. It does not apply to Fire or Panic zone types.

NOTE: Must be "2" for Commercial Burglary installations.

***90**

2nd Subs. Acct # (partition-specific)

Enter **00-09; B-F (11-15)**

[15] [15] [15] [15] [15]
 [15] [15] [15] [15] [15]

Enter a 4- or 10-digit (depending on report format) primary subscriber account number. Each number requires a 2-digit entry so as to allow entry of hexadecimal digits (B-F). If a 4-digit account number is to be used, enter data only in the first four locations, and enter * in the fifth location.

NOTE: This field *must* be programmed if a secondary phone number is used (field *34). This account number can be the same as the primary account number.

1*11 Zone Bypass after Disarm

0 = disable
1 = enable

[00000000]

1 2 3 4 5 6 7 8

Enter 1 for each partition in which zones will remain bypassed after disarm.

NOTES:

For each partition in which field 1*11 is enabled, the **USER CODE + OFF** will no longer unby-pass zones. To unby-pass ALL zones, you must enter **USER CODE + # + 64**. To unby-pass zones INDIVIDUALLY, you must enter **USER CODE + 6 + zone number**.

Any zone that was automatically bypassed by the system will be unby-passed upon disarming of the system (e.g., STAY mode, Auto-STAY, etc.).

Vent zones and zones bypassed by a programmed Auto-Bypass schedule (Timed Driven Event) are considered "manual bypasses" and will not be unby-passed upon disarming the system.

Zones that were in a bypassed state at the time a System Shutdown is sent from the Compass Downloading software will be unby-passed when the System Shutdown is removed.

1*12 Program Notification

0 = no
1 = yes

[1]

If enabled, sends signal to central station indicating the system has been put in programming mode.

NOTE: Must be "1" for Commercial Fire installations.

1*13 Sys. Sensor Rev. Relay

0 = use neither Zone 1 or Zone 2 inputs
1 = use Zone 1 input;
2 = use Zone 2 input;
3 = use Zone 1 and Zone 2 inputs

[0]

Selects zones for system sensor reversing relay.

NOTE: When code + #69 fire Drill test is active, these zones if programmed, will be disabled.

Not Used for Commercial Fire installations.

1*15 Cancel Verify

0 = disable
1 = enable alarm output pulse upon kissoff of Cancel report.

[1]

NOTES:

Field 1*52 must be enabled to send a Cancel report to the central station. Cancel reports must be enabled in system group 1.

1*17 Lobby Partition

0 = none; 1-8 = partition number

[0]

Select the Common Lobby Partition.

1*18 Affects Lobby (partition-specific)

1 = if this partition affects the common lobby (enable)
0 = if it does not (disable)

[0]

If enabled, causes lobby partition to disarm when this partition disarms.

NOTES:

This partition must be armed before lobby can be armed.

Must be "0" for Commercial Burglary and Commercial Fire installations.

1*19 Arms Lobby (partition-specific)

0 = disable
1 = enable

[0]

If enabled, arming this partition causes the system to attempt to arm the lobby partition. Field 1*18 must also be enabled (partition-specific).

NOTES:

The lobby cannot be armed unless all partitions programmed for "affect" (field 1*18) is already armed.

If this field is enabled, Field 1*18 for this partition must also be enabled.

Must be "0" for Commercial Burglary and Commercial Fire installations.

1*20**Exit Error Logic Enable**

0 = disable
1 = enable

 [1]

Exit Error Logic functions as follows: the system at the end of the exit delay, if a door is left open or an interior zone is faulted, starts the entry delay period, and sounds the bell(s), siren(s), and keypad sounders for the duration of entry delay. This gives the user time to re-enter the premises and disarm the system before exit error occurs.

If the user does not re-enter the premises and disarm the system, the system bypasses the faulted entry/exit and/or interior zone(s). The rest of the system is armed. In addition, the following dialer reports are sent to the central station if programmed:

Exit Error by Zone

Entry/Exit or Interior Alarm with the zone number

Bypass reports

UL Exit Error Logic is not suitable for use in a UL installation.

NOTE: Exit Error only affects Bell #1 regardless of the zone's bell assignment.

NOTE: Must be "0" for Commercial Burglary installations.

1*21**Exit Delay Reset**

0 = disable
1 = enable

 [1]

If enabled, when the panel is armed, the normal exit delay begins. After the user exits, closes the door and then re-enters the premises, the exit delay time is reset to the programmed value.

Exit Delay Reset is designed to allow an operator to re-enter the premises to retrieve a forgotten item without triggering an alarm. This feature may only be activated once after arming.

UL Exit Delay Reset is not suitable for use in a UL installation.

NOTE: Must be "0" for Commercial Burglary installations.

Cross-Zoning**UL**

Cross Zoning is not suitable for use in a UL installation.

Cross Zoning is designed so that a combination of two zones must be faulted within a 5-minute period of each other (once the first zone trips, the cross zoning window begins, and when the 2nd zone trips within that window, the alarm for both zones will occur). This prevents momentary faults from one of the zones from causing an alarm condition. You can select four "sets" of cross-zones (programmed in data fields 1*22, 1*23, 1*24 and 1*25), keeping in mind the following:

- Both zones in each set must protect the same area.
- Both zones in each set must be in the same partition.

Conditions That Affect Cross-Zone Operation

- Fire zones can not be cross-zoned.
- In the event of a continuous fault (lasting at least 5 minutes) on one of the paired zones, a fault on the second zone causes an alarm immediately.
- If one of the zones in a pair is bypassed or has a zone response type set to 0, the cross-zoning feature does not apply.
- If an entry/exit zone is paired with an interior follower zone, be sure to enter the entry/exit zone as the first zone of the pair. This ensures that the entry delay time is started before the follower zone is processed.
- If a relay is programmed to activate on a fault of one of the zones, the relay activates without the other zone being faulted.
- If a relay is programmed to activate on an alarm or trouble, both zones must trip before the relay activates, and both zones must restore for the relay to deactivate (if relay is programmed to deactivate on a Zone List Restore).



If the one of the zones trips and the second zone does not trip within the 5-minute period, an "error" message is reported to the central station. The Contact ID event code is 378.

1*22**Cross-Zoning Pair 1**

Enter **001-250**
Enter **000,000** to disable

 [000] [000]

Select the first pair of cross zones, which must both be faulted within a 5-minute period to cause an alarm.

NOTE: Must be set to "000,000" for Commercial Fire and Burglary installations.

1*23 Cross-Zoning Pair 2

Enter **001-250**
Enter **000,000** to disable

[000] [000]

Select the second pair of cross zones, which must both be faulted within a 5-minute period to cause an alarm.

NOTE: Must be set to "000,000" for Commercial Fire and Burglary installations.

1*24 Cross-Zoning Pair 3

Enter **001-250**
Enter **000,000** to disable

[000] [000]

Select the third pair of cross zones, which must both be faulted within a 5-minute period to cause an alarm.

NOTE: Must be set to "000,000" for Commercial Fire and Burglary installations.

1*25 Cross-Zoning Pair 4

Enter **001-250**
Enter **000,000** to disable

[000] [000]

Select the fourth pair of cross zones, which must both be faulted within a 5-minute period to cause an alarm.

NOTE: Must be set to "000,000" for Commercial Fire and Burglary installations.

1*26 Panic Button or Speedkey

For A, B, C keys:
00 = panic function; **01-32** = macro number

For D key:
00 = to select a macro to execute when key is pressed; **01-32** = macro number

[00] [00] [00] [00]
A B C D

Select for the A, B, and C keys whether the system performs a panic or a speedkey function when the key is pressed.

Select for the D key whether the system performs a specific macro or if the user will select a macro when the key is pressed.

1*28 RF Tx LowBattery Sound

0 = when disarmed
1 = immediate

[0]

Select when the RF transmitter low-battery condition should display and audible beep annunciate on the keypad.

NOTE: Must be "1" for Commercial Fire and UL Commercial Burglary installations.

1*29 RF Tx LowBattery Reporting

0 = disable
1 = enable

[0]

If enabled, the system sends a Trouble message for RF transmitter low-battery condition to the central station.

NOTES:

The Trouble message will be sent for a transmitter supervision failure, independent of this selection.

Must be "1" for Commercial Fire and UL Commercial Burglary installations.

1*30 RF Rcvr Check-in Interval

Enter **02-15** times 2 hours (4-30 hours).
00 = disable receiver supervision.

[02]

Select the check-in monitoring interval for the RF receiver(s).

Failure of a receiver to receive any RF signal within the time entered results in the activation of the response type programmed for zone 990 for the first receiver and zone 988 for the second receiver and their related communication reports.

NOTE: Maximum is "2" (4 hr) for Commercial Fire and UL Commercial Burglary installations.

1*31 RF Tx Check-in Interval

Enter **02-15** times 2 hours (4-30 hours).
00 = disable transmitter supervision.

[02]

Select the check-in monitoring interval for the RF transmitters.

Failure of an individual transmitter to send a supervision signal within the time entered will result in a trouble response and related communication report.

NOTE: Maximum is 2 (4 hr) for Commercial Fire and UL Commercial Burglary installations.

1*34 **Comm. Split Reporting (Dialer only)**
0 = Split Reporting disabled
1 = Alarm, Alarm Restore, and Cancel reports to primary, all others to secondary
2 = Open/Close and Test reports to secondary, all other reports to primary
3 = Fire Alarms and Fire Restores to primary and secondary, all others to secondary

[0]
Select the type of split reporting for system communication.
NOTES:
See *51 for split/dual reporting combinations.
Split reporting should not be used with Dynamic Signaling.

1*35 **ACS Dir Enables (Access Control)**
0 = disable
1 = enable

[000000]
Trace Trbl Byp Not Used Syst Alm
There are six entries for this field as follows: Trace, Trouble, Not Used, Bypass, System, and Alarm.
If Trace is enabled, access grant/denial events sent to the central station.
For the other events, if enabled, a report is sent to the central station.
NOTE: Not Used. Must be set to "0".

1*42 **Call Waiting Defeat**
0 = disable
1 = enable

[0]
If enabled, the system defeats Call Waiting on the first outgoing call attempt to both the primary and secondary numbers.
After the panel's initial call to report the alarm, the panel may attempt to make an additional call, perhaps for a cancel or a zone restoral. If Call Waiting is not defeated, an operator at the central station attempting to contact the premises (to verify whether the alarm is valid) hears the phone ringing indefinitely and must dispatch on the call.
NOTE: DO NOT enable this feature unless Call Waiting is being used.

1*43 **Permanent Keypad Backlight (partition-specific)**
0 = disable
1 = enable

[0]
If enabled, backlighting for the keypad display remains on at all times. Otherwise the backlighting comes on when a key is pressed.
NOTES:
When a key is pressed, display backlighting turns on for **all** keypads in that partition.
This field affects only standard keypads, not graphic/touch-screen keypads.

1*44 **RF Keypad Tamper Detection**
0 = disable
1 = enable

[0]
If enabled, when more than 40 key depressions are received without a valid sequence (arm, disarm, etc.), the control panel disables the wireless keypad. This inhibit is removed once a valid key sequence is received from a wired keypad.
NOTE: Not Used. Must be set to "0".

1*45 **Exit Delay Sounding (partition-specific)**
0 = disable
1 = enable

[1]
If enabled, the system produces slow beeping from the keypads during exit delay and reverts to rapid beeping during the last 10 seconds of the exit delay.
NOTES:
Must be "1" for UL/ULC installations.
The duration of the beeping is the programmed value of field *10 regardless of which entry/exit zone is used to exit the premises.
See "SOUND OPTION" prompt in this guide for disabling the entry/exit beeps on individual keypads.

1*47 **Chime on Bell 1 (partition-specific)**
0 = disable
1 = enable

[0]
If enabled, the system produces chime annunciation on the Bell 1 output.

1*48 **RF Keypad Assign 1-8=Part.**
0=NO
0 = none
1-8 = partition number

[0]
Select the partition in which RF keypad is used.
NOTE: Not Used. Must be set to "0".

1*49	Suppress Tx Superv. Sound	<input type="checkbox"/> [1]
	0 = disable 1 = enable	If enabled, no trouble soundings occur on the keypad for transmitter check-in failures.
		NOTE: Must be "0" for Commercial Burglary and Commercial Fire installations.
1*50	Seconds Added per day	<input type="checkbox"/> <input type="checkbox"/> [00]
	Enter 00-60	Enter the number of seconds that will be added per day to correct the real-time clock, if internal crystal sync is selected in 1*54.
		NOTES: NOT FOR DOMESTIC USE. For use in Asia Pacific applications only. Time adjustment should only be set in 1*50 or 1*51. Do Not Set Both.
1*51	Seconds Removed per day	<input type="checkbox"/> <input type="checkbox"/> [00]
	Enter 00-60	Enter the number of seconds that will be subtracted per day to correct the real-time clock, if internal crystal sync is selected in 1*54.
		NOTES: NOT FOR DOMESTIC USE. For use in Asia Pacific applications only. Time adjustment should only be set in 1*50 or 1*51. Do Not Set Both.
1*52	Send Cancel If Alarm + OFF (partition-specific)	<input type="checkbox"/> [1]
	0 = within bell timeout period only. 1 = no restriction	If set to "1" (no restrictions), Cancel reports are sent when the system is disarmed after an alarm, regardless of how much time has gone by. If set to "0" (within bell timeout period only), Cancel reports are sent within Bell Timeout period only.
		NOTE: This option must be enabled so Cancel reports are always sent.
1*53	Download Callback	<input type="checkbox"/> [0]
	0 = callback required 1 = no callback required	Select whether a callback from the control panel is required for downloading.
		NOTE: Must be set to "0" for Commercial Burglary and Commercial Fire installations.
1*54	Internal Clock Sync.	<input type="checkbox"/> [0]
	0 = use AC sync for clock 1 = use internal crystal for clock	Select the sync method for the real-time clock. If "Use Internal Crystal for Clock" is selected, refer to 1*50 and 1*51 settings.
		NOTE: NOT FOR DOMESTIC USE. For use in Asia Pacific applications only.
1*55	European Date Format	<input type="checkbox"/> [0]
	0 = disable (mm/dd/yy) 1 = enable (dd/mm/yy)	Select the date format for display in the event log.
1*56	AC 60Hz or 50Hz	<input type="checkbox"/> [0]
	0 = 60Hz 1 = 50Hz	Select the frequency for the AC.
		NOTE: Must be "0" for U.S. and Canadian installations.
1*57	Enable 5800 RF Button Global Arm	<input type="checkbox"/> [0]
	0 = disable 1 = enable	If enabled, the system arms/disarms in accordance with the button's user's global arming settings.
		NOTE: Must be "0" for Commercial Burglary and Commercial Fire installations.

1*58	Enable 5800 RF Force Arm 0 = disable 1 = enable	<input type="checkbox"/> [0] If enabled, allows the RF button user to force a bypass of all faulted zones when arming the system. NOTES: When attempting to arm the system, the keypad beeps once after the button is pressed if any faulted zones are present. The user should then press the button again within 4 seconds to force-bypass those zones and arm the system. Must be set to "0" for Commercial Burglary and Commercial Fire installations. <hr/> ULC Force Arming is not a ULC Listed feature and must be disabled for ULC installations.
1*60	Zone 5/Audio Alarm Ver. 0 = disable 1 = enable	<input type="checkbox"/> [0] If enabled, zone 5 is used for 2-way audio (AAV). NOTES: Must be set to "0" for Commercial Burglary and Commercial Fire installations. Zone 5 cannot be used as protection zone.
1*70	Event Log Types 0 = disable 1 = enable	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> [100010] Alarm Chk Byp O/C Syst Test This field has six entries as follows: Alarm, Check, Bypass, Open/Close, System and Test. If enabled, the system logs those events into the event log.
1*71	12/24 Hour Time Stamp Format 0 = 12-hour 1 = 24-hour	<input type="checkbox"/> [0] Select the type of time stamping for the event log.
1*72	Printer On-Line Mode 0 = disable 1 = enable	<input type="checkbox"/> [0] If enabled, the system prints the events as they occur. If disabled, the system prints the log only upon request. NOTE: Not Used. Must be set to "0".
1*74	Relay Timeout XXX Minutes Enter 000-127 times 2 minutes (000-254).	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> [000] Enter relay timeout, 0-127 in multiples of 2 minutes, desired for #80 Menu Mode Time-Driven event relay command numbers "04/09" and <i>Output Programming</i> in the #93 <i>Menu Mode Programming</i> output command "56."
1*75	Relay Timeout YYY Seconds Enter 000-127 seconds.	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> [000] Enter relay timeout, 0-127 seconds, desired for #80 Menu Mode Time-Driven event relay command numbers "05/10" and <i>Output Programming</i> in the #93 <i>Menu Mode Programming</i> output command "57."
1*76	Access Relay # (partition-specific) 01-96 = relay number 00 = relay not used.	<input type="checkbox"/> <input type="checkbox"/> [00] If enabled, the assigned relay closes for 2 seconds when the user enters his code and presses 0. NOTES: Must be set to "00" for Commercial Burglary and Commercial Fire installations.
1*77	Log 1st Maint. Signal 0 = disable 1 = enable	<input type="checkbox"/> [0] If enabled, the system logs the first maintenance signal from each smoke detector. If disabled, no logging occurs.
1*78	Ext. Home Control Evt 0 = limited 1 = extended	<input type="checkbox"/> [1] If extended, there are 255 commands to the home control command set. If limited, there are 32 commands to the home control command set. NOTE: Not Used for Commercial Fire installations. Must be set to "0".

1*79**Home Control Events**0 = disable
1 = enable [000000]

Alarm Trbl Byp O/C Syst Test

Select the type of events (status reports) transmitted via the RS232 output.

NOTE: Not Used for Commercial Fire installations. Must be set to "0" in each Entry.**1*80****Log Faults & Restores**0 = disable
1 = enable [1]

When enabled automatically transfers zone fault/restore data of the RS232 output.

NOTE: Not Used for Commercial Fire installations. Must be set to "0".**3rd Page Programming Fields (press *94)****2*00****# of Partitions (1-8)**

Enter 1-8.

 [1]

Enter the number of partitions used in the system.

2*01**Daylight: Start & End Month**0 = disable
1 = enable [03] [11]

Start End

Enter the months (00-12) in which daylight saving time starts and ends.

Enter 00, 00 if daylight saving time does not apply to the user's region.

Standard setting for U.S. is 03, 11.

2*02**Daylight: Start & End Weekend**0 = disable
1 = enable [21]

Start End

Enter the start and end weekends for daylight saving time as follows: 1=first;

2=second; 3=third; 4=fourth; 5=last; 6=next to last; 7=third from last.

Standard setting for U.S. is 2, 1.

2*03**ULC S304 Enable**0 = disable
1 = enable [0]

If enable is selected, the following will happen: A 2-minute stabilization upon power up – (zones scanning will be disabled when the panel is powered up for 2 minutes). Previous reporting will be enabled. Attempting to arm when there is a faulted burglary zone will cause a 4-second long tone.

ULC

The ULC S304 Enable must be set to "1" (enabled) for ULC installations.

2*05**Auto-arm Delay (partition-specific)**00 = no delay.
01-14 times 4 minutes (04-56) delay.
15 = no auto arming. [15]

Enter the time between the end of the arming window and the start of the auto-arming warning period, in values of 1 – 14 times 4 minutes. When this delay expires, the Auto-Arm Warning Period (field 2*06) begins.

NOTE: This field must be set to "00" for UL installations.**2*06****Auto-arm Warning Period (partition-specific)**01-15 times 1-minute warning.
00 = no warning period. [15]

This is the time during which the user is warned to exit the premises prior to the auto-arming of the system (beeps every 15 seconds; "ALERT" displayed at keypad). Enter 1 to 15 minutes. 00 = instant at end of arming delay.

NOTE: This field must be set to "00" for UL installations.**2*07****Auto-disarm Delay (partition-specific)**00 = no delay.
01-14 times 4 minutes (04-56) delay.
15 = no auto disarming. [15]

This is the time between the end of the disarming window and the start of auto disarming of the system. Enter 01 – 14 times 4 minutes; 00 = instant at end of window; 15 = no auto disarm.

NOTE: Must be "15" for Commercial Burglary and Commercial Fire installations.

2*08	Force-Arm Enable (partition-specific) 0 = disable 1 = enable	<input type="checkbox"/> [0] If enabled, the system automatically bypasses any faulted zones when it attempts to auto-arm. If disabled, the system will not auto-arm. NOTE: This field must be set to "0" for UL installations. ULC Force Arming is not a ULC Listed feature and must be disabled for ULC installations.
2*09	Open/Close by Exception (partition-specific) 0 = disable 1 = enable	<input type="checkbox"/> [0] If enabled, Open/Close reports are sent only if the openings/closings occur outside the arm and disarm windows. Open reports are also suppressed during the closing window in order to prevent false alarms if the user arms the system, then re-enters the premises, for example to retrieve a forgotten item. NOTES: Openings and closings are still recorded in the event log. This field must be set to "1" if No Opening and No Closing reports are to be sent.
2*10	Disarm During arm/disarm (partition-specific) 0 = disable 1 = enable	<input type="checkbox"/> [0] If enabled, disarming of the system is allowed only during the arming/disarming windows, or if the system is in alarm (if 2*11 is set to 1). NOTE: This applies only to Operator-level users. Installer, Master, and Manager-level users can disarm the system at any time.
2*11	Allow Disarm Outside Alarm 0 = disable 1 = enable	<input type="checkbox"/> [0] Use only if field 2*10 is set to "1". If enabled, allows the system to be disarmed outside the programmed disarm (opening) window if an alarm has occurred. Otherwise disarming is allowed only during the disarm window. If field 2*10 is set to "0" for a partition, this field has no effect for that partition. NOTE: Used only if field 2*10 is enabled.
2*18	Enable GOTO for Partition (partition-specific) 0 = disable 1 = enable (Allow log-on from other partitions)	<input type="checkbox"/> [0] If enabled, this partition can be accessed from another partition's keypad using the GOTO command. NOTE: Must be disabled "0" for partition 1 in Commercial Fire installations.
2*19	Use Partition Descriptor 0 = disable 1 = enable	<input type="checkbox"/> [0] If enabled, the normal keypad display will include a partition number and 4-digit descriptor.
2*21	Supervision Pulses for Communicator 0 = disable 1 = enable	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> [00000] Silent Panic Duress Supv Trbl Not Used. If enabled, causes the control to send periodic short pulses on the J2 communicator triggers to the communications device. The communications device uses these pulses to determine that its connection to the control is still intact. Must be set to "00000" for UL commercial fire and burglary installations.
2*22	Display other Fire Alarm (partition-specific) 0 = disable 1 = enable	<input type="checkbox"/> [0] If enabled, allows fire alarms that occur on other partitions to be displayed at this partition's keypad(s). NOTE: Must be disabled "0" for partition 1 in Commercial Fire installations.
2*23	Display other Burg & Panic (including CO alarms) (partition-specific) 0 = disable 1 = enable	<input type="checkbox"/> [0] If enabled, allows burglary, panic and CO alarms that occur on other partitions to be displayed at this partition's keypad(s). NOTE: Must be disabled "0" for partition 1 in Commercial Fire installations.

2*24**Display Troubles of Other Partitions (partition-specific)**0 = disable
1 = enable [0]

If enabled, allows troubles that occur on other partitions to be displayed at this partition's keypad(s).

NOTE: Must be disabled "0" for partition 1 in Commercial Fire installations.

4th Page Programming Fields (press *94)

3*00**CHECK or TRBL**0 = CHECK
1 = TRBL [0]

Select whether the system should display CHECK or TRBL when a trouble condition occurs.

3*01**Event Display Lock**0 = disable
1 = enable [1]

If enabled, the system locks the display on the first fire alarm. Press * to display the next fire alarm in the system. If disabled, the system scrolls all alarms automatically.

When 3*01 is Enabled, the following priorities go into effect:

The First event to occur is locked on the display; subsequent events will be displayed in priority order:

Priority 1: Life Safety: ZT 06, 07, 09, 16, 17, and Duress override all others below

Priority 2: Property Safety: ZT 01, 02, 03, 04, 05, 10 override all others below

Priority 3: Supervisory: ZT 14, 18, 19 and Fire Trouble override all others below

Priority 4: System: AC Loss, Low Bat, Line Cut, etc. do not override any other events

NOTE: Must be set to "1" for Commercial Fire installations.**3*12****ZN Type 18 Delay Use**0 = disable
1 = enable [1]

If enabled, use the delay time programmed in field 3*16.

NOTE: Must be set to "0" for Commercial Fire installations.**3*13****"Supv" on Open and Short (Applies to Zone Type 18)**0 = disable
1 = enable [0]

If "0" is selected, the system will respond with a trouble on open, and a supervisory on short.

If "1" is selected, the system will respond with a supervisory on open, and a supervisory on short.

NOTE: Must be set to "0" for Commercial Fire installations.**3*14****W.F. Alarm Silence Opt.**0 = silenced by User Code + OFF
1 = silenced when zone restores [0]

Select how the Waterflow zone type will be silenced.

NOTES:

This feature may be set to 1 only by permission of the local authority.

For an output of a 4204CF to be silenced when 3*14=1, all Type 17 (Waterflow) zones activating the output must be put into a Zone List, and that Zone List must be the STP condition of the 4204CF fire output. In addition to the STP ZL, you also need an STP ZT of 22 in order to silence via code + off in the event the zone does not restore.

Since a Type 17 zone is processed as a FIRE alarm, it will activate outputs programmed for STT ZT 17, 16, 09, and 39. The only way to have individual output activations (e.g. ZT17 versus ZT09) is to use zone lists.

NOTE: Must be set to "0" for Commercial Fire installations.**3*16****ZN Typ 17/18 Dly**Enter 01-15 times 2 seconds
Enter 00 for no delay [00]

Select the delay time for zone types 17 and 18. The zone must be faulted for entire delay time before an alarm or supervisory condition occurs. This may prevent alarms due to minor fluctuations in waterflow.

Maximum combined delay of 3*16 and 3*18 cannot exceed 90 seconds for UL installations.

NOTES:

For zone types 17 and 18 a fault must be programmed in the event type.

Must be set to "00" for Commercial Fire installations.

3*17**ZN 6 Alt Func En**0 = disable
1 = enable [0]

If enabled, zone 6 may be used as a tamper zone (bell and cabinet tampers). If used, the zone will annunciate in accordance with response type, rather than a ground fault when a ground fault is detected.

3*18**Extended Dly For Typ 17/18**0 = no extended delay
1 = multiply delay by 4 [0]

This option allows the delay programmed in field 3*16 for Waterflow and Supervisory zones to be extended by 4 times.

NOTE: Must be set to "0" for Commercial Fire installations.**3*20****Trig Outs Func Sel (Only applies to Vista-128FBPT panel)**0 = remote keypad sounder
1 = keyswitch LEDs [0]

Select the function of the J2 trigger outputs. See chart below.

J2 Pin	Field3*20 = 0	Field3*20 = 1
1	Panic Alarm	Panic Alarm
2	Trouble	Trouble
3	Burglary Alarm	Burglary Alarm
4	Fire Supervisory	Fire Supervisory
5	Fire Alarm	Fire Alarm
6	Remote Console Sounder	Keyswitch Ready LED
7	Open/Close	Keyswitch Armed LED
8	Ground	Ground
9	Communicator Xmit Okay	Communicator Xmit Okay

3*21**Max Attempts**

Enter the number of dialing attempts 1-8.

 [8]

Select the maximum number of dialer attempts for the system.

NOTE: Must be 3, 4, or 5 for NFPA 72 compliant systems if a secondary phone number is programmed.**3*30****Dialer Sel**0 = disable
1 = enable [10]

Main Backup

This field has two entries, one for each dialer (main and backup). Enter 1 if the dialer is being used.

NOTE: If 3*30 is disabled (0, 0), the panel does not report at all via communications device.**3*50****Zone Types 16-18 Rest.**0 = disable
1 = enable

16 17 18

This field has three entries, one for each zone type. Select the zone types that will send Restore reports.

NOTE: Must be "1" for Commercial Fire installations**3*55****Reset on 2nd OFF for Bell 1**0 = disable
1 = enable [0]If enabled, the system silences bell 1 output when the second **User Code + OFF** Code is entered after a fire alarm. If disabled, the system silences bell 1 output after the first **User Code + OFF**.**NOTE:** Must be "0" for Commercial Fire installations**3*56****Reset on 2nd OFF for Bell 2**0 = disable
1 = enable [0]If enabled, the system silences the bell 2 output when the second **User Code + OFF** Code is entered after a fire alarm. If disabled, the system silences bell 2 output after the first **User Code + OFF**.**NOTE:** Must be "0" for Commercial Fire installations

3*57**Confirm Arm Bell 2, Aux**

0 = disable
1 = enable

 [00]

Bell 2 Aux

This field has two entries, one for bell 2 and one for the auxiliary relay. If enabled, produces ½-second external alarm sounding (“ding”) at the end of exit delay (or after kiss-off from the central station, if sending closing reports).

NOTES:

If using a keyfob, when the button is pressed, either for arming or disarming, the bell will ding indicating that the button is working.

Must be “1” for Commercial Burglary installations.

3*59**Chime on Bell 2, Aux**

0 = disable
1 = enable

 [00]

Bell 2 Aux

This field has two entries, one for bell 2 and one for the auxiliary relay. If enabled, the system produces chime annunciation on the output.

NOTE: Must be set to “00” if Bell 2 or Aux. Relay is used for Fire.

3*60**Bell 2, Aux Rly Timeout**

Enter 01-15 multiplied by 2 minutes.
00 = no timeout.

 [00] [00]

Bell 2 Aux

This field has two entries, one for bell 2 and one for the auxiliary relay. Defines the length of time the output and the keypad’s sounder will sound for all audible alarms.

NOTE: Must be a minimum of 16 minutes for Commercial Burglary installations and a minimum 6 minutes for Commercial Fire installations.

3*61**Aux Rly Func Sel**

0 = trouble/supervisory
1 = alarm, silenced by **User Code + OFF**
2 = smoke detector reset
3 = battery save
4 = alarm, silenced by **User Code + # + 67**

 [1]

Select the condition that will trigger the auxiliary relay.

NOTES:

Select “4” for applications requiring independent resetting of the relay. Smoke detector reset triggers the relay momentarily (approximately 6 seconds) on the second **User Code + OFF** entry.

Battery save is used to disconnect power from non-critical loads 4 hours after AC loss.

3*82**Burg Features Enabled**

0 = disable
1 = enable

 [1]

If enabled, arming, test and chime modes can be used on partition 1.

NOTES:

These features are automatically enabled on all other partitions.

Must be set to “0” in Commercial Fire installations.

3*85**System Zone Byp Inhibit**

0 = prevent bypass
1 = allow only installer to bypass
2 = allow only installer and master codes to bypass

 [1]

Select which codes, if any, can bypass fire zones CO zones and systems zones.

NOTES:

This applies to fire zones programmed with zone types 9, 16, 17, and 18 and system zones 970-977.

The bypassing can only be done from partition 1.

SUMMARY OF PROGRAMMING COMMANDS

- **To enter program mode**, enter installer code + [8] + [0] + [0] + [0]
- **To set standard defaults**, press *97
- **To change to next page of program fields**, press *94
- **To return to previous set of fields**, press *99
- **To erase account and phone number field entries**, press [*] + field number + [*]
- **To assign zone descriptors**, press #93 + follow menu prompts
- **To add custom words**, press #93 + follow menu prompts
- **To enter Installer’s Message**, press #93 + follow menu prompts
- **To exit program mode**, enter *99 OR *98: *99 allows re-access to programming mode by installer code. *98 prevents re-access to programming mode by installer code.

Programming With #93 Menu Mode

NOTE: The following field should be preset before beginning: 2*00 Number of Partitions. In addition, receivers should be programmed via Device programming.

After programming all system related programming fields in the usual way, press #93 while still in programming mode to display the first choice of the menu driven programming functions. Press 0 (NO) or 1 (YES) in response to the displayed menu selection. Pressing 0 will display the next choice in sequence.

NOTE: All references in this manual for number of zones, number of user codes, and the event log capacity, use the VISTA-250FBPT's features. See page 5 of this manual for the table listing the differences between the VISTA-128FBPT and the VISTA-250FBPT control panels.

#93 MENU MODE KEY COMMANDS

The following is a list of commands used while in the menu mode.

#93	Enters Menu mode
[*]	Serves as ENTER key. Press to have keypad accept entry.
[#]	Backs up to previous screen.
0	Press to answer NO
1	Press to answer YES
001-009	All data entries are either 2-digit or 3-digit entries.
000	Exits menu mode and goes back to Data Field Programming Mode if entered at first prompt of each main menu option.

Menu selections are as follows:

PROMPT	EXPLANATION
<div style="border: 1px solid black; padding: 5px;"> ZONE PROG? 1 = YES 0 = NO 0 </div>	For programming the following: <ul style="list-style-type: none"> • Zone Number • Zone Response Type • Partition Number for Zone • Dialer report code for zone • Input Device Type for zone (whether RF, polling loop, etc.) • Enrolling serial numbers of 5800 Series transmitters & serial polling loop devices into the system. • Zone Attributes (e.g., Arm w/Fault, Silent, etc.)
<div style="border: 1px solid black; padding: 5px;"> EXPERT MODE? 1 = YES 0 = NO 0 </div>	Same as Zone Programming except: <ul style="list-style-type: none"> • Done with a minimum number of keystrokes. • Can program wireless keys using pre-defined templates. <p>NOTE: Be aware some of the zone attributes cannot be programmed in the Expert Mode. These can only be done in Zone Programming.</p>
<div style="border: 1px solid black; padding: 5px;"> REPORT CODE PROG? 1 = YES 0 = NO 0 </div>	For programming the following: <ul style="list-style-type: none"> • Alarm report codes for zones • Restore & supervisory codes • All other system report codes
<div style="border: 1px solid black; padding: 5px;"> ALPHA PROG? 1 = YES 0 = NO 0 </div>	For entering alpha descriptors for the following: <ul style="list-style-type: none"> • Zone Descriptors • Default Screen • Custom Words • Partition Descriptors
<div style="border: 1px solid black; padding: 5px;"> DEVICE PROG? 1 = YES 0 = NO 0 </div>	For defining the following device characteristics for addressable devices, including keypads, RF receivers (5881ENHC), output relay modules (4204/4204CF), and Communicators (7847i, GSMV/GSMHS, IGSMV/IGSMHS, etc.). <ul style="list-style-type: none"> • Device Address • Device Type • Keypad Options (incl. partition assignment) • RF House ID • Communicator Options (incl. programming communicators)
<div style="border: 1px solid black; padding: 5px;"> OUTPUT PGM? 1 = YES 0 = NO 0 </div>	For defining output relay functions.

PROMPT	EXPLANATION
RLY VOICE DESCR? 1 = YES 0 = NO 0	Not Used. Must be set to "0" for Commercial Fire Installations.
CUSTOM INDEX? 1 = YES 0 = NO 0	Not Used. Must be set to "0" for Commercial Fire Installations.
ACCESS POINT PGM 1 = YES 0 = NO 0	For defining the parameters for each of the VistaKey access points, including which group(s) have access through an access point (door). See the <i>VistaKey-SK Installation and Setup Guide</i> for the detailed programming instructions.
ACCESS GRP PGM 1 = YES 0 = NO 0	For defining the capabilities (privileges) for each group of users. See the <i>VistaKey-SK Installation and Setup Guide</i> for the detailed programming instructions.
EVENT/ACTION PGM 1 = YES 0 = NO 0	For defining events and time windows for an access group. See the <i>VistaKey-SK Installation and Setup Guide</i> for the detailed programming instructions.

Zone Programming

Zone Number Designations

The VISTA-128FBPT supports up to 128 zones, the VISTA-250FBPT supports up to 250 zones, of hardwire, polling loop and/or wireless protection, distributed among up to 8 partitions. The following table lists the zone numbers and the types of sensors that can be used with each, and some alternate functions of the zones.

Zone	Function
1 & 2	2-wire Smoke Detectors (if used)
6	Cabinet Tamper/Ground Fault (if used)
7	Keypad (if used)
1-8	Traditional Hardwired Zones
1-250	5800 Series Wireless Devices
9-250	Polling Loop Devices
995	* + 1 Panic (Do not use in Fire Alarm applications)
996	# + 3 Panic (Do not use in Fire Alarm applications)
999	* + # Panic (Do not use in Fire Alarm applications)

Zone Defaults

Zone #	Zone Type	Zone #	Zone Type
001	09	800-830	00
002	09	970	19
003	03	971-974	19
004	03	975	00
005	03	988 & 990	00
006	03	992*	N/A
007	03	995	09
008	03	996	08
009-250	00	997	19
601-632	00	999	06

NOTES:

* Zone 992 is the Duress zone. Programming of the zone response type is not applicable. This zone requires only the report code programming.

Zone Index

The zones are designated as follows:

ZONE # RANGE	ZONE FUNCTION	ACTUAL ZONE
001 – 250	Protection zones	As indicated
601 – 632	Relay Supervision Zones	6 + 2-digit Relay Number; e.g., Relay Number 03, if supervised, is zone 603. NOTE: Relay supervision should be used only for relays on 4204CF modules.
800 – 830	ECP Device Supervision Zones	8 + 2-digit Device Address; e.g., Device Address 01, if supervised, is zone 801.
970-977, 988, 990, & 997	System Supervision Zones	970: Bell 1 Output 971: Bell 2 Output 972: Earth Ground 973: J2 Input 1 (communications device) 974: Dialer 1 975: Dialer 2 976: Auxiliary Relay 977: J2 Trigger Outputs 988: 2 nd Wireless Receiver – +not receiving signals 990: 1 st Wireless Receiver – not receiving signals 997: Polling Loop (short circuit)
992, 995 – 999	Duress and Keypad Panics	992: Duress 995: 1 + * panic (A key) 996: 3 + # panic (C key) 999: * + # panic (B key)

Supervision zones should be given a response type of either 05 (Trouble by Day, Alarm by Night) or 19 (24-Hour Trouble).

Communication Defaults for Zones

ZONE #	1st	2nd	ZONE #	1st	2nd	ZONE #	1st	2nd	ZONE #	1st	2nd
1	01	00	69	09	00	137	02	00	205	10	00
2	02	00	70	10	00	138	03	00	206	11	00
3	03	00	71	11	00	139	04	00	207	12	00
4	04	00	72	12	00	140	05	00	208	13	00
5	05	00	73	13	00	141	06	00	209	14	00
6	06	00	74	14	00	142	07	00	210	15	00
7	07	00	75	15	00	143	08	00	211	01	00
8	08	00	76	01	00	144	09	00	212	02	00
9	09	00	77	02	00	145	10	00	213	03	00
10	10	00	78	03	00	146	11	00	214	04	00
11	11	00	79	04	00	147	12	00	215	05	00
12	12	00	80	05	00	148	13	00	216	06	00
13	13	00	81	06	00	149	14	00	217	07	00
14	14	00	82	07	00	150	15	00	218	08	00
15	15	00	83	08	00	151	01	00	219	09	00
16	01	00	84	09	00	152	02	00	220	10	00
17	02	00	85	10	00	153	03	00	221	11	00
18	03	00	86	11	00	154	04	00	222	12	00
19	04	00	87	12	00	155	05	00	223	13	00
20	05	00	88	13	00	156	06	00	224	14	00
21	06	00	89	14	00	157	07	00	225	15	00
22	07	00	90	15	00	158	08	00	226	01	00
23	08	00	91	01	00	159	09	00	227	02	00
24	09	00	92	02	00	160	10	00	228	03	00
25	10	00	93	03	00	161	11	00	229	04	00
26	11	00	94	04	00	162	12	00	230	05	00
27	12	00	95	05	00	163	13	00	231	06	00
28	13	00	96	06	00	164	14	00	232	07	00
29	14	00	97	07	00	165	15	00	233	08	00
30	15	00	98	08	00	166	01	00	234	09	00
31	01	00	99	09	00	167	02	00	235	10	00
32	02	00	100	10	00	168	03	00	236	11	00
33	03	00	101	11	00	169	04	00	237	12	00
34	04	00	102	12	00	170	05	00	238	13	00
35	05	00	103	13	00	171	06	00	239	14	00
36	06	00	104	14	00	172	07	00	240	15	00
37	07	00	105	15	00	173	08	00	241	01	00
38	08	00	106	01	00	174	09	00	242	02	00
39	09	00	107	02	00	175	10	00	243	03	00
40	10	00	108	03	00	176	11	00	244	04	00
41	11	00	109	04	00	177	12	00	245	05	00
42	12	00	110	05	00	178	13	00	246	06	00
43	13	00	111	06	00	179	14	00	247	07	00
44	14	00	112	07	00	180	15	00	248	08	00
45	15	00	113	08	00	181	01	00	249	09	00
46	01	00	114	09	00	182	02	00	250	10	00
47	02	00	115	10	00	183	03	00	601-632	00	00
48	03	00	116	11	00	184	04	00	800-830	00	00
49	04	00	117	12	00	185	05	00	970	00	00
50	05	00	118	13	00	186	06	00	988	00	00
51	06	00	119	14	00	187	07	00	990	00	00
52	07	00	120	15	00	188	08	00	992 (DURESS)	11	00
53	08	00	121	01	00	189	09	00			
54	09	00	122	02	00	190	10	00	995	01	00
55	10	00	123	03	00	191	11	00	996	02	00
56	11	00	124	04	00	192	12	00	997	06	00
57	12	00	125	05	00	193	13	00	999	03	00
58	13	00	126	06	00	194	14	00	ALARM RST.	01	00
59	14	00	127	07	00	195	15	00	TROUBLE	01	00
60	15	00	128	08	00	196	01	00	TRBLE. RST	01	00
61	01	00	129	09	00	197	02	00	BYPASS	01	00
62	02	00	130	10	00	198	03	00	BYP. RST.	01	00
63	03	00	131	11	00	199	04	00			
64	04	00	132	12	00	200	05	00			
65	05	00	133	13	00	201	06	00			
66	06	00	134	14	00	202	07	00			
67	07	00	135	15	00	203	08	00			
68	08	00	136	01	00	204	09	00			

Zone Response Type Definitions

Each zone must be assigned a zone type, which defines the way in which the system responds to faults in that zone. There are three keypad-activated zones (panic keys; see note) for each partition, a polling loop supervision zone, and four RF supervisory zones, two for each RF receiver installed. Zone types are defined below.

Type 00: Zone Not Used

Program with this zone type if the zone is not used.

Type 01: Entry/Exit #1 Burglary

Provides entry delay whenever the zone is faulted and the system is armed in the AWAY or STAY mode. When the panel is armed in the INSTANT or MAXIMUM mode, no entry delay is provided. Exit delay begins whenever the control is armed, regardless of the arming mode selected. These delays are programmable.

Assign this zone type to zones that are used for primary entry to and exit from the facility.

Type 02: Entry/Exit #2 Burglary

Provides a secondary entry delay, if the system is armed in the AWAY or STAY modes and the zone is faulted. When the panel is armed in the INSTANT or MAXIMUM mode, no entry delay is provided. Secondary exit delay begins whenever the control is armed, regardless of the arming mode selected. These delays are programmable.

Assign this zone type to zones that are used for entry and exit of the facility and require more time than the primary entry and exit point. Delay times for this zone type must be greater than those for zone type 01 (e.g., a garage, loading dock, or basement door).

Type 03: Perimeter Burglary

Provides an instant alarm if the zone is faulted and the system is armed in the AWAY, STAY, INSTANT, or MAXIMUM mode. Assign this zone type to all exterior doors and windows.

Type 04: Interior, Follower

Provides a delayed alarm (using the programmed entry delay time) if an entry/exit zone is faulted first. Otherwise it produces an instant alarm. It is active when the system is armed in the AWAY or MAXIMUM mode, but the MAXIMUM mode eliminates the entry delay.

If the Interior Follower zone is programmed for one of the STAY modes (default is STAY mode 1), it is automatically bypassed when the panel is armed in the STAY or INSTANT mode.

Assign this zone type to a zone covering an area such as a foyer, lobby, or hallway through which one must pass upon entry or exit (to and from the keypad).

Type 05: Trouble by Day/Alarm by Night

Provides an instant alarm if the zone is faulted and the system is armed in the AWAY, STAY, INSTANT, or MAXIMUM mode. During the disarmed state (day), the system annunciates a latched trouble sounding from the keypad (and a central station report, if desired).

Assign this zone type to a zone that contains a foil-protected door or window (such as in a store), or to a zone covering a sensitive area such as a stock room or drug supply room. It can also be used on a zone in an area where immediate notification of an entry is desired.

Type 06: 24-Hour Silent Alarm

Sends a report to the central station but provides no keypad display or sounding. Assign this zone type to a zone containing an Emergency button.

Type 07: 24-Hour Audible Alarm

Sends a report to the central station and provides an alarm sound at the keypad and an audible external alarm. Assign this zone type to a zone containing an Emergency button.

Type 08: 24-Hour Auxiliary Alarm

Sends a report to central station and provides an alarm sound at the keypad only. **(No other Notification Appliance Circuit is activated.)** Assign this zone type to a zone an Emergency button or one containing monitoring devices such as water sensors or temperature sensors.

Type 09: Supervised Fire (Without Verification)

Provides a fire alarm on a short circuit and a trouble condition on open circuit. A fire alarm produces a pulsing of the Notification Appliance Circuit if a Sync Module is used. This type is always active and can only be bypassed by the Installer code or the Master code, (field 3*85).

Type 10: Interior with Delay

Provides entry and exit delays (using the programmed entry and exit delay times) when armed in the AWAY mode. Provides only exit delay when armed in the MAXIMUM mode (no entry delay).

If the Interior with Delay zone is programmed for one of the STAY modes (default is STAY mode 1), it is automatically bypassed when the panel is armed in the STAY or INSTANT mode. Delay begins whenever sensors in this zone are violated, regardless of whether or not an entry/exit delay zone was tripped first.

Assign this zone type to a zone covering an area such as a foyer, lobby, or hallway through which one must pass upon entry or exit (to and from the keypad).

Type 13: Remote P/S

Sends a report to the central station upon detection of an AC power loss on a power supply following the parameters selected in *19 (Randomize AC Loss Report). The exception is that if option 3 is selected for *19, 6- 12 hour reporting will not be used. Instead if option 3 is selected, reporting will be 1-3 hours, the same as if option 2 were selected.

Type 14: CO Detector Alarm

Sends a report to the central station and displays a CO text message at the keypad. Upon a CO alarm only the keypad's sounder will annunciate. The external bell will not sound at all.

Type 16: Fire with Verification

Provides a fire alarm when there is a short circuit and a trouble condition when there is an open circuit. An initial short results in a 7-second smoke detector power reset. Any subsequent short within 90 seconds causes a fire alarm. This type is always active and can only be bypassed by the Installer code or the Master code, (field 3*85).

Type 17: Fire Waterflow

Provides a trouble condition on open circuit and an alarm on a short circuit that remains longer than the programmed time delay (fields 3*16 and 3*18). The alarm can be silenced by either an entry of **User Code + OFF** or when the zone restores (field 3*14). This type is always active and can only be bypassed by the Installer code or the Master code, (field 3*85). For zone type 17 a "fault" programmed in the event type.

Type 18: Fire Supervisory

Provides a supervisory response on a short circuit. Open circuit can be programmed for either a trouble or supervisory response (field 3*13). This type is always active and can only be bypassed by the Installer code or the Master code, (field 3*85). For zone type 18 a "fault" programmed in the event type.

Type 19: 24-Hour Trouble

Provides a trouble response on a short or open circuit. No alarm sounders are activated.

Type 20: Arm-STAY (5800 Series devices only)

Causes the system to arm in the STAY mode when the zone is activated.

Type 21: Arm-AWAY (5800 Series devices only)

Causes the system to arm in the AWAY mode when the zone is activated.

Type 22: Disarm (5800 Series devices only)

Causes the system to disarm when the zone is activated.

Type 23: No Alarm Response

Used on a zone when an output relay action is desired, but with no accompanying alarm (e.g., for lobby door access).

Type 27: Access Point

Assign this zone type to an input device (hardwired zone, wireless zone, keypad, access control relay, etc.) that controls an access entry point (e.g., a door). The access point entry relay can be assigned to an access control relay (controlled by the VISTA-128FBPT/ VISTA-250FBPT), ECP relay (4204), or to the access control system independent of the VISTA-128FBPT/ VISTA-250FBPT.

Type 29: Momentary Exit

Used to cause an access point programmed for entry to revert to an exit point for 15 seconds. After the 15 seconds, it automatically reverts to an entry point. Use this zone type only with VistaKey modules.

NOTE FOR PANIC KEYS: Keypad panic zones share the same zone response type for all 8 partitions, but panics may be individually enabled for each partition.

IMPORTANT! FAULT ANNUNCIATION

Polling loop and RF troubles (zones 988, 990, and 997) report as trouble conditions only, and as such, should be assigned zone type 19 if annunciation is desired. See <i>Polling Loop Supervision</i> and <i>RF System Operation and Supervision</i> in <i>SECTION 3: Installing the Control</i> for more information.

Zone Input Type Definitions

Each zone must be assigned an input type, which defines the where the system will "look" for status of the zone (RF receiver, polling loop, etc.). Zone input types are defined below.

Type 01 Hardwired (HW)

Reserved for built-in hardwired zones 1 through 8.

Type 02 RF Motion (RM)

Select for 5800 Series transmitters. Sends periodic check-in signals, fault and low-battery signals. The control panel automatically restores the zone to "ready" after a few seconds. This type is designed for facilities with multiple motion detectors that may fault and restore simultaneously. The transmitter must remain within the receiver's range.

NOTE: If using RF Motion with a door/window type transmitter, only loop 1 may be used.

Type 03 Supervised RF (RF)

Select for 5800 Series transmitters that will be supervised for check-in signals. The transmitter must remain within the receiver's range.

Type 04 Unsupervised RF (UR)

Select for 5800 Series transmitters that will not be supervised for check-in signals. The transmitter may therefore be carried off-premises.

Type 05 Unsupervised Button RF (BR)

Select for 5800 Series transmitters specifically designed for this input type. These transmitters send only fault signals. They do not send low-battery signals until they are activated. The transmitter may be carried off-premises.

Type 06 Serial Number Polling Loop (SL)

Use for V-Plex devices with a built-in serial number.

For VistaKey, select this type for Door Status Monitor Backup DSMB. If local power to the VistaKey is lost, a V-Plex SIM, located on the VistaKey board, is powered directly from the polling loop and reports the state of the DSM via the standard V-Plex polling system.

NOTE: To obtain the DSMB function, the Input Type must be defined as 06 and the next prompt in Zone Programming (Access Point) must contain the Access Point number (01-15) (address of the VistaKey module).

Type 07 DIP Switch Loop (DP)

Select for polling loop devices that use DIP switches for programming the zone number of the device.

Type 08 Dip Switch Polling Loop Right Loop (PS)

Select for the second loop of two-zone polling loop devices.

Type 09 Console Input (CS)

Select when this zone is to be controlled by a keypad input (user code + [#] + [7] + [3]) for access control.

Type 11 VistaKey Door Status Monitor (DSM)

Select this input type when using a VistaKey module connected to a door. This must be programmed for each VistaKey module to provide the DSM zone mapping a panel zone. If this is not programmed the panel will not “see” the VistaKey module.

It is also used to determine the door is opened after a card swipe or if the door is being held open. The device is normally a magnetic switch mounted on the door. The status of the switch is different when the door is in an open position.

Type 12 VistaKey Request to Exit (RTE)

Use this input type to map an uncommitted RTE zone to an alarm panel zone. This input type is not normally used if the zone is used for a request-to-exit function.

Type 13 VistaKey General Purpose (GP)

This input type operates in the same manner as other alarm panel zones and is provided so that a zone in the proximity of the VistaKey can be wired without having to run additional wiring from the control panel.

Using a Relay to Unlock a Door

This control can be programmed so that a user can trigger a relay for 2 seconds (e.g., to unlock a door) by entering the User Code + [0].

To program a relay for this purpose, perform the following steps:

Step	Action
1	Enter Output Programming in the #93 Menu Mode.
2	Program the output type as 1 or 2.
3	For type 1, program the ECP address and relay number.
4	For type 2, program the house and unit codes.
5	Program the relay number in field 1*76 (partition-specific). NOTE: Cannot be used on partition 1 in Commercial Fire installations.



- All Fire zones should be assigned to partition 1.
- If using 5800 Series transmitters, do not the install batteries until you are ready to enroll them. After enrolling the transmitter, the battery need not be removed. This is to prevent enrolling the wrong serial number.

PROMPT	EXPLANATION
ZONE PROG? 1 = YES 0 = NO 0	Press 1 to enter ZONE PROGRAMMING mode. The following screens appear. Press [*] to display the next screen. Press # to display a previous screen.
SET TO CONFIRM? 1 = YES 0 = NO 0	This prompt appears once upon entering Zone Programming Mode. If “Yes,” Confirmation prompts will be displayed after the device’s Serial and Loop numbers have been entered later.
ENTER ZONE NO. 000 = QUIT 010 Zone 010 entered ↑	Enter the 3-digit zone number to be programmed, as follows: Protection Zones = 001–250 Relay Zones = 601–632 (use for relays on 4204CF modules only). ECP Device Supervisory Zones = 800–830 System Supervisory Zones = 988, 990, 992 (duress), 997 Keypad Panic Zones = 995 (Do not use in Fire Alarm applications), 996, 999 Press [*] to continue.

PROMPT	EXPLANATION																																				
010 ZT P RC In L 00 1 10 00 1	<p>This display appears, showing a summary of the zone's current programming. ZT = Zone Type, P = Partition, RC = Report Code, In = the input type of device, and L = the device's loop number to which the sensor is connected.</p> <p>Some devices can support more than one zone by means of individual loops (for example 5817CB, etc.). If the zone is not programmed, the display appears as shown here. If you are checking a zone's programming, and it is programmed satisfactorily, press [#] to back up one step and enter another zone number, if desired.</p> <p>Press [*] to continue.</p>																																				
010 ZONE TYPE PERIMETER 03	<p>Each zone must be assigned a zone type, which defines the way in which the system responds to faults in that zone. Refer to the <i>Zone Type Definitions</i> section for detailed definitions of each zone type. Enter the zone type desired (or change it, if necessary). Available zone types are listed below.</p> <table border="0"> <tr> <td>Zone number 010 and Zone Type 03 entry shown</td> <td>00 = Assign for Unused Zones</td> <td>14 = CO Detector Alarm</td> </tr> <tr> <td>† These are special zone types used with 5800 Series Wireless Pushbutton Units that result in arming the system in the STAY or AWAY mode, or disarming the system, depending on the selection made.</td> <td>01 = Entry/Exit #1, Burglary</td> <td>16 = Fire With Verification</td> </tr> <tr> <td></td> <td>02 = Entry/Exit #2, Burglary</td> <td>17 = Waterflow</td> </tr> <tr> <td></td> <td>03 = Perimeter, Burglary</td> <td>18 = Fire Supervisory</td> </tr> <tr> <td></td> <td>04 = Interior Follower, Burglary</td> <td>19 = 24-Hour Trouble</td> </tr> <tr> <td></td> <td>05 = Trouble Day/Alarm Night</td> <td>20 = Arm-STAY†</td> </tr> <tr> <td></td> <td>06 = 24 Hr. Silent Alarm</td> <td>21 = Arm AWAY†</td> </tr> <tr> <td></td> <td>07 = 24 Hr. Audible Alarm</td> <td>22 = Disarm†</td> </tr> <tr> <td></td> <td>08 = 24 Hr. Auxiliary</td> <td>23 = No Alarm Response (e.g., relay activation)</td> </tr> <tr> <td></td> <td>09 = Fire Without Verification</td> <td>27 = Access Point</td> </tr> <tr> <td></td> <td>10 = Interior Delay, Burglary</td> <td>29 = Momentary Exit (used with VistaKey module)</td> </tr> <tr> <td></td> <td>13 = Remote P/S</td> <td></td> </tr> </table> <p>Press [*] to continue.</p>	Zone number 010 and Zone Type 03 entry shown	00 = Assign for Unused Zones	14 = CO Detector Alarm	† These are special zone types used with 5800 Series Wireless Pushbutton Units that result in arming the system in the STAY or AWAY mode, or disarming the system, depending on the selection made.	01 = Entry/Exit #1, Burglary	16 = Fire With Verification		02 = Entry/Exit #2, Burglary	17 = Waterflow		03 = Perimeter, Burglary	18 = Fire Supervisory		04 = Interior Follower, Burglary	19 = 24-Hour Trouble		05 = Trouble Day/Alarm Night	20 = Arm-STAY†		06 = 24 Hr. Silent Alarm	21 = Arm AWAY†		07 = 24 Hr. Audible Alarm	22 = Disarm†		08 = 24 Hr. Auxiliary	23 = No Alarm Response (e.g., relay activation)		09 = Fire Without Verification	27 = Access Point		10 = Interior Delay, Burglary	29 = Momentary Exit (used with VistaKey module)		13 = Remote P/S	
Zone number 010 and Zone Type 03 entry shown	00 = Assign for Unused Zones	14 = CO Detector Alarm																																			
† These are special zone types used with 5800 Series Wireless Pushbutton Units that result in arming the system in the STAY or AWAY mode, or disarming the system, depending on the selection made.	01 = Entry/Exit #1, Burglary	16 = Fire With Verification																																			
	02 = Entry/Exit #2, Burglary	17 = Waterflow																																			
	03 = Perimeter, Burglary	18 = Fire Supervisory																																			
	04 = Interior Follower, Burglary	19 = 24-Hour Trouble																																			
	05 = Trouble Day/Alarm Night	20 = Arm-STAY†																																			
	06 = 24 Hr. Silent Alarm	21 = Arm AWAY†																																			
	07 = 24 Hr. Audible Alarm	22 = Disarm†																																			
	08 = 24 Hr. Auxiliary	23 = No Alarm Response (e.g., relay activation)																																			
	09 = Fire Without Verification	27 = Access Point																																			
	10 = Interior Delay, Burglary	29 = Momentary Exit (used with VistaKey module)																																			
	13 = Remote P/S																																				
010 Arm w/ Fault? 1 = YES 0 = NO 0	<p>If you selected response type 1, 2, 4, or 10, this prompt appears. Enter 1 to enable arming of the partition with this zone faulted. The zone must be restored (see Force Arming, the next prompt) before the exit delay expires otherwise the system starts the entry delay and must be disarmed, or an alarm occurs.</p>																																				
010 Force Arming? 1 = YES 0 = NO 0	<p>If you entered 1 (YES) at the previous prompt, this prompt appears. Enter 1 to enable the system to automatically bypass the zone if it is faulted at the end of the exit delay.</p> <p>If you enter 0 to disable and the zone is faulted at the end of exit delay, the system either performs the exit error logic, if field 1*20 is enabled, or an alarm occurs.</p> <p>NOTE: Force Arming cannot be enabled for UL installations.</p>																																				
010 Vent zone ? 1 = YES 0 = NO 0	<p>If you selected response type 3, this prompt appears. Enter 1 to enable the arming of the partition with this zone faulted (force arm). The zone is automatically bypassed.</p> <p>NOTE: The zone may be unbypassed simply by restoring the zone (e. g., closing the window), if the Vent Re-arm option (next prompt) for the zone is enabled.</p> <p>Enter 0 to disable.</p> <p>Press [*] to continue.</p>																																				
010 Vent Re-arm ? 1 = YES 0 = NO 1	<p>If you entered 1 (YES) at the previous prompt, this prompt will appear. Enter 1 to enable the system to automatically unbypass the zone when it is restored (e.g., by closing the window).</p> <p>Enter 0 to disable. The zone is bypassed for the duration of the armed period regardless of the zone status.</p> <p>Press [*] to continue.</p>																																				
010 STAY MODE None 0	<p>If you selected response type 1, 2, 3, 4, 5, or 10, this prompt will appear. Enter the STAY mode for this zone (0-2).</p> <p>0 = None. The zone is not bypassed when the partition is armed STAY.</p> <p>1 = Stay 1. The zone is automatically bypassed when the user enters [User Code] + [3] (STAY) + [1].</p> <p>2 = Stay 2. The zone is automatically bypassed when the user enters [User Code] + [3] (STAY) + [2].</p> <p>NOTES:</p> <p>0 (None) cannot be selected for response types 4 and 10.</p> <p>Response types 4 and 10 are defaulted for STAY mode 1.</p> <p>If the user enters [User Code] + [3] (STAY) + [3], all zones assigned to Stay mode 1 and 2 in the partition are automatically bypassed.</p> <p>If none of the zones in the partition are assigned to Stay mode 2, then when the user enters [User Code] + [3] (STAY), all zones assigned to Stay mode 1 are automatically bypassed.</p> <p>Press [*] to continue.</p>																																				

PROMPT	EXPLANATION
010 Auto-stay ? 1 = YES 0 = NO 0	<p>If you selected response type 1, 2, 3, 4, 5, or 10, this prompt will appear. Enter 1 to enable. The zone is automatically bypassed if none of the entry/exit zones are opened during the exit delay time (no one exits the premises). Enter 0 to disable.</p> <p>NOTES: All zones enabled for auto-stay except types 3 and 5 have exit delay time when the partition is armed. If auto-stay is enabled, make sure at least one zone is programmed for entry/exit in the same partition, otherwise this zone will be automatically bypassed every time the partition is armed.</p> <p>Press [*] to continue.</p>
010 Silent ? 1 = YES 0 = NO 1	<p>If you selected response type 1, 2, 3, 4, 5, or 10, this prompt will appear. Enter 1 to enable. The zone follows all the selected response type's characteristics, except in the alarm condition, the alarm output and the keypad sounder do not sound and the keypad does not display the alarm condition.</p> <p>Enter 0 to disable.</p> <p>Press [*] to continue.</p>
010 Bypass Group 01-15 01	<p>If you selected response type 1, 2, 3, 4, 5, or 10, this prompt will appear. Enter the bypass group for the zone (01-15). This enables the user to bypass a group of zones by entering [User Code] + [6] (Bypass) + [*] + [Group No.] (01-15).</p> <p>Enter 00 for None.</p> <p>Press [*] to continue.</p>
010 Access Point (00-15) 01	<p>If response type 27, or 29 was selected, this prompt will be displayed. Enter the access point to be controlled by the input type (00-15 for type 27; 01-15 for type 29).</p> <p>NOTE: If you are using the VistaKey module, the access point must match the address that was set in the module.</p> <p>Press [*] to continue.</p>
10 ENTRY OR EXIT 1	<p>If response type 27, or 29 was selected, this prompt will be displayed. Enter whether the access point is an entry or exit point.</p> <p>0 = entry; 1 = exit</p> <p>Press [*] to continue.</p>
10 Partition 1	<p>Enter the partition number (1-8) you are assigning this zone to.</p> <p>Press [*] to continue.</p>
010 REPORT CODE 1 st 03 2 nd 12 3C	<p>Enter the report code. The report code consists of 2 hexadecimal digits, each in turn consisting of 2 numerical digits. For example, for a report code of "3C," enter 03 for "3" and 12 for "C."</p> <p>(Refer to the <i>System Communication</i> section in the <i>Installation and Setup Guide</i> for more information about report codes and reporting formats.)</p> <p>Press [*] to continue.</p>
010 BELL/RLY SEL 0	<p>Each zone can be assigned to activate either one or both Notification Appliance Circuits and/or the system's auxiliary relay. Enter one of the following assignments:</p> <p>0=none; 1=bell 1; 2=bell 2; 3=bell 1 & bell 2; 4=aux relay; 5=bell 1 & aux relay; 6=bell 2 & aux relay; 7=bell 1 & bell 2 & aux relay.</p> <p>Press [*] to continue.</p>

PROMPT	EXPLANATION
<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">(01-) INPUT TYPE</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">RF Xmitter 3</div> <p>Input types 4 & 5 are valid for certain 5800 Series transmitters only If using input type 02 with a door/window type transmitter, only loop 1 may be used. If you selected response type 12, 28, or 29 the input type MUST be 00.</p>	<p>Enter the input device type as follows:</p> <ul style="list-style-type: none"> 00 = not used 01 = hardwired 02 = RF motion (RM type) 03 = supervised RF transmitter (RF type) 04 = unsupervised RF transmitter (UR type) 05 = RF button-type transmitter (BR type) 06 = serial number polling loop device (SL type) 07 = DIP switch-type polling loop device 08 = right loop of DIP switch type device 09 = keypad input (code + #73) 10 = Not Used 11 = VistaKey Door Status Monitor (DM) 12 = VistaKey Request to Exit (RE) 13 = VistaKey General Purpose (GP) <p>Right loops refer to the use of the right loop on a device, which allow hardwired devices to be monitored by the polling loop.</p> <p>If you are programming hardwired or DIP switch polling loop devices, the summary display appears after completing this entry.</p> <p>NOTE: After programming, refer to the Installation and Setup Guide test section for testing of the RF devices.</p> <p>NOTE: Input types 11 (DM), 12 (RE), and 13 (GP) should only be used with VistaKey modules.</p> <p>Press [*] to continue.</p>
<div style="border: 1px solid black; padding: 2px;">010 SMART CONTACT 1 = YES 0 = NO</div>	<p>If input type 3 or 6 was selected, this prompt will be displayed. Enter 1 for devices that monitor maintenance signals (ex. 5193SD, 5193SDT) or can be used to limit fault signals in the disarmed state (ex. DT7500SN or IS2500SN). Otherwise, enter 0.</p> <p>NOTES:</p> <ol style="list-style-type: none"> 1. The Smart Contact option must ONLY be selected for devices that support the feature, otherwise unpredictable results may occur. 2. If using the 5193SD/SDT V-Plex smoke detectors the “Smart” option must be selected in zone programming or when they enroll unpredictable results may occur if the smoke goes into a High Sens or Low Sens condition.
<div style="border: 1px solid black; padding: 2px;">010 ANTI MASK 1 = YES 0 = NO 0</div>	<p>If zone type is 04 (interior) or 10 (interior with delay) and input type 06 (serial poll) is selected, this prompt will be displayed. Enable for PIRs that support anti-mask (e.g., DT7500SN). The trouble report code will be used to report the masked condition.</p>
<div style="border: 1px solid black; padding: 2px;">001 Tamper Option none 0</div>	<p>If you selected input type 1, 6, 7, or 8, this prompt displays. If the zone has a tamper switch wired in the loop in addition to a sensor contact, enter the tamper option.</p> <p>Enter 1 if the tamper switch is normally closed (wired in series) with the EOL resistor. Enter 2 if the tamper switch is normally open (wired in parallel) with the EOL resistor. Enter 0 if a tamper switch is not being used in the loop.</p> <p>NOTE: For zone response types 9 or 16 (Fire), the tamper selection must be “0” none.</p>
<div style="border: 1px solid black; padding: 2px;">010 V-PLEX RELAY? 1 = YES 0 = NO</div>	<p>If you selected input type 6, this prompt is displayed. Enter 1 if using a 4101SN Relay Module for this zone. Otherwise enter 0.</p> <p>Press [*] to continue.</p>
<div style="border: 1px solid black; padding: 2px;">010 CONS ECP ADDR (00-30) 01</div>	<p>If you selected input type 09, this prompt is displayed. Enter the ECP address of the keypad that is being used for entry/exit for this access point (00-30).</p> <p>Press [*] to continue.</p>
<div style="border: 1px solid black; padding: 2px;">010 ACCESS POINT (01-15) 01</div>	<p>If you selected input types 06, 11 - 13 this prompt is displayed. Enter the access point (01-15) to be controlled by the input type.</p> <p>NOTE: For input type 06, the selected address must be 00 if VistaKey is not selected. If you are using the VistaKey module, the access point must match the address that was set in the module.</p> <p>Press [*] to continue.</p>

PROMPT	EXPLANATION				
<table border="1"> <tr> <td>010 INPUT S/N:</td> <td>L</td> </tr> <tr> <td> Axxx-xxxx</td> <td>1</td> </tr> </table>	010 INPUT S/N:	L	Axxx-xxxx	1	<p>For Serial Number entry and Loop Number entry, do one of the following:</p> <p>a. Transmit two open and close (or close and open) sequences. For a button-type transmitter, press and release the button, wait approximately 4 seconds, then press and release the button a second time.</p> <p>OR</p> <p>b. Manually enter the 7-digit serial number printed on a label on the transmitter, using the Alpha keypad. Then press the [*] key, the cursor moves to the "L" position. You can edit the loop number, if necessary. When the loop number is acceptable, press [*].</p> <p>OR</p> <p>c. Press key [C] to copy the last serial number enrolled (used when programming a transmitter with several input loops).</p> <p>Press [*] to accept.</p>
010 INPUT S/N:	L				
Axxx-xxxx	1				
<table border="1"> <tr> <td>010 INPUT S/N:</td> <td>L</td> </tr> <tr> <td> A022-4064</td> <td>1</td> </tr> </table>	010 INPUT S/N:	L	A022-4064	1	<p>The cursor will then move to the Loop column (L) with the previously entered/transmitted serial number displayed.</p> <p>Enter the loop number (refer to 5800 Series Transmitters Loop Designations below).</p> <p>To Delete an Existing Serial Number, enter "0" in the loop number field. The serial number will change to "0"s.</p> <p>If "0" was entered in error, simply re-enter the loop number or press [#], and the serial number will return to the display.</p> <p>Press [*] to accept.</p>
010 INPUT S/N:	L				
A022-4064	1				
<table border="1"> <tr> <td>010 INPUT S/N:</td> <td>L</td> </tr> <tr> <td> A022-4064</td> <td>1</td> </tr> </table>	010 INPUT S/N:	L	A022-4064	1	<p>The system will then check for a duplicate serial/loop number combination.</p> <p>If a duplicate serial/loop number combination is found, the keypad will emit a single long beep, and display the serial number along with a "?" for the loop number, allowing you to re-enter the correct loop number.</p> <p>If the serial/loop number combination is not a duplicate in the system, a display appears showing the serial number and loop number entry.</p> <p>Press [*] to continue.</p>
010 INPUT S/N:	L				
A022-4064	1				

5800 Series Transmitters Loop Designations

PROMPT	EXPLANATION
XMIT TO CONFIRM PRESS * TO SKIP	Confirmation Option: This prompt only appears if you answered "Yes" at the first prompt. The system enters a confirmation mode so that the operation of the actual programmed input can be confirmed. Activate the loop input or button that corresponds to this zone. At any time during this step, you may press the [*] key on the keypad to save the serial and loop number combination without confirming.
Entd A022-4063 1 Rcvd A022-4064	If the serial number transmitted <u>does not</u> match the serial number entered , a display similar to the one at the left appears. If the loop number does not match, it is also displayed. If so, activate the loop input or button on the transmitter once again. If a match is not obtained (i.e., summary display does not appear), press the [#] key twice and then enter or transmit the correct serial number.
010 ZT P RC In L 03 1 3C RF 1s	If the serial number transmitted <u>does</u> match the serial number entered, the system beeps 3 times and a summary display appears, showing that zone's programming. Note that an "s" indicates that a transmitter's serial number has been enrolled. Press [*] to accept the zone information.
ENTER ZONE NO. 000 = QUIT 011	The system now returns to the "ENTER ZONE NO." prompt for the next zone. When all zones have been programmed, enter "000" to quit.

After you have enrolled each wireless device, remove ONE of the serial number labels from that device and affix it in the appropriate column on the worksheets provided later in this *Programming Guide*; then enter the other information (zone number, zone type, etc.) relevant to that device.



When you have finished programming all zones, test each using the system's Test Mode. Do not use the Transmitter ID Sniffer Mode. The system checks only for transmission of one zone on a particular transmitter, NOT the zones assigned to each additional loop, and also does not verify polling loop type zones.

Expert Mode Zone Programming

Expert mode allows you to program zones using the minimum number of screens and keystrokes.



Expert Mode Zone Programming does not provide the capability to program some of the zone's attributes, such as Arm w/Fault, Vent Zone, STAY mode, Auto-STAY, Bypass Group, etc. If you want to program a zone for any of these attributes, you must use Zone Programming.

Enter the Programming mode with **[Installer Code] + 8 0 0 0**

Before programming your zones, do the following:

1. Program field **2*00: Number of Partitions**.
2. Enable your RF Receiver in *Device Programming* menu mode.

To program your zones, press *93 to display the "ZONE PROG?" prompt. Enter "0" (NO) to each prompt until the "EXPERT MODE?" prompt appears.

PROMPT	EXPLANATION
<pre>EXPERT MODE? 1 = YES 0 = NO 0</pre>	Press 1 to enter Expert mode.
<pre>SET TO CONFIRM? 0 = NO 1 = YES 0</pre>	This prompt appears once upon entering Expert Mode. If you select "Yes," Confirmation prompts will be displayed after the device's Serial and Loop numbers have been entered later.
<pre>Zn ZT P RC In L 001 03 1 10 HW -</pre>	A summary display appears, showing zone 1's current programming or default values.
<pre>Zn ZT P RC In L 010 03 1 10 RF 1s</pre>	Enter the desired 3-digit zone number and press [*]. NOTE: If you want to exit the Expert mode, enter "000" + [*]. If an "s" appears after the loop number, it indicates that the transmitter's serial number has been enrolled. Use the [D] key to enter and duplicate wireless keys (see "Entering Wireless Keys" later)
<pre>Zn ZT P RC In L 010 03 1 10 RF -</pre>	Enter all zone information except for Loop number, or press "C" to copy the zone information on this screen from the last saved zone (including Loop). ZT = Zone Type P = Partition RC = Report Code In = Input Device Type L = Loop number to which the sensor is connected. NOTE: Pressing the [C] copies the zone information from the last saved zone, which includes the input type. Verify this information is correct for this zone. On this screen: <ul style="list-style-type: none"> • Use the [A] key to move to the right. • Use the [B] key to move to left and to back up to "ZT" field. Press [*] to accept the existing or newly-entered zone information.

PROMPT	EXPLANATION
--------	-------------

ZN B M V A C E AD 010 2 1 1 0 1 1 01	<p>Enter the remainder of the zone's information, or press the [C] key to copy the zone attributes on this screen from the last saved zone.</p> <p>B = Bell/Relay Assignment M = Maintenance (only used if "In" = 3 or 6) V = Do Not Use. Must be set to "0". AC = Access Point (only used if ZT = 27, 29 or In = 6, 11, 12, 13) E = Entry or Exit? (only used if ZT = 27) AD = Address (only used if "In" = 9) If "In" = 9, enter the Device Address</p> <p>NOTE: Pressing the [C] copies the zone attributes from the last saved zone. Verify the attributes for this zone are correct.</p> <p>On this screen:</p> <ul style="list-style-type: none"> • Use the [A] key to move to the right. • Use the [B] key to move to left and to back up to "V" field. <p>Press [*] to accept existing information.</p>
---	---

010 INPUT S/N: L A XXX-XXXX -	<p>If you entered RM, RF, BR, UR or SL for the Input Type, this screen displays. Otherwise the summary screen for the next zone displays.</p> <p>Enter the 7-digit serial number, using one of the following methods:</p> <ol style="list-style-type: none"> a. Transmit two open and close (or close and open) sequences. For a button-type transmitter, press and release the button, wait approximately 4 seconds, then press and release the button a second time. OR b. Manually enter the 7-digit serial number printed on a label on the transmitter, using the alpha keypad. Then press the [*] key, the cursor will move to the "L" position. You can edit the loop number, if necessary. When the loop number is acceptable, press [*]. OR c. Press key [C] to copy the last serial number enrolled (used when programming a transmitter with several input loops). <p>Remember, you can use the [A] key to move to the right or the [B] key to move to the left. You can also use the [#] key to back up without saving.</p>
----------------------------------	--

010 INPUT S/N: L A022-4064 1	<p>Press [*] to accept the serial number and advance to the "L" position (if method "a" or "c" was used), then enter the loop number. If necessary, press the [#] key to back up without saving, and re-enter or edit the serial number before pressing [*] to save</p> <p>The system checks for a duplicate. If a duplicate serial/loop number combination is found, the keypad will emit a single long beep, and display the serial number along with a "?" for the loop number, allowing you to re-enter the correct loop number.</p>
---------------------------------	--

010 INPUT S/N: L A000-0000 1	<p>To Delete an Existing Serial Number, enter "0" in the loop number field. The serial number will change to "0"s.</p> <p>If "0" was entered in error, simply re-enter the loop number or press [#], and the serial number will return to the display.</p>
---------------------------------	---

XMIT TO CONFIRM PRESS * TO SKIP	<p>The prompt to confirm appears. This prompt only appears if you answered "Yes" at the "SET TO CONFIRM?" prompt.</p> <p>The system enters a confirmation mode so that the operation of the actual programmed input can be confirmed. Activate the loop input or button that corresponds to this zone. At any time during this step, you may press the [*] key on the keypad to save the serial and loop number combination without confirming.</p>
------------------------------------	---

Entd A022-4063 1 Rcvd A022-4064	<p>If the serial number transmitted <u>does not</u> match the serial number entered, a display similar to the one at the left appears. If the loop number does not match, it also is displayed.</p> <p>If so, activate the loop input or button on the transmitter once again. If a match is not obtained (i.e., summary display for the next zone does not appear), press the [#] key twice and then enter or transmit the correct serial number.</p> <p>Activate the button on the wireless key again after re-entering the serial number.</p>
------------------------------------	---

Zn ZT P RC In L 011 00 1 10 00 1	<p>If the serial number transmitted <u>matches</u> the serial number entered, the system beeps 3 times and advances to the summary display for the next zone's programming.</p> <p>After all the zones have been programmed, enter 000 for the zone number to quit.</p>
-------------------------------------	---

After you have enrolled each wireless device, remove ONE of the serial number labels from that device and affix it in the appropriate column on the worksheets provided later in this *Programming Guide*; then enter the other information (zone number, zone type, etc.) relevant to that device.

Report Code Programming

All report codes are entered using #93 Menu Mode Programming, either through Report Code Programming, or through Zone Programming while entering other zone information. In the VISTA-128FBPT/VISTA-250FBPT, reports are divided into six categories. These categories represent the main menu options in Report Code Programming. Reports and the categories in which they are found are as follows:

ALARM CODES	RESTR, SUPV. CODES (for groups of 16 zones)	SYSTEM GROUP #1
Zone Alarm Reports	Alarm Restore Trouble Trouble Restore Bypass Bypass Restore	Closing (arm AWAY) Opening (disarm) System Low Battery Low Battery Restore AC Loss AC Restore Periodic Test Power Cancel Program Tamper
SYSTEM GROUP #2	SYSTEM GROUP #3	SYSTEM GROUP #4
Arm STAY Time Set, Log Reset Dialer Queue Overflow Exit Error by Zone Recent Close	Early Open Early Close Late Open Late Close Failed to Open Failed to Close Auto-Arm Failed Schedule Change	Fire Walk-Test Start Fire Walk-Test End Off-Normal

The programming sequence that follows assumes that you will be entering all reports for the system at one time. In actuality, you may skip from one main menu option to another by pressing **0** (No) at each main menu option. Main menu options are highlighted in bold text. To enter report codes, do the following:

Enter Program Mode: **[Installer Code] + 8 0 0 0**. Then press **#93**. Enter **0** (No) at each main menu option until the *Report Code Programming* option is displayed.

PROMPT	EXPLANATION
REPORT CODE PROG 1 = YES 0 = NO 0	Press 1 (Yes) to enter to <i>Report Code Programming</i> .
Zone Alarm Reports	
ALARM, ID DIGIT? 1 = YES 0 = NO 0	Press [1] (Yes) to enter Alarm Report Codes for zones. Press [0] (No) to skip to the next main menu option.
ENTER ZONE NO. 000 = QUIT 001	Enter the zone number for which you are entering the report code. Press [*] to continue.
001 REPORT CODE 1st 00 2nd 00 00	Enter the first digit of the Alarm report code (double-digit entry) and press [*] . Enter the 2nd digit of the Alarm Report code. Press [*] to continue.
ENTER ZONE NO. 000 = QUIT 001	Enter the zone number for which you are entering the report code. When all zone Alarm Codes have been programmed, enter 000 to Quit. Press [*] to continue.
QUIT REPORT MENU 1 = YES 0 = NO 0	If you have completely finished entering report codes, press [1] (Yes) to quit <i>Report Code Programming</i> . If you wish to enter other system report codes, enter 0 (No). Press [*] to continue.

Restore/Supervisory Codes

PROMPT	EXPLANATION
<p>RESTR, SUPV. CODE 1 = YES 0 = NO 0</p>	<p>Press [1] (Yes) to enter Restore and Supervisory Codes for zones.</p>
<p>ENTER ZN FOR GRP 000 = QUIT 001</p>	<p>Enter one zone for each group of 16 zones (001-016, 017-032, etc.).</p>
<p>ALARM RESTORE GRP 001-016 00</p>	<p>Enter the first digit of the Alarm Restore Report Code for this group of zones (double-digit entry). The second digit (for two-digit reporting formats) is automatically the ID (second) digit of the Alarm Report Code for each zone (if programmed).</p> <p>Press [*] to continue.</p>
<p>TROUBLE GRP 001-016 00</p>	<p>Enter the first digit of the Trouble Report Code for this group of zones (double-digit entry). The second digit (for two-digit reporting formats) is automatically the ID (second) digit of the Alarm Report Code for each zone (if programmed).</p> <p>Press [*] to continue.</p>
<p>TROUBLE RESTORE GRP 001-016 00</p>	<p>Enter the first digit of the trouble restore code (single-digit entry) and press [*]. The second digit (for two-digit reporting formats) is automatically the ID (second) digit of the alarm report code for each zone (if programmed).</p> <p>Press [*] to continue.</p>
<p>BYPASS GRP 001-016 00</p>	<p>Enter the first digit of the Bypass Report Code (double-digit entry) and press [*]. The second digit (for two-digit reporting formats) is automatically the ID (second) digit of the Alarm Report Code for each zone (if programmed).</p> <p>Press [*] to continue.</p>
<p>BYPASS RESTORE GRP 001-016 00</p>	<p>Enter the first digit of the Bypass Restore Report Code (double-digit entry) and press [*]. The second digit (for two-digit reporting formats) is automatically the ID (second) digit of the Alarm Report Code for each zone (if programmed).</p> <p>Press [*] to continue.</p>
<p>ENTER ZN FOR GRP 000 = QUIT 017</p>	<p>Enter one zone for each group of 16 zones. When you are finished entering Restore and Supervisory Codes for all zone groups, enter 000.</p> <p>Press [*] to continue.</p>
<p>QUIT REPORT MENU 1 = YES 0 = NO 0</p>	<p>If you have completely finished entering report codes, press [1] (Yes) to quit <i>Report Code Programming</i>. If you wish to enter other system report codes, enter 0 (No).</p> <p>Press [*] to continue.</p>

System Group #1 Codes

PROMPT	EXPLANATION
SYSTEM GROUP #1? 1 = YES 0 = NO 0	To enter System Group #1 codes, press 1 (Yes).
CLOSE 1st 00 2nd 00	Enter the first digit of the Closing (Arm-AWAY) report. Press [*]. Enter the second digit of the report. If the user number is desired as the second digit, enter 01 (not necessary for Contact ID). Press [*] to continue.
	Enter the rest of the codes in the same manner. Other report codes in System Group #1 are: <ul style="list-style-type: none">• Opening (Disarm) Also, enable this if you desire Callback Requested reports (the panel answers a phone call from the downloader).• System Low Battery• Low Battery Restore• AC Loss• AC Restore• Periodic Test• Power• Cancel• Program Tamper Once you have entered these report codes, the system prompts you with the Quit menu.
QUIT REPORT MENU 1 = YES 0 = NO 0	If you have completely finished entering report codes, press 1 (Yes) to quit <i>Report Code Programming</i> . If you wish to enter other system report codes, enter 0 (No). Press [*] to continue.

System Group #2 Codes

PROMPT	EXPLANATION
SYSTEM GROUP #2 ? 1 = YES 0 = NO 0	To enter System Group #2 codes, press [1] (Yes).
STAY 1st 00 2nd 00	Enter the first digit of the Arm-STAY report. Press [*]. Enter the second digit of the report. If the user number is desired as the second digit, enter 01 (not necessary for Contact ID). Press [*] to continue.
	Enter the rest of the codes in the same manner. Other codes in System Group #2 are: <ul style="list-style-type: none">• Time Set, Log Reset• Dialer Queue Overflow• Exit Error by Zone• Recent Close Once you have entered these report codes, the system prompts you with the Quit menu.
QUIT REPORT MENU 1 = YES 0 = NO 0	If you have completely finished entering report codes, press [1] (Yes) to quit <i>Report Code Programming</i> . If you wish to enter other system report codes, enter 0 (No). Press [*] to continue.

System Group #3 Codes

PROMPT	EXPLANATION
SYSTEM GROUP #3 ? 1 = YES 0 = NO 0	To enter System Group #3 codes, press [1] (Yes).
EARLY OPEN 1st 00 2nd 00	Enter the first digit of the Early Opening Report Code. Press [*] . Enter the second digit of the report code. If the user number is desired as the second digit, enter 01 (not necessary for Contact ID). Press [*] to continue.
	Enter the rest of the codes in the same manner. Other codes in System Group #3 are: <ul style="list-style-type: none">• Early Close• Late Open• Late Close• Failed to Open• Failed to Close• Auto-Arm Failed• Schedule Change Once you have entered these report codes, the system prompts you with the Quit menu.
QUIT REPORT MENU 1 = YES 0 = NO 0	If you have completely finished entering report codes, press [1] (Yes) to quit <i>Report Code Programming</i> . If you wish to enter other system report codes, enter 0 (No). Press [*] to continue.

System Group #4 Codes

PROMPT	EXPLANATION
SYSTEM GROUP #4 ? 1 = YES 0 = NO 0	To enter System Group #4 codes, press [1] (Yes).
WALK TEST START 1st 00 2nd 00	Enter the first digit of the Fire Walk Test Start Report Code. Press [*] . Enter the second digit of the report code. Press [*] to continue.
	Enter the rest of the codes in the same manner. Other codes in System Group #4 are: <ul style="list-style-type: none">• Fire Walk-Test End.• Off-Normal. Once you have entered these report codes, the system prompts you with the Quit menu.
QUIT MENU MODE? 1 = YES 0 = NO 0	Enter 1 to exit back to normal Programming mode. Enter 0 to stay in Menu mode.

Alpha Descriptors Programming

You can program a user-friendly English language description/location for all protection zones, relays, keypad panics, polling loop short, and RF receiver supervision troubles.

Each description can be composed of a combination of words (up to 3) that are selected from a vocabulary of 244 words stored in memory, and any word can have an "s" or " 's " added to it.

NOTE: Due to the use of 3-digit zone numbers, the first word of the descriptor is limited to 6 characters if you want it to fit on the top line of the display.

In addition, up to 60 installer-defined words can be added to those already in memory. Thus, when an alarm or trouble occurs in a zone, an appropriate description for the location of that zone will be displayed at the keypad.

A custom installer's message can be programmed for each partition which is displayed when the system is "Ready" (e.g., THE PETERSONS').

1. To program alpha descriptors, enter Programming mode, then press **#93** to display "ZONE PROG?"
2. Press **[0]** (NO) twice to display "ALPHA PROG?".
3. Press **[1]** to enter *Alpha Programming*.

There are 6 submenu selections that will be displayed one at a time.

Press **[1]** to select the mode desired.

Press **[0]** to display the next mode available. The alpha menu selections are:

ZONE DESCRIP?	For entering zone descriptors.
DEFAULT SCREEN?	For creating custom message; displayed when system is ready.
CUSTOM WORD?	For creating custom words for use in descriptors.
PART DESCRIP?	For creating 4-character partition names.
EXIT EDIT MODE?	Press [1] to exit back to #93 Menu Mode.

4. Refer to the sections that follow for procedures for adding alpha descriptors.

Zone Descriptors

1. **Select ZONE DESCRIPTOR mode.**

The keypad keys perform the following functions:

- [3] Scrolls both alphabet and actual words in ascending alphabetical order.
- [1] Scrolls both alphabet and actual words in descending alphabetical order.
- [2] Adds or removes an "s" or " 's " to a vocabulary word.
- [6] Switches between alphabet and actual word list; used to accept entries.
- [8] Saves the zone description in the system's memory.
- [#] [#] plus zone number displays the description for that zone.

2. **Enter the zone number to which you want to assign a descriptor.**

For example, key **[*] 001** to begin entering the description for Zone 1, (key **[*] 002** for Zone 2, **[*] 003** for Zone 3, etc.).

The following is displayed: * ZN 001 A.

Note that the first letter of the alphabet appears after the zone number, and that the zone number is automatically included with the description.

3. **Enter the descriptor for that zone.**

Use one of two methods as follows:

(Assume, for example, that the desired description for Zone 1 is BACK DOOR.)

- a) Press **[#]** followed by the 3-digit number of the first word from the fixed dictionary shown later in this section (e.g., **[0][1][5]** for BACK).

Press **[6]** in order to accept the word and proceed, or press **[8]** to store the complete descriptor and exit;

or

- b) Select the first letter of the desired description (note that "A" is already displayed). Use the **[3]** key to advance through the alphabet and the **[1]** key to go backward.

Press **[3]** key repeatedly until "B" appears (press **[1]** to go backwards if you happen to pass it), then press **[6]** to display the first available word beginning with "B".

Press **[3]** repeatedly to advance through the available words until the word "BACK" is displayed.



To add an "s" or " 's," if you need to, press **2**. The first depression adds an "s," the second depression adds an " 's," the third depression displays no character (to erase the character), the fourth depression adds an "s," etc.

4. **Accept the word.**

To accept the word, press [6], which switches back to the alphabet list for the next word, or press [8] to store the complete descriptor and then exit.

5. **Select the next word.**

For selection of the next word (DOOR), repeat step 3a (word #063) or 3b, but selecting the word "DOOR."

To accept the word, press [6], which again switches back to alphabet list.

6. **Store the descriptor.**

When all desired words have been entered, press [8] to store the description in memory.

To review the zone descriptors, key [#] plus zone number (e.g., #001).

To edit zone descriptors, key [*] plus zone number (e.g., *001)

7. **Exit Zone Description Mode: enter 000.**

Default Screen (Custom Message Display)

Normally, when the system is in the disarmed state, the following display is present on the keypad.

```
****DISARMED****  
READY TO ARM
```

Part or the entire above message can be modified to create a custom installer message for each partition. For example, "****DISARMED****" on the first line or "READY TO ARM" on the second line could be replaced by the installation company name or phone number for service.

NOTE: There are only 16 character spaces on each of the two lines.

To create a custom display message, proceed as follows:

1. **Select Default Screen mode.**

The keypad asks for the partition number for this message.

Enter the partition number. Press [*] to accept entry.

The following display appears:

```
****DISARMED****  
READY TO ARM
```

A cursor is present at the extreme left of the first line (over the first "star"). Press [6] to move the cursor to the right and [4] to move the cursor to the left. Press [7] to insert spaces or erase existing characters.

2. **Create the message.**

For example, to replace "READY TO ARM" with the message "SERVICE 424-0177," proceed as follows:

Press [6] to move the cursor to the right, and continue until the cursor is positioned over the first location on the second line.

Press [3] to advance through the alphabet to the first desired character (in this case, "S"). Press [1] to go backward, when necessary. When the desired character is reached, press [6].

The cursor then moves to the next position, ready for entry of the next character (in this example, "E"). When the cursor reaches a position over an existing character, press [3] or [1] to advance or back up from that character in the alphabet.

Proceed in this manner until all characters in the message have been entered.

3. **Save the message.**

Store the new display message in memory by pressing [8].

4. **The system asks for a new partition number.**

Enter 0 to quit or 1-8 for a new partition number.

Custom Words

Up to 60 installer-defined words can be added to the built-in vocabulary. Each of the 60 "words" can actually consist of several words, but bear in mind that a maximum of 10 characters can be used for each word string.

1. **Select CUSTOM WORD Mode.**

The keys perform the following functions:

[3] Advances through alphabet in ascending order.

[1] Advances through alphabet in descending order.

[6] Selects desired letter; moves the cursor 1 space to the right.

[4] Moves the cursor one space to the left.

[7] Inserts a space at the cursor location, erasing any character at that location.

[8] Saves the new word in the system's memory.

[*] Returns to Description Entry Mode.

2. **Enter the custom word number (01-60) you want to create.**

For example, if you are creating the first word (or word string), enter 01; when creating the second word, enter 02, and so on. A cursor now appears at the beginning of the second line.

3. Type the word using one of two methods as follows:

a) Press [#], followed by the 2-digit entry for the first letter you would like to display (e.g., **65** for "A").
When the desired character appears, press **[6]** to select it. The cursor will then move to the right, in position for the next character. Press [#] plus the 2-digit entry for the next letter of the word.

or

b) Press **3** to advance through the list of symbols, numbers, and letters.
Press **1** to move back through the list.

When you have reached the desired character, press **[6]** to select it. The cursor then moves to the right, in position for the next character.

4. Repeat step 3 to create the desired custom word (or words).

Press **[4]** to move the cursor to the left if necessary.

Press **[7]** to enter a blank (or to erase an existing character).

Each word or word string cannot exceed 10 characters.

5. Save the word by pressing [8].

This returns you to the "CUSTOM WORD?" display. The custom word (or string of words) is automatically added to the built-in vocabulary at the end of the group of words beginning with the same letter.

Custom words are retrieved as word numbers 255 to 314 for words 1 to 60, respectively, when using method 3a to enter alpha descriptors.

When using method 3b to enter alpha descriptors, each word appears at the end of the group of words that begin with the same letter as it does.

6. Repeat steps 2 through 6 to create up to a maximum of 60 custom words (or word strings).

7. Exit Custom Word Mode by entering 00 at the "CUSTOM WORD" prompt.

Partition Descriptors

1. Select "Part DESCRIPT." Mode.

The system asks for the partition number desired. Enter the number as a single-key entry **1-8**.

2. Follow the same procedure as for custom words.

NOTE: The partition descriptors are limited to 4 characters (e.g., WHSE for warehouse).

Alpha Descriptor Vocabulary

(For entering alpha descriptors. To select a word, press [#] followed by the word's 3-digit number.)

NOTE: This vocabulary is not to be used for relay voice descriptors. See the *Relay Voice Descriptors* section when programming relay voice descriptors.

001 AIR	060 DIALER 2	113 JEWELRY	164 POLICE	211 TOOL
002 ALARM	061 DINING	114 KITCHEN	165 POOL	212 TOWER
003 ALERT	063 DISPLAY		166 POWER	213 TRANSMITTER
005 ALLEY	064 DOCK			214 TRAP
006 AMBUSH	065 DOOR	115 LAB	167 QUAD	215 TV
007 ANTENNA	067 DOWNSTAIRS	116 LAUNDRY	168 RADIO	203 UNIT
008 AREA	068 DRAWER	117 LEAK	169 REAR	216 UPPER
009 APARTMENT	069 DRIVEWAY	118 LEFT	170 RECREATION	217 UPSTAIRS
010 ART	070 DRUG	119 LEVEL	171 REFRIG	218 UTILITY
011 ASSET	071 DUCT	120 LIBRARY	133 RELAY	219 VALVE
012 ATTIC		121 LIGHT	136 REMOTE	220 VAULT
013 AUDIO	072 EARTH	122 LIQUOR	140 RESTAURANT	221 VIBRATION
014 AUX	073 EAST	123 LIVING	004 RESTROOM	222 VIDEO
	074 ELECTRIC	124 LOADING	172 RIGHT	223 VOLTAGE
016 BACK	037 ELEVATOR	066 LOBBY	173 ROOM	
017 BAR	075 EMERGENCY	085 LOCAL	174 ROOF	224 WALL
018 BARN	076 ENTRY	125 LOCK		225 WAREHOUSE
019 BASEMENT	077 EQUIPMENT	126 LOOP	175 SAFE	226 WATER
020 BATHROOM	078 ESCALATOR	127 LORRA	176 SCREEN	227 WEST
022 BEDROOM	079 EXECUTIVE	128 LOT	146 SECURITY	228 WINDOW
023 BELL	080 EXIT	129 LOW	177 SENSOR	229 WINE
024 BELL 1	081 EXTERIOR	130 LOWER	178 SERVICE	230 WING
025 BELL 2			179 SHED	015 WOMEN
026 BLOCKED	082 FACTORY	131 MACHINE	188 SHIPPING	231 WORK
027 BLOWER	083 FAILURE	132 MODULE	180 SHOCK	
028 BOILER	084 FAMILY	134 MAIN	181 SHOP	232 XMITTER
029 BOTTOM	086 FENCE	091 MAN_PULL	182 SHORT	
030 BOX	087 FILE	135 MASTER	183 SHOW	233 YARD
031 BREAK	088 FIRE	137 MEDICAL	184 SIDE	
032 BUILDING	089 FLOOR	138 MEDICINE	185 SKYLIGHT	234 *see note
033 BURNER	090 FLOW	139 MEZZANINE	186 SLIDING	235 ZONE
	092 FREEZER	021 MEN	187 SMOKE	236 0
034 CABINET	093 FRONT	094 MIDDLE	189 SOUNDER	237 1
035 CORRIDOR	095 FURNACE	129 MODULE	190 SOUTH	238 1ST
036 CAMERA		141 MONEY	191 SPRINKLER	239 2
038 CASE	096 GALLERY	142 MONITOR	192 STAIRWAY	240 2ND
039 CASH	097 GARAGE	144 MOTION	193 STATION	241 3
040 CCTV	098 GAS	145 MOTOR	194 STATUE	242 3RD
041 CEILING	099 GATE		196 STORE	243 4
042 CELLULAR	100 GLASS	147 NORTH	197 STORAGE	244 4TH
043 CENTRAL	101 GROUND	148 NURSERY	199 STRIKE	245 5
044 CIRCUIT	102 GUEST		195 STROBE	246 5TH
045 CLIP	103 GUN	149 OFFICE	200 SUMP	247 6
046 CLOSED	104 HALL	150 OIL	201 SUPERVISED	248 6TH
047 COIN	105 HEAT	151 OPEN	202 SUPERVISION	249 7
048 COLD	106 HIGH	152 OPENING	204 SWITCH	250 7TH
049 COATROOM	107 HOLDUP	153 OUTSIDE	198 SYSTEM	251 8
050 COLLECTION	143 HOOD	154 OVERFLOW		252 8TH
051 COMBUSTION	054 HORN_CKT	155 OVERHEAD		253 9
052 COMPUTER	108 HOUSE	156 PAINTING	205 TAMPER	254 9TH
053 CONTACT	062 HVAC	158 PANIC	207 TELEPHONE	255 Custom Word 1
		157 PARKING	208 TELLER	to
055 DELAYED	109 INFRARED	159 PASSIVE	209 TEMPERATURE	314 Custom Word 60
056 DEN	110 INSIDE	160 PATIO	210 THERMOSTAT	
057 DESK	111 INTERIOR	161 PERIMETER		
058 DETECTOR	112 INTRUSION	162 PHONE		
059 DIALER 1		163 POINT		

* **NOTE:** When 234 is entered the appropriate zone number will be inserted.

CHARACTER (ASCII) CHART

(For Adding Custom Words)

32 (space)	42 *	52 4	62 >	72 H	82 R
33 !	43 +	53 5	63 ?	73 I	83 S
34 "	44 ,	54 6	64 @	74 J	84 T
35 #	45 -	55 7	65 A	75 K	85 U
36 \$	46 .	56 8	66 B	76 L	86 V
37 %	47 /	57 9	67 C	77 M	87 W
38 &	48 0	58 :	68 D	78 N	88 X
39 '	49 1	59 ;	69 E	79 O	89 Y
40 (50 2	60 <	70 F	80 P	90 Z
41)	51 3	61 =	71 G	81 Q	

NOTE: This factory-provided vocabulary of words is subject to change.

Device Programming

This menu is used to program keypads, receivers, and relay modules, etc.



Device Address **00** is always set as an alpha keypad assigned to Partition 1 with no sounder suppression options, and these settings cannot be changed.

From Data Field Programming mode, press **#93** to display "ZONE PROG?" Press **[0]** repeatedly to display "DEVICE PROG?"

PROMPT	EXPLANATION						
<div style="border: 1px solid black; padding: 5px;"> DEVICE PROG? 1=YES 0=NO 0 </div>	Press [1] to enter <i>Device Programming</i> .						
<div style="border: 1px solid black; padding: 5px;"> DEVICE ADDRESS 01-30, 00=QUIT 01 </div>	The device address identifies the device to the control. Enter the 2-digit device address number to match the device's physical address setting (01-30). Press [*] to accept entry.						
<div style="border: 1px solid black; padding: 5px;"> DEVICE TYPE 00 </div>	Select the type of addressable device as follows: <table style="width: 100%; border: none;"> <tr> <td style="width: 50%;">00 = device not used</td> <td style="width: 50%;">04 = output relay module (4204)</td> </tr> <tr> <td>01 = alpha keypad (6160/6160CR-2, GUI)</td> <td>06 = communicator</td> </tr> <tr> <td>03 = RF receiver (5881ENHC)</td> <td>12 = Remote Interactive Services (RIS)</td> </tr> </table> Press [*] to accept entry.	00 = device not used	04 = output relay module (4204)	01 = alpha keypad (6160/6160CR-2, GUI)	06 = communicator	03 = RF receiver (5881ENHC)	12 = Remote Interactive Services (RIS)
00 = device not used	04 = output relay module (4204)						
01 = alpha keypad (6160/6160CR-2, GUI)	06 = communicator						
03 = RF receiver (5881ENHC)	12 = Remote Interactive Services (RIS)						

Alpha Keypad

PROMPT	EXPLANATION				
<div style="border: 1px solid black; padding: 5px;"> 01 CONSOLE PART. 1 </div>	If you selected device type 01 (alpha keypad), this prompt appears. Enter the addressable device's default partition number (1 to maximum number of partitions programmed for system in field 2*00). This is the primary partition for the device. Enter 9 to make this keypad a "Master" keypad for the system. Press [*] to accept entry.				
<div style="border: 1px solid black; padding: 5px;"> 01 SOUND OPTION 00 </div>	If you entered device type 01 (alpha keypad), this prompt appears. Keypads can be individually programmed to suppress arm/disarm beeps, entry/exit beeps and chime mode beeps. This helps prevent unwanted sounds from disturbing users in other areas of the premises. Enter a number 00-03 for the keypad sounding suppression options desired for the keypad as follows: <table style="width: 100%; border: none;"> <tr> <td>00 = no suppression</td> </tr> <tr> <td>01 = suppress arm/disarm & entry/exit beeps</td> </tr> <tr> <td>02 = suppress chime mode beeps only</td> </tr> <tr> <td>03 = suppress arm/disarm, entry/exit and chime mode beeps</td> </tr> </table> Press [*] to accept entry.	00 = no suppression	01 = suppress arm/disarm & entry/exit beeps	02 = suppress chime mode beeps only	03 = suppress arm/disarm, entry/exit and chime mode beeps
00 = no suppression					
01 = suppress arm/disarm & entry/exit beeps					
02 = suppress chime mode beeps only					
03 = suppress arm/disarm, entry/exit and chime mode beeps					
<div style="border: 1px solid black; padding: 5px;"> 01 KEYPAD GLBL? 0 </div>	If you entered device type 01 (alpha keypad), this prompt appears. Each keypad can give users with access to multiple partitions the ability to arm and disarm those partitions from it. To enable this keypad for global arming/disarming, enter 1 . To prevent the ability to use this keypad for global arming/disarming, enter 0 . Press [*] to accept entry.				
<div style="border: 1px solid black; padding: 5px;"> 01 AUTO-STAY ARM DISABLED? 0 </div>	0 = No, 1 = Yes. If enabled (1=yes), Auto-Stay Arming is turned off for the selected keypad address (system does not automatically revert to Auto-Stay Arm mode if armed Away and no entry/exit doors are opened). Default is No. Press [*] to accept entry.				
<div style="border: 1px solid black; padding: 5px;"> 01 AUI ? 1 = YES 0 = NO 0 </div>	If you selected device type 01 (alpha keypad), this prompt appears. Enter 1 (YES) if the device is a graphic/touch-screen keypad and/or a virtual keypad used for RIS. Must be set to "0" for Commercial Fire Installations. Press [*] to accept entry.				

RF Expander

PROMPT	EXPLANATION
01 RF EXPANDER HOUSE ID 00	If you selected device type 03 (RF receiver), this prompt appears. Enter the 2-digit House ID (00-31). Press [*] to accept entry.

Output Relay Module

PROMPT	EXPLANATION
01 SUPERVISED CF? 0	If you selected device type 04 (relay module), this prompt appears. Enter 1 if the unit is a 4204CF. If not, enter 0 . If you enter 1, only Relay 1 (Output A) and Relay 3 (Output B) on each module may be programmed for functions. NOTE: For Commercial Fire installations, only one notification appliance module may be used, and only one notification appliance output (A or B) may be used on that module. Press [*] to accept entry.

Communicator

If you selected device type 6, the 6160/6160CR-2 Keypad functions similarly to the 7720P Programming Tool. See Figure 1 for the functions of the keys on the 6160CR-2.




Figure 1: 6160CR-2 Key Functions for Programming the Communicator

Each key has two possible functions: a normal function and a SHIFT function. To perform a normal key function, simply press the desired key. To perform a SHIFT key function, press SHIFT key, then press desired function key.

Normal and SHIFT key Functions:

Key	Normal Key Function	SHIFT Key Function
BS/ESC	[BS]: Press to delete entry Also, can reset EEPROM defaults *	[ESC]: Press to quit Program Mode
↓/↑	[↓]: Scroll down programming	[↑]: Scroll up programming
N/Y	[N]: Press for "NO" answer	[Y]: Press SHIFT-Y for "YES" answer
SHIF T	Press before pressing a SHIFT key function. Will light READY LED. LED goes out once a key is pressed. Press again for each SHIFT function desired.	
1/A	[1]: For entering the number 1	[A]: Used for entering C.S. ID number
2/B	[2]: For entering the number 2	[B]: Used for entering C.S. ID number
3/C	[3]: For entering the number 3	[C]: Used for entering C.S. ID number
4/D	[4]: For entering the number 4	[D]: Used for entering C.S. ID number
5/E	[5]: For entering the number 5	[E]: Used for entering C.S. ID number
6/F	[6]: For entering the number 6	[F]: Used for C.S. ID & FAST Mode
7/S	[7]: For entering the number 7	[S]: Press to display diagnostic status
8/T	[8]: For entering the number 8	[T]: Press to send TEST messages
9/X	[9]: For entering the number 9	[X]: Press to reset the 7847i
/SPACE	[]: Not used with 7847i	[SPACE]: Not used with 7847i
0	[0]: For entering the number 0	No SHIFT function
#/ENTER	[#/ENTER]: Press to accept entries	No SHIFT function

* Active only when the "REVIEW?" prompt is displayed.

The 6160/6160CR-2 Keypad displays the following prompts, which are sent by the Communicator to the control. **NOTE: These prompts are for the 7847i Communicator only. If you are using a different communicator, refer to the communicator's instructions for the correct prompts.**

PROMPT	EXPLANATION
<div style="border: 1px solid black; padding: 5px;"> DEVICE ADDRESS </div>	Enter the device address of the Communicator. The default address is 3.
<div style="border: 1px solid black; padding: 5px;"> ID # (1234) </div>	Enter the 4-digit customer account number, 0001-9999 . This ID number will appear in the messages generated by the Communicator. Messages generated by the panel and transmitted by the Communicator will contain the ID number programmed into the panel. The Communicator and the panel should have the same ID number, if possible.
	If a different 4-digit customer account number is used in the Communicator that is programmed into the alarm control, the Communicator will transmit Communicator-specific messages (power-on reset, AC fail, etc.) using the Communicator customer number, and alarm messages using the control panel's customer number. If these numbers are different, you will be billed for two AlarmNet Communicator accounts.

PROMPT	EXPLANATION
<div style="border: 1px solid black; padding: 5px;"> ODD [Y/N] (N) </div>	Enter Y for odd system flag; N for even system flag.
<div style="border: 1px solid black; padding: 5px;"> Alarmnet (Y/N) (Y) </div>	Enter Y if this is an AlarmNet installation. Enter N if this is a private system and skip to Question 7.
<div style="border: 1px solid black; padding: 5px;"> CS ID (11) </div>	Enter the primary central station's system ID number 1-7F (will not be displayed for private system users).
<div style="border: 1px solid black; padding: 5px;"> BAT PRESENT [Y/N] (N) </div>	Enter Y if optional battery will be used. Must be Y for UL installations (a battery must be installed).
<div style="border: 1px solid black; padding: 5px;"> USE RADIO # [Y/N] (N) </div>	If you selected Y , the Communicator ID number replaces the panel Subscriber ID in panel-generated messages. If you selected N , the Communicator sends panel-generated messages with the panel Subscriber ID number.
<div style="border: 1px solid black; padding: 5px;"> 2ND CS ID (12) </div>	This must be programmed with a value, even if it is the same as the primary central station. The alarm panel has the option of sending a selected message to the second central station.
<div style="border: 1px solid black; padding: 5px;"> REVIEW (Y/N) (N) </div>	Enter Y to review the programming options and to ensure that the correct responses have been made. Parameters can be changed during review. Enter N to end programming session.

Output Programming

The system supports up to 96 outputs. Outputs can be used to perform many different functions and actions. Each output must be programmed to begin one of four types of ACTIONS at a designated START event, and end that ACTION at a designated STOP event. The options used to start and stop these devices are described below, followed by the actual screen prompts and available entries.

NOTE: If you are using outputs on the polling loop (e.g., 4101SN) no more than 20 of the polling loop outputs may be programmed for the same START or STOP condition. Also, if you are using ZONE # for the START of a polling loop output and want that output to stop when the same zone restores, the STOP programming MUST BE BLANK.

If you are using Zone Type 17 (Waterflow) or 18 (Fire Supervisory) to trigger an output, you must program an Event for the START (alarm, trouble, etc.). All other Zone Type/System Operations do not require an Event.

The letter(s) in parentheses after each function described below, such as (A) after ACTION, are those that appear in the various summary displays of programmed data during programming.

ACTION (A) The "ACTION" of the device is how the device will respond when it is activated by the "START" programming. You may want the device to activate momentarily, to pulse on and off continuously, or to remain activated until some other event occurs to stop it. There are five different action choices:

- **ACTIVATE** for 2 SECONDS and then reset. If selected, it is not necessary to program a stop parameter.
- **ACTIVATE** and **REMAIN ACTIVATED** until stopped by some other event.
- **PULSE ON** and **OFF** until stopped by some other event.
- **NO RESPONSE** when the device is not used.
- **TOGGLE** on and off alternately with each activation of event. **Do not program a stop parameter as this may cause unpredictable results.**

START (STT) The "START" programming determines when and under what conditions the device is activated. The following START options are available:

- 1) **EVENT (EV)** is the condition (alarm, fault, trouble) that must occur to a zone or group of zones (zone list) in order to activate the device. These conditions apply **only** when a zone list is used. The different choices for "EVENT" are listed below and in "Programming Relays" later in this section.
 - **ALARM** Action begins upon any alarm in an assigned zone in the zone list.
 - **FAULT** Action begins upon any opening of an assigned zone in the zone list.
 - **TROUBLE** Action begins upon any trouble condition in an assigned zone in the zone list.
 - **NOT USED** Action is not dependent upon one of the above events.

ZONE LIST (ZL) is a group of zones to which the "EVENT" applies in order to activate a particular device. Note that there are a total of 15 zone lists that can be programmed; when the selected EVENT (alarm, fault or trouble) occurs in **any** zone in the selected "Start" ZONE LIST (01-15), activation of the selected device will START.

- 2) **ZONE #** A specific zone going into alarm, fault, trouble, or restore (Event programming) can be used to start the relay action. Enter the 3-digit zone number (000-250).
- 3) **ZONE TYPE/SYSTEM OPERATION (ZT)**. If all zones to be used to start the device have the same response type, and there are no other zones of this type that are **not** to activate this device, then "ZONE TYPE" may be used instead of a "ZONE LIST" and "EVENT" to activate the device.

If a system operation, such as "DISARMING" or "ANY FIRE ALARM," is to activate the device, enter the appropriate choice under the "ZONE TYPE" option.

The "ZONE TYPE/SYSTEM OPERATION" option functions independently of the "EVENT/ZONE LIST" combination.

If a specific "ZONE TYPE" is chosen, any zone of that response type going into alarm, trouble, or fault will cause the device to activate as selected in "ACTION." If the same "ZONE TYPE" is also chosen for the STOP programming, any zone of that type that *restores* will de-activate the device.

If a "SYSTEM OPERATION" is chosen, that operation will cause the device to activate as selected in "ACTION." The different choices for "ZONE TYPE" and "SYSTEM OPERATION" are listed in "Programming Relays" later in this section, and on the Programming Form.

- 4) **PARTITION NO. (P)**. The device's "Start" ZONE TYPE/SYSTEM OPERATION may be limited to an occurrence on one partition (1-8), or any partition (0).

STOP (STP): The "STOP" programming determines when and under what conditions the device is de-activated. The following options are available:

- 1). **RESTORE ZONE LIST (ZL).** If a "ZONE LIST" is used as the "Stop" event, the device de-activates when **all** the zones in that list restore from a previous fault, trouble, or alarm condition. This occurs regardless of what is programmed to "START" the device; therefore, a "RESTORE ZONE LIST" is normally only used when a "ZONE LIST" is used to start the device.
- 2). **ZONE TYPE/SYSTEM OPERATION (ZT).** Instead of using a "RESTORE ZONE LIST," you can select a specific zone (response) type or system operation action to de-activate the device.
 If you choose a specific "ZONE TYPE," any zone of that response type that restores from a previous alarm, trouble, or fault condition will cause the device to de-activate.
 If you choose a "SYSTEM OPERATION," that operation causes the device to de-activate. The different choices for "ZONE TYPE" and "SYSTEM OPERATION" are listed in "Programming Relays" later in this section, and in the Programming Form.
- 3) **PARTITION NO. (P).** The device's "Stop" Zone Type/System Operation may be limited to an occurrence on one partition (1-8), or on any partition (0).

The "ZONE TYPE/SYSTEM OPERATION" option functions independently of the "RESTORE/ZONE LIST" combination.

Output Devices Programming

From Data Field Programming Mode, press **#93** to display the "ZONE PROG?" prompt. Press **[0]** (NO) to each menu option until the "OUTPUT PGM?" prompt appears. Press **[1]** (YES).

While in this mode, press **[*]** to advance to next screen. Press **[#]** to back up to the previous screen.

PROMPT	EXPLANATION
ENTER RELAY # (00=QUIT) 01	Enter the relay (output device) identification number 01-96 . This is a reference number only, used for identification purposes. The actual module address and relay number on the module are programmed in the last two prompts. Press [*] to continue.
02 A EV ZL ZT P STT 0 0 00 00 0	Press [*] to continue.
02 A ZL ZT P STOP 0 00 00 0	The keypad displays a summary STOP screen. Press [*] to continue.
02 RELAY ACTION NO RESPONSE 0	The Relay Action is the way in which the relay will respond when activated by the "start" event. Enter the desired action for this relay as follows: 0 =not used; 1 =close for 2 seconds.; 2 =stay closed; 3 =pulse on/off; 4 = toggle on and off alternately NOTE: For options 1 and 4, do not program a "Stop" parameter.
02 START EVENT NOT USED 0	An output may be activated by an Event/Zone List combination, and/or by a Zone Type/System Operation. For an Event/Zone List or Event Zone Number combination, enter the event code as follows: 0 =not used; 1 =alarm; 2 =fault; 3 =trouble NOTE: An Event is required for Zone List, Zone Number and Zone Types 17 and 18. If you are not using a Zone List or Zone Number to activate the relay, enter 0 . Press [*] to continue.
02 START: ZN LIST 00	A zone list is a set of zones that can be used to initiate the start or stop relay action. If a zone list is being used to start this relay action, enter the zone list number, 1-15 . If a zone list is not being used, enter 0 . Press [*] to continue.
02 START: ZONE # 000	A specific zone can be used instead of or in addition to an Event/Zone List or Zone Type/System Operation combination to start the relay action. Enter the 3-digit zone number. Press [*] to continue.
02 START: ZN TYPE NO RESPONSE 00	A Zone Type/System Operation can be used instead of or in addition to an Event/Zone List combination or a specific zone to start the relay action. If a Zone Type/System Operation is being used, enter the 2-digit code as listed in the table that follows. Press [*] to continue.

Output Programming Notes when using with a Burglary/Panic Zone Type:

1. When using a START EVENT OF FAULT on a ZONE # and no other start or stop entries, the Output assigned to the relay will follow the zone (tripped Relay on, restored Relay off) on FAULT/ALARM/TROUBLE, armed and disarmed.
2. When using a START EVENT OF FAULT on a ZONE # and a STOP ZONE/TYPE of 22, the Output assigned to the relay will START on FAULT/ALARM/TROUBLE, but will not Stop until code and off is entered.
3. When using a START EVENT OF ALARM on a ZONE # and no other start or stop entries, the Output assigned to the relay will follow the zone (on after an ALARM only) and off when zone restores.
4. When using a START EVENT OF ALARM on a ZONE # and a STOP ZONE/TYPE of 22, the Output assigned to the relay will START only on ALARM of the zone and will not Stop until code and off is entered.

NOTE: BYPASSING A ZONE WILL PREVENT IT FROM STARTING AN OUTPUT.

Choices for Start/Stop Zone Types and System Operations:

00 = No Response (Not Used)	22 = Disarming (Code + Off)	44 = RF Low Battery
01 = Entry/Exit #1	23 = No Alarm Response	45 = Polling Loop Failure
02 = Entry/exit #2	27 = Access Point (allows more than one relay to be controlled by activation if access point request)	47 = Console Failure
03 = Perimeter	29 = Momentary Exit (use w/Vistakey only)	51 = RF Receiver Failure
04 = Interior Follower	30 = On Second Code + Off	52 = KISSOFF
05 = Trouble Day/Alarm Night	31 = End of Exit Time	54 = Smoke Detector Reset
06 = 24-Hr. Silent	32 = Start of Entry Time	55 = Disarm + 1 Minute
07 = 24-Hr. Audible	33 = Any Burglary Alarm	56 = XX Minutes (enter XX in field 1*74) *
08 = 24-Hr. Auxiliary	34 = Code + [#] + 71 Key Entry	57 = YY Seconds (enter YY in field 1*75) *
09 = Fire Alarm or Trouble	35 = Code + [#] + 72 Key Entry	58 = Duress
10 = Interior W/Delay	36 = At Bell 1 Timeout **	60 = Audio Alarm Verification (must be selected for both START and STOP operation)
12 = Not Used	37 = 2x Bell 1 Timeout **	61 = Code + [#] + 67
13 = Remote P/S	38 = Chime	62 = Bell 2 Timeout
14 = CO Detector Alarm	39 = Fire Alarm	63 = Auxiliary Relay Timeout
16 = Fire With Verification	40 = Bypassing	
17 = Waterflow*****	41 = AC Power Fail	
18 = Fire Supervisory	42 = System Battery Low	
19 = 24-Hour Trouble	43 = Communication failure	
20 = Arming-STAY***		
21 = Arming-AWAY****		

- * Stop condition only
- ** Or at disarming, whichever occurs earlier
- *** The output also activates when the partition is armed in the INSTANT mode
- **** The output also activates when the partition is armed in the MAXIMUM mode
- ***** Use an event of fault or alarm as the START option



If you are using options 56 and/or 57 (usually as the STOP Zone Type), you must program data fields 1*74 and 1*75 for the respective relay timeouts for minutes and seconds.

PROMPT	EXPLANATION
02 START: ACS PT (00-15) 00	If the start zone type you selected was 27 (access point), this prompt is displayed. Enter the access point (00-15) that will start the relay action. Press [*] to continue.
02 START: PARTN ANY PARTITION 0	If the starting event will be limited to occurring on a specific partition, enter the partition number (1-8) in which the start event will occur. Enter 0 for any partition. Press [*] to continue.



Do not use a zone programmed with an RF Button (Input Type BR) to STOP a relay. The system will not deactivate the relay.

PROMPT	EXPLANATION
02 STOP: ZN LIST 00	If a zone list is being used to stop this relay action, enter the zone list number, 1-15 . The restore of a zone on the zone list stops the relay. If a zone list is not being used, enter 0 . Press [*] to continue.
02 STOP: ZN TYPE NO RESPONSE 00	If a Zone Type/System Operation is being used to stop the relay action, enter the 2-digit code listed in the Choices for Start/Stop System Operation chart. The restore of the Zone Type or System Operation stops the relay. NOTE: If a 4204CF is being used, the stop action for a NAC must be programmed as zone type 62, Bell 2 Timeout. Only one relay of the 4204CF may be used for this function. Press [*] to continue.
02 STOP: ACS PT (00-15) 00	If the stop zone type you selected was 27 (access point), this prompt is displayed. Enter the access point (00-15) which will stop the relay action. Press [*] to continue.
02 STOP: PARTN ANY PARTITION 0	This is the partition to which the stop condition will be limited. Enter 0 for any partition. Enter 1-8 for specific partition number. Press [*] to continue.
02 RELAY GROUP 00	Relays may be grouped for common activation by time-driven events (commands 06-10). Enter 00 (no group) or 01-15 for a specific group number. Press [*] to continue.
02 FIRE BELL 1=YES 0=NO 0	Enter 1 only if this output is to be used to activate a fire alarm sounder. Press [*] to continue.
02 RESTRICTION 1=YES 0=NO 0	The system may have some devices that are not intended to be under end user control, such as relays activating fire doors or machinery. NOTE: #70 must be set to yes for Commercial Fire installations. Enter 1 if the end user will be restricted from accessing this relay group. Press [*] to continue.
02 RELAY TYPE V-PLEX 0	Enter 0 for V-Plex (polling loop) devices. Enter 1 for (ECP) relay modules (4204/4204CF). Press [*] to continue.
02 V-PLEX ZONE # 000	For polling loop trigger outputs (4101SN), enter the protection zone number (009-250) linked to each output, if used. Be sure to enroll the module's serial number (see Zone Programming). Press [*] to continue.
02 ECP ADDRESS 00	If you selected 1 or 3 for (4204/4204CF), enter the actual module's address (01-32 – 4204/4204CF) as set by its DIP switches. Up to 8 4204/4204CF modules can be installed in a system. Press [*] to continue.
02 MODULE RELAY# 0	For 4204 Relay Outputs, enter the specific relay number on that module (1-4). For 4204CF outputs, enter only module relay number 1 (Output A) or relay number 3 (Output B) . These are the only two programmable relays on the 4204CF Module. Press [*] to continue. The keypad will display the Start and Stop summary screens again. Press [*] to continue.

When all relays have been programmed, enter **00** at the "ENTER RELAY NO." prompt.

If you are defining a zone list, continue to the next section. If not, enter **00** + [*] at the next two prompts. You will then be asked "Quit Menu Mode?" Enter **1** for "Yes," **0** for "No." Then enter ***99** to exit programming completely.

If supervision of the 4204CF Relay Output is desired, enter a response type for that output's corresponding supervisory zone. This is equal to 600 + [Relay ID No.]. For example, if you are programming Relay ID No. 1, the relay's supervisory zone is 601. Program this zone with response type 05 (Day/Night) in *Zone Programming*.

Zone List Programming

After all relays have been programmed, upon entering **00** at the "ENTER RELAY NO." prompt, you are asked to enter a zone list. If a zone list number was used to start or stop a relay, you must define the zones belonging to that list as follows:

PROMPT	EXPLANATION
ENTER Zn LIST ? 00=QUIT 00	Enter the zone list number 01-15 . Enter 00 to quit.
01 ADD ZONE # 000=QUIT 000	Using 3-digit entries enter each zone to be included in this zone list. Press [*] after you enter each zone number. When you have entered all zones, enter 000 . Press [*] to continue.
01 Del Zn LIST ? 1=YES 0=NO 0	Enter 0 to save this zone list. Enter 1 to delete it.
01 DEL ZONES ? 1=YES 0=NO 0	Enter 1 to delete one or more zones in that zone list. Enter 0 if no changes are necessary. If you enter 1 , the following screen appears; otherwise, the "Enter Zone LIST" prompt reappears.
01 Zn to DELETE ? 000=QUIT 000	Enter each zone number to be deleted from the zone list, pressing [*] after each number.
VIEW Zn LIST ? 00=QUIT 00	This display appears if you pressed 00 at the "Enter Zone LIST" prompt. Enter the zone list number that you wish to view. Press [*] to continue.
01 ASSIGNED ZONE 000=QUIT 000	Press [*] to scroll through all zones in that list. Enter 000 + [*] to quit. Press [1] to exit Menu Mode. Press *99 to exit Program Mode.

Relay Voice Descriptors

Each voice descriptor can consist of up to 3 words selected from the Relay Voice Descriptors and Custom Word Substitutes Vocabulary list (later in this section).



The index numbers from this vocabulary list are to be used for relay voice descriptors only. For normal system voice annunciation (e.g., alarms, troubles, status), use the highlighted words in the alpha vocabulary list in the *Alpha Programming* part of this guide.

To enter relay voice descriptors, do the following:

1. From Data Field Programming mode, press **#93** to display the "ZONE PROG?" prompt.
2. Press **[0]** (NO) to each menu option until the "RLY VOICE DESCR?" prompt is displayed. Follow the instructions below. While in this mode, press **[*]** to advance to next screen. Press **[#]** to back up to previous screen.

PROMPT	EXPLANATION
RLY VOICE DESCR? 1=YES 0=NO 0	Press [1] to program voice descriptors for relays.
ENTER RELAY NO. 00=QUIT 01	Enter the 2-digit relay number (01-32) for the relay desired, or enter 00 to quit Relay Voice Descriptor Programming Mode. Press [*]
01 ENTER DESC d1	From the Relay Voice Descriptors and Custom Word Substitutes Vocabulary list, enter the 3-digit index number for the first word of the relay descriptor phrase. Press [*] to accept entry.
01 ENTER DESC d2	From the Relay Voice Descriptors and Custom Word Substitutes Vocabulary list, enter the 3-digit index number for the second word of the relay descriptor phrase. If second word is not desired, press [000] . Press [*] to accept entry.
01 ENTER DESC d3	From the Relay Voice Descriptors and Custom Word Substitutes Vocabulary list, enter the 3-digit index number for the third word of the relay descriptor phrase. If third word is not desired, press [000] . Press [*] to accept entry. The "ENTER RELAY NO." prompt appears. Enter the next relay number to be programmed. When you have programmed all output devices, enter 00 to quit. Enter *99 to exit Program Mode.

Relay Voice Descriptors and Custom Word Substitutes Vocabulary

Word	Index	Word	Index	Word	Index	Word	Index	Word	Index
Air.....	116	Device.....	060	Gas.....	138	Off.....	011	Smoke.....	024
Alarm.....	255	Dim.....	163	Glass.....	139	Office.....	147	South.....	155
And.....	067	Dining.....	031	Hall.....	050	On.....	058	Stairs.....	006
Apartment.....	117	Door.....	016	Heat.....	010	One.....	070	Station.....	156
Appliances.....	161	Down.....	008	Inside.....	209	Open.....	148	Storage.....	157
Area.....	118	Downstairs.....	184	Kitchen.....	022	Outside.....	210	Sun.....	154
Attic.....	119	Driveway.....	130	Laundry.....	140	Panic.....	013	System.....	062
Back.....	121	Duct.....	131	Left.....	027	Partition.....	090	Temperature.....	158
Bar.....	122	East.....	132	Light.....	019	Patio.....	149	Third.....	159
Basement.....	021	Eight.....	077	Living.....	030	Phone.....	061	Three.....	072
Bathroom.....	051	Eighth.....	221	Loading.....	142	Power.....	063	Tool.....	213
Battery.....	053	Equipment.....	133	Lower.....	094	Pump.....	166	Two.....	071
Bedroom.....	015	Exit.....	004	Machine.....	143	Rear.....	088	Up.....	025
Blower.....	123	Factory.....	134	Master.....	144	Right.....	028	Upper.....	187
Boiler.....	124	Fence.....	135	Medical.....	014	Room.....	018	Upstairs.....	183
Bright.....	162	Fifth.....	218	Motion.....	145	's.....	007	Utility.....	185
Building.....	125	Fire.....	040	Nine.....	078	Second.....	056	West.....	215
Burglary.....	039	First.....	136	Ninth.....	222	Service.....	150	Window.....	017
Central.....	089	Five.....	074	No.....	165	Seven.....	076	Wing.....	216
Chime.....	054	Floor.....	029	North.....	146	Seventh.....	220	Zero.....	069
Closed.....	126	Four.....	073	Not.....	012	Shed.....	151	Zone.....	002
Computer.....	127	Fourth.....	217			Shop.....	152		
Console.....	066	Foyer.....	137			Side.....	153		
Den.....	052	Front.....	087			Six.....	075		
Detector.....	128	Garage.....	023			Sixth.....	219		

System Layout Worksheets

Before programming any security system, you should first define the installation. To help you lay out a partitioned system, use the following worksheets. This will further simplify the programming process.

NOTE: All references in this manual for number of zones, number of user codes, number of access cards, and the event log capacity, use the VISTA-250FBPT's features. See page 2 of this manual for the table listing the differences between the VISTA-128FBPT and the VISTA-250FBPT control panels. All other features are identical.

PARTITIONS

Partition #	Descriptor (4-char max)	Prim. Sub. #	Sec. Sub. #	Alpha Default Message (32-character maximum)
Partition 1				
Partition 2				
Partition 3				
Partition 4				
Partition 5				
Partition 6				
Partition 7				
Partition 8				
Keyswitch Arming Partition Assignment (1-8):				
Wireless Keypad Partition Assignment (1-8):				
Use Partition Descriptor (yes/no)?				
Common Lobby Partition Assignment (1-8):				

COMMUNICATION OPTIONS BY PARTITION

Option	Part. 1	Part. 2	Part. 3	Part. 4	Part. 5	Part. 6	Part. 7	Part. 8
Swinger Suppression Count 00-15; 00=no suppression								
Cancel Report After Disarm								
Dialer Reports for Panic (* + 1)								
Dialer Reports for Panic (# + 3)								
Dialer Reports for Panic (* + #)								
Dialer Reports for Duress								
Burglary Alarm Communications Delay (30 sec.)								

SYSTEM DEFINITIONS BY PARTITION (enter values or yes/no)

Option	Part. 1	Part. 2	Part. 3	Part. 4	Part. 5	Part. 6	Part. 7	Part. 8
Entry Delay #1 (00, 30-225 seconds):								
Exit Delay #1 (00, 45-225 seconds):								
Entry Delay #2 (00, 30-225 seconds):								
Exit Delay #2 (00, 45-225 seconds):								
Quick Arming								
Multiple Alarms per Arming								
Console Panic for Zone 995 (* + 1)								
Console Panic for Zone 996 (# + 3)								
Console Panic for Zone 999 (* + #)								
Allow Sign-on (GOTO function)								
Non-Bypassable Zone (001-250)								
Bell 1 Sounder Duration (2 min. increments)								
Bell 2 and Aux Relay Sounder Duration for (2 min. incr.)								
Console Annunciation During Entry								
Console Annunciation During Exit								
Bell 1 Confirmation of Arming Ding								
Bell 2 and Aux Relay 1 Confirmation of Arming Ding								
Chime on Bell 1								
Chime on Bell 2 and Aux Relay								
Access Control Relay (field 1*76)								
Affects Lobby (check partitions that apply)								
Arms Lobby (check partitions that apply)								
Display Fire Alarms of Other Partitions								
Display Burg and Panic Alarms of Other Partitions								
Display Troubles of Other Partitions								

ACCESS CODES and USER DEFINITIONS FOR PARTITIONS 3 and 4

4-digit Security Code	Access Group 0; 1-8	Partition 3						Partition 4					
		3-Digit User #	Auth. Level	Open/Close	Group Bypass	RF Key	Global Arm	3-Digit User #	Auth. Level	Open/Close	Group Bypass	RF Key	Global Arm

ACCESS CODES and USER DEFINITIONS FOR PARTITIONS 5 and 6

4-digit Security Code	Access Group 0; 1-8	Partition 5						Partition 6					
		3-Digit User #	Auth. Level	Open/Close	Group Bypass	RF Key	Global Arm	3-Digit User #	Auth. Level	Open/Close	Group Bypass	RF Key	Global Arm

ACCESS CODES and USER DEFINITIONS FOR PARTITIONS 7 and 8

4-digit Security Code	Access Group 0; 1-8	Partition 7						Partition 8					
		3-Digit User #	Auth. Level	Open/Close	Group Bypass	RF Key	Global Arm	3-Digit User #	Auth. Level	Open/Close	Group Bypass	RF Key	Global Arm

Authority Levels: 1=Master (arm, disarm, bypass, and/or modify lower level users)
 2=Manager (arm, disarm, bypass, and/or modify lower level users)
 3=Operator A (arm, disarm, bypass)
 4=Operator B (arm, disarm)
 5=Operator C (arm, disarm only if system was armed with this code)
 6=Duress code (arm, disarm, triggers silent panic alarm)

Defaults:

User	4-Digits	Alpha
User 1 (Installer)	5140	INSTLR
User 2	1234	MASTER

ZONE DEFINITION FOR ZONES 001-025

Zone No.	Zone Type	Part 1-8	Input Type	Arm w/Fault	Vent Zone	STAY Mode	Auto-STAY	Silent	Bypass Group	Access Point	Tamper	Serial #/ Loop	Rpt. Code	Smart Zone	Anti Mask	Zone Info (part nos.) & Alpha Descriptor (3 words max.)
1																
2																
3																
4																
5																
6																
7																
8																
9																
10																
11																
12																
13																
14																
15																
16																
17																
18																
19																
20																
21																
22																
23																
24																
25																

ZONE DEFINITION FOR ZONES 026-050

Zone No.	Zone Type	Part 1-8	Input Type	Arm w/Fault	Vent Zone	STAY Mode	Auto-STAY	Silent	Bypass Group	Access Point	Tamper	Serial # / Loop	Rpt. Code	Smart Zone	Anti Mask	Zone Info (part nos.) & Alpha Descriptor (3 words max.)
26																
27																
28																
29																
30																
31																
32																
33																
34																
35																
36																
37																
38																
39																
40																
41																
42																
43																
44																
45																
46																
47																
48																
49																
50																

ZONE DEFINITION FOR ZONES 051-075

Zone No.	Zone Type	Part 1-8	Input Type	Arm w/Fault	Vent Zone	STAY Mode	Auto-STAY	Silent	Bypass Group	Access Point	Tamper	Serial # / Loop	Rpt. Code	Smart Zone	Anti Mask	Zone Info (part nos.) & Alpha Descriptor (3 words max.)
51																
52																
53																
54																
55																
56																
57																
58																
59																
60																
61																
62																
63																
64																
65																
66																
67																
68																
69																
70																
71																
72																
73																
74																
75																

ZONE DEFINITION FOR ZONES 076-100

Zone No.	Zone Type	Part 1-8	Input Type	Arm w/Fault	Vent Zone	STAY Mode	Auto-STAY	Silent	Bypass Group	Access Point	Tamper	Serial # / Loop	Rpt. Code	Smart Zone	Anti Mask	Zone Info (part nos.) & Alpha Descriptor (3 words max.)
76																
77																
78																
79																
80																
81																
82																
83																
84																
85																
86																
87																
88																
89																
90																
91																
92																
93																
94																
95																
96																
97																
98																
99																
100																

ZONE DEFINITION FOR ZONES 101-125

Zone No.	Zone Type	Part 1-8	Input Type	Arm w/Fault	Vent Zone	STAY Mode	Auto-STAY	Silent	Bypass Group	Access Point	Tamper	Serial # / Loop	Rpt. Code	Smart Zone	Anti Mask	Zone Info (part nos.) & Alpha Descriptor (3 words max.)
101																
102																
103																
104																
105																
106																
107																
108																
109																
110																
111																
112																
113																
114																
115																
116																
117																
118																
119																
120																
121																
122																
123																
124																
125																

ZONE DEFINITION FOR ZONES 126-150

Zone No.	Zone Type	Part 1-8	Input Type	Arm w/Fault	Vent Zone	STAY Mode	Auto-STAY	Silent	Bypass Group	Access Point	Tamper	Serial # / Loop	Rpt. Code	Smart Zone	Anti Mask	Zone Info (part nos.) & Alpha Descriptor (3 words max.)
126																
127																
128																
129																
130																
131																
132																
133																
134																
135																
136																
137																
138																
139																
140																
141																
142																
143																
144																
145																
146																
147																
148																
149																
150																

ZONE DEFINITION FOR ZONES 151-175

Zone No.	Zone Type	Part 1-8	Input Type	Arm w/Fault	Vent Zone	STAY Mode	Auto-STAY	Silent	Bypass Group	Access Point	Tamper	Serial # / Loop	Rpt. Code	Smart Zone	Anti Mask	Zone Info (part nos.) & Alpha Descriptor (3 words max.)
151																
152																
153																
154																
155																
156																
157																
158																
159																
160																
161																
162																
163																
164																
165																
166																
167																
168																
169																
170																
171																
172																
173																
174																
175																

ZONE DEFINITION FOR ZONES 176-200

Zone No.	Zone Type	Part 1-8	Input Type	Arm w/Fault	Vent Zone	STAY Mode	Auto-STAY	Silent	Bypass Group	Access Point	Tamper	Serial # / Loop	Rpt. Code	Smart Zone	Anti Mask	Zone Info (part nos.) & Alpha Descriptor (3 words max.)
176																
177																
178																
179																
180																
181																
182																
183																
184																
185																
186																
187																
188																
189																
190																
191																
192																
193																
194																
195																
196																
197																
198																
199																
200																

ZONE DEFINITION FOR ZONES 201-225

Zone No.	Zone Type	Part 1-8	Input Type	Arm w/Fault	Vent Zone	STAY Mode	Auto-STAY	Silent	Bypass Group	Access Point	Tamper	Serial # / Loop	Rpt. Code	Smart Zone	Anti Mask	Zone Info (part nos.) & Alpha Descriptor (3 words max.)
201																
202																
203																
204																
205																
206																
207																
208																
209																
210																
211																
212																
213																
214																
215																
216																
217																
218																
219																
220																
221																
222																
223																
224																
225																

ZONE DEFINITION FOR ZONES 226-250

Zone No.	Zone Type	Part 1-8	Input Type	Arm w/Fault	Vent Zone	STAY Mode	Auto-STAY	Silent	Bypass Group	Access Point	Tamper	Serial # / Loop	Rpt. Code	Smart Zone	Anti Mask	Zone Info (part nos.) & Alpha Descriptor (3 words max.)
226																
227																
228																
229																
230																
231																
232																
233																
234																
235																
236																
237																
238																
239																
240																
241																
242																
243																
244																
245																
246																
247																
248																
249																
250																

ZONE DEFINITIONS FOR KEYPAD PANIC ZONES 995, 996, and 999

Zone No.	Zone Type	Enter yes/no for each partition-field *22								Bell/Relay Activation	Report Code	Zone Information and Alpha Descriptor (3 words max.)
		1	2	3	4	5	6	7	8			
995 (see note below)												
996												
999												

NOTE: Do Not Use Zone No. 995 in a Fire Alarm application.

ZONE DEFINITIONS FOR SYSTEM ZONES; 970 – 975, 988; 990 and 997

Zone No.	Zone Type	Bell/Relay Activation	Report Code	Zone Information and Alpha Descriptor (three words max.)
970				
971				
972				
973				
974				
975				
988				
990				
997				

ZONE DEFINITIONS FOR RELAY SUPERVISORY ZONES 601-632

Zone No.	Zone Type	Report Code	Zone Information and Alpha Descriptor (3 words max.)	Zone No.	Zone Type	Report Code	Zone Information and Alpha Descriptor (3 words max.)
601				617			
602				618			
603				619			
604				620			
605				621			
606				622			
607				623			
608				624			
609				625			
610				626			
611				627			
612				628			
613				629			
614				630			
615				631			
616				632			

NOTE: Only the relays on 4204CF modules may be supervised. If supervision is programmed for other types of Output Devices, unpredictable results may occur.

ZONE DEFINITIONS FOR SUPERVISORY OF ECP DEVICE ZONES 800-830

Zone No.	Zone Type	Report Code	Zone Information and Alpha Descriptor (3 words max.)	Zone No.	Zone Type	Report Code	Zone Information and Alpha Descriptor (3 words max.)
800				816			
801				817			
802				818			
803				819			
804				820			
805				821			
806				822			
807				823			
808				824			
809				825			
810				826			
811				827			
812				828			
813				829			
814				830			
815							

Zone Types			
00=zone not used	07=24-hour audible	16=fire w/verification	23=no alarm response
01=entry/exit 1	08=24-hour auxiliary	17=waterflow	27=access control
02=entry/exit 2	09=supervised fire	18=supervisory	29=momentary on exit
03=perimeter	10=interior (delay)	19=24-hour trouble	
04=interior (follower)	12=Not Used	20=arm stay	
05=day/night burglary	13=Remote P/S	21=arm away	
06=24-hour silent	14=CO Detector alarm	22=disarm	

Input Types		Bells/Auxiliary Relay Activation	
00=not used	07=Dip switch-type polling loop	0=none	4=auxiliary relay
01=hardwired	08=right loop dip switch poll loop	1=bell 1	5=bell 1 and auxiliary relay
02=RF motion transmitter	09=keypad input	2=bell2	6=bell 2 and auxiliary relay
03=supervised RF transmitter	10=Not Used	3=bells 1 and 2	7=bells 1 and 2 and auxiliary relay
04=unsupervised RF transmitter	11=VistaKey door status monitor		
05=RF button transmitter	12=VistaKey request to exit		
06=serial number polling loop	13=VistaKey general purpose		

Output Devices Worksheets

Applicable only if relays (4204/4204CF) or V-Plex are used.

Output Devices – Programmed in the #93 Menu Mode in the Output Programming Section. Fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.

- NOTES:**
1. For 4204/4204CF, the Device Programming section must be programmed for the device address. Set the DIP switches on the device for that address.
 2. For V-Plex, devices must be programmed in the Zone Programming section
 3. If you are using outputs on V-Plex (e.g., 4101SN) no more than 20 of the V-Plex outputs may be programmed for the same START or STOP condition. Also, if you are using ZONE # for the START of a V-Plex output and want that output to stop when the same zone restores, the STOP programming **MUST BE BLANK**.

OUTPUT DEV #	A	S T A R T				S T O P			Relay Group	Restrict	0=V-Plex 1=4204/ 4204CF	V-Plex Zone # or Dev Add 4204/4204CF	Relay # for 4204/ 4204CF
		EV/ZL	Zone	ZT / P		ZL	ZT / P						
1													
2													
3													
4													
5													
6													
7													
8													
9													
10													
11													
12													
13													
14													
15													
16													
17													
18													
19													
20													

OUTPUT DEVICES WORKSHEET (cont'd)

OUTPUT DEV #	A	S T A R T			S T O P			Relay Group	Restrict	0=V-Plex 1=4204/ 4204CF	V-Plex Zone # or Dev Add 4204/4204CF	Relay # for 4204/ 4204CF
		EV/ZL	Zone	ZT / P	ZL	ZT / P						
21												
22												
23												
24												
25												
26												
27												
28												
29												
30												
31												
32												
33												
34												
35												
36												
37												
38												
39												
40												
41												
42												
43												
44												
45												

OUTPUT DEVICES WORKSHEET (cont'd)

OUTPUT DEV #	A	S T A R T			S T O P			Relay Group	Restrict	0=V-Plex 1=4204/ 4204CF	V-Plex Zone # or Dev Add 4204/4204CF	Relay # for 4204/ 4204CF
		EV/ZL	Zone	ZT / P	ZL	ZT / P						
46												
47												
48												
49												
50												
51												
52												
53												
54												
55												
56												
57												
58												
59												
60												
61												
62												
63												
64												
65												
66												
67												
68												
69												
70												

OUTPUT DEVICES WORKSHEET (cont'd)

OUTPUT DEV #	A	S T A R T			S T O P			Relay Group	Restrict	0=V-Plex 1=4204/ 4204CF	V-Plex Zone # or Dev Add 4204/4204CF	Relay # for 4204/ 4204CF
		EV/ZL	Zone	ZT / P	ZL	ZT / P						
71												
72												
73												
74												
75												
76												
77												
78												
79												
80												
81												
82												
83												
84												
85												
86												
87												
88												
89												
90												
91												
92												
93												
94												
95												
96												

A = DEVICE ACTION

0 = No Response; 1 = Close for 2 sec; 2 = Close and stay closed; 3 = Pulse on and off; 4 = Toggle alternately between START and STOP events

EV = EVENT

0 = Not used; 1 = Alarm; 2 = Fault; 3 = Trouble; 4 = Restore

ZL = ZONE LIST

01-15, 00 = Not Used

"START" ZONE LIST: Upon alarm, fault, trouble or restore of ANY zone in this list, device action will START.

"STOP" ZONE LIST: Upon restore of ALL zones on this list, device action will STOP. It need not be same list as used for START.

ZT = ZONE TYPE/SYSTEM OPERATION

Choices for Zone Type/System Operation are:

00 = No Response (Not Used)	21 = Arming-AWAY****	42 = System Battery Low
01 = Entry/Exit #1	22 = Disarming (Code + Off)	43 = Communication failure
02 = Entry/exit #2	23 = No Alarm Response	44 = RF Low Battery
03 = Perimeter	27 = Access Point (allows more than one relay to be controlled by activation if access point request)	45 = Polling Loop Failure
04 = Interior Follower	29 = Momentary Exit	47 = Console Failure
05 = Trouble Day/Alarm Night	30 = On Second Code + Off	51 = RF Receiver Failure
06 = 24-Hr. Silent	31 = End of Exit Time	52 = Kissoff
07 = 24-Hr. Audible	32 = Start of Entry Time	54 = Fire Zone Reset
08 = 24-Hr. Auxiliary	33 = Any Burglary Alarm	55 = Disarm + 1 Minute
09 = Fire Alarm or Trouble	34 = Code + [#] + 71	56 = XX Minutes (enter XX in field 1*74) *
10 = Interior W/Delay	35 = Code + [#] + 72	57 = YY Seconds (enter YY in field 1*75) *
12 = Not Used	36 = At Bell Timeout **	58 = Duress
13 = Remote P/S	37 = 2 Times Bell Timeout **	60 = Audio Alarm Verification (must be selected for both START and STOP operation)
14 = CO Detector Alarm	38 = Chime	61 = Code + [#] + 67
16 = Fire With Verification	39 = Fire Alarm	62 = Bell 2 Timeout
17 = Waterflow*****	40 = Bypassing	63 = Auxiliary Relay Timeout
18 = Fire Supervisory	41 = AC Power Fail	
19 = 24-Hour Trouble		
20 = Arming-STAY***		

* Stop condition only

** Or at disarming, whichever occurs earlier

*** The output also activates when the partition is armed in the INSTANT mode

**** The output also activates when the partition is armed in the MAXIMUM mode

***** Use an event of fault or alarm as the START option

P = PARTITION No. 1-8, 0 = Any

ZONE LISTS FOR OUTPUT DEVICES – Programmed in the #93 Menu Mode in the Output Programming Section. Fill in the required data on the worksheet below and follow the procedure shown earlier in this *Programming Guide* as you enter the data during the displays and prompts that appear in sequence. Up to 15 zone lists may be created

NOTE:Record desired zone numbers below. More or fewer boxes than shown may be needed, as any list may include *any* or *all* of system's zone numbers.

Zone List 1: Started or stopped by zone numbers (enter 000 to end entries).

<input type="text"/>						
----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------

<input type="text"/>						
----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------

Zone List 2: Started or stopped by zone numbers (enter 000 to end entries).

<input type="text"/>						
----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------

<input type="text"/>						
----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------

Zone List 3: Started or stopped by zone numbers (enter 000 to end entries).

<input type="text"/>						
----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------

<input type="text"/>						
----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------

Zone List 4: Started or stopped by zone numbers (enter 000 to end entries).

<input type="text"/>						
----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------

<input type="text"/>						
----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------

Zone List 5: Started or stopped by zone numbers (enter 000 to end entries).

Zone List 6: Started or stopped by zone numbers (enter 000 to end entries).

Zone List 7: Started or stopped by zone numbers (enter 000 to end entries).

Zone List 8: Started or stopped by zone numbers (enter 000 to end entries).

Zone List 9: Started or stopped by zone numbers (enter 000 to end entries).

Zone List 10: Started or stopped by zone numbers (enter 000 to end entries).

Zone List 11: Started or stopped by zone numbers (enter 000 to end entries).

Zone List 12: Started or stopped by zone numbers (enter 000 to end entries).

Zone List 13: Started or stopped by zone numbers (enter 000 to end entries).

Zone List 14: Started or stopped by zone numbers (enter 000 to end entries).

Zone List 15: Started or stopped by zone numbers (enter 000 to end entries).

Scheduling

ULC Scheduling is currently not approved for ULC applications.

- UL**
- You must program Bypass and Auto-Arm Fail reports for UL installations.
 - Auto-disarming is not permitted in UL installations.
 - You must not program Random Scheduling of Time Driven Events for UL installations.
-

General

The scheduling features allow certain operations to be automated, such as arming, disarming, bypassing of zones, and activating relay outputs.

The system uses time windows (a programmed period of time with a start and stop time) for defining open/close schedules, holiday schedules, user-defined temporary schedules, and access schedules for users.

Scheduled events are programmed by user-friendly menu modes of programming (#80, #81, #83, and #93 modes), explained in detail in this section. These menus take you step by step through the options.

Auto Arming

ULC Auto Arming is not a ULC Listed feature.

The system can automatically arm (AWAY Mode) a partition at the end of a pre-determined closing (arming) time window. Auto Arming can be delayed three ways: by use of the Auto-Arm Delay, the Auto-Arm Warning, or by manually extending the closing (arming) time window with a keypad command.

The system can also automatically bypass any open zones when auto arming.

Auto-Arm Delay

Auto-Arm Delay provides a delay (grace period) before auto arming. It starts at the end of the closing time window.

The delay is set in 4-minute increments, up to 56 minutes in partition-specific program field 2*05. At the expiration of this delay, the Auto-Arm Warning will start.

Auto-Arm Warning

The Auto-Arm Warning causes the keypad sounder to warn the user of an impending Auto-Arm.

The warning can be set from 1 to 15 minutes prior to the arming in partition-specific program field 2*06. During this period the keypad beeps every 15 seconds and displays "AUTO ARM ALERT." During the last 60 seconds, the keypads beep every 5 seconds.

The panel arms at the conclusion of the Auto-Arm Warning period.

Extend Closing Window

A user can manually delay the arm (closing) time window by 1 or 2 hours. This is done by entering a keypad command (User Code + #82), which then prompts the user to enter the desired extension time of 1 or 2.

This feature is useful if a user must stay on the premises later than usual.

The Auto-Arm delay and warning periods begin at the end of the extension.

Force Arm

The Force Arm option causes the panel to attempt to bypass any faulted zones prior to auto arming (panel performs a force-arm).

ULC Force Arming is not a ULC Listed feature and must be disabled for ULC installations.

This option is set in partition-specific program field 2*08.

Auto Disarming

The system can automatically disarm a partition at the end of a pre-determined opening (disarm) time window.

The disarming time can be delayed by using the Auto-Disarm Delay feature.

Disarm Delay

Auto-Disarm Delay provides a delay before auto disarming. This delay is added to the end of the disarm time window.

The delay is set in 4-minute increments, up to 56 minutes, in partition-specific program field 2*07.

Restrict Disarming

This option allows disarming by users only during the disarm time window and during the arming time window (in case user needs to re-enter premises after manually arming the partition).

This option is set in partition-specific field 2*10. If field 2*10 is set, we highly recommend setting field 2*11, as well. This field allows the partition to be disarmed outside the arm/disarm time windows only if the partition is in alarm.

Exception Reports

This option allows the reporting of openings and closings to the central station only if the arming and disarming occurs outside of the predetermined opening and closing time windows. It is set in partition-specific field 2*09. The system can be programmed to send Failed to Open and Failed to Close reports if the partition is not armed or disarmed by the end of the corresponding time window.

Limitation of Access of Users by Time

A user’s access to the system can be limited to a certain time period. Outside this time, that user’s code is inactive. The system provides up to eight access schedules, each consisting of two time windows (typically one for opening, one for closing) for each day of the week and two time windows for holidays. The access schedules are programmed in the #80 Menu Mode, and enabled when a user’s access code is added to the system. If a user tries to operate the system outside the schedule, the alpha keypad displays “Access Denied.”

Time-Driven Events

The system can automatically activate and de-activate relays at predetermined times to turn lights or other devices on and off. The Time-Driven events can be activated at different times in relation to a time window:

- At the beginning of a time window
- At the end of a time window
- During a time window (on at beginning of window, off at end)
- At both the beginning and end of the time window (e.g., to sound a buzzer at the beginning and end of a coffee break)
- Random time at the start of the time window (occurs within 30 minutes after the start of the time window)
- Random time at the end of the time window (occurs within 30 minutes after the end of the time window)
- Random during the time window (begins within 30 minutes after the start of the time window and ends within 30 minutes after the end of the time window)

The system can perform the same actions on a daily basis, or can perform an action only once (e.g., turn on the porch light this Wednesday at 8:00 PM).

The system also provides up to 20 programmable “timers” available to the end user for the purpose of activating output devices at preset times and days.

Time Window Definitions

Scheduled events are based on time windows, (periods of time) during which an event may take place. The system supports up to 20 time windows, each defined by a “Start” time and a “Stop” time.

The windows are shared by all 8 partitions, and are used when programming the various schedules (open/close, limitation of access), as well as for Time-Driven event control.

Scheduling Example

A store that has the following hours:

Monday to Friday	9am to 6pm
Saturday	10am to 4pm
Sunday	Closed
Holidays	Closed

The owner desires the following time windows to allow time for employees to arm or disarm the system:

Monday to Friday	Open (disarm)	8am to 9am
	Close (arm)	6pm to 6:30pm
Saturday	Open (disarm)	9am to 10am
	Close (arm)	4pm to 4:30pm
Sunday & Holidays	Closed	

For this schedule, the four time windows need to be programmed:

Window	Start	Stop	Purpose
1	8am	9am	Monday-Friday open window
2	9am	10am	Saturday open window
3	4pm	4:30pm	Saturday close window
4	6pm	6:30pm	Monday-Fri. close window

Using the #80 Menu Mode, the installer can program open/close schedules by assigning a time window to a day of the week (windows are entered as 2-digit entries)

Mon	Tue	Wed	Thu	Fri	Sat	Sun	Hol
Op/Cl							
01/04	01/04	01/04	01/04	01/05	02/03	00/00	00/00

NOTE: 00 is entered for those days on which the store is closed.

Employees can arm and disarm the system, when programmed, within the open and close time windows without causing a report to be sent to the central station (reporting by exception, field 2*09). The system can be programmed to automatically arm/disarm in case an employee fails to arm/disarm manually (auto-arm/auto-disarm).

Open/Close Schedules Definitions

General

The open/close scheduling is controlled by one of three schedules. Each schedule consists of one time window for openings and one time window for closings.

There are three types of schedules available: Daily, Holiday, and Temporary.

Daily Schedule

Each partition can have one daily schedule consisting of one opening window and one closing window per day.

Holiday Schedule

A holiday schedule overrides the regular daily schedule on selected holidays throughout the year.

The opening and closing windows are programmed in the daily schedule, but the holidays themselves are defined in *Holiday Schedule Programming* in the #80 Menu Mode.

Temporary Schedule

The temporary schedule provides a method for the end user to override the daily and holiday schedules. It consists of one opening window and one closing window for each day of the week. The schedule takes effect for up to one week, after which it is automatically deactivated.

This schedule is programmed using the #81 Temporary Schedule Menu Mode.

Additional Schedules

Additional opening and closing schedules can be programmed using the *Time-Driven Event Programming*. For example, a schedule for normal store openings/closings can be programmed with a daily open/close schedule, and another open/close schedule for a lunch hour can be programmed using the Time-Driven event schedule programming.

Refer to "Time-Driven Events" later in this section for detailed information.

Open/Close Reports by Exception

The system can help reduce communication traffic to the central station by using the Open/Close Reports by Exception feature. The Open/Close by Exception option suppresses these reports from being sent to the central station if an arm or disarm is done *within* the expected time window. Reports are only sent if the arm or disarm occurs outside the assigned time window.

The system keeps a record of *all* openings/closings in its event log.

If a disarming occurs during a closing window (for example, a person who arms the system forgets something and has to re-enter), the Opening report (although outside of the opening window) will not be sent (as long as that disarming occurs within the closing window).

This option is programmed in partition-specific program field 2*09.

Example of Open/Close Exception Reporting & Scheduling

The following chart gives an example of how the Open/Close by Exception reporting works.

6:01PM	5:59AM	6AM	9AM	9:01AM	3:59PM	4PM	6PM	6:01PM	5:59AM
<p>Early Opening reports are sent if system is manually disarmed before opening window begins.</p> <p>Early and Late Opening and Closing reports are programmable options in Report Code Programming in the Programming Guide. They are not dependent on the programming of the Exception Reporting option.</p>		<p style="text-align: center;">Opening Window</p> <p>No reports are sent if system is disarmed during this time window.</p> <p>If an arming occurs, a Closing report is sent to the central station regardless of how the Exception Reporting option is set.</p>		<p>Auto-disarm delay begins.</p> <p>Auto-disarm occurs after delay (if auto-disarm is enabled).</p> <p>Missed Opening reports are sent if manual disarming has not occurred at expiration of opening window.</p> <p>Late Opening reports are sent if disarm occurs after the opening window expires.</p> <p>Early Closing reports are sent if manual arming occurs before the closing window begins. Missed Opening/Closing type reports are programmed in Report Code Programming in the Programming Guide. The Exception Reporting option must be set for these to be sent.</p>		<p style="text-align: center;">Closing Window</p> <p>No reports are sent if system is armed* during this time window.</p> <p>* or disarmed if user needs to re-enter premises.</p>		<p>Auto-arm delay begins.</p> <p>Auto-arm warning begins.</p> <p>Auto-arm occurs after warning expires (if auto-arm is enabled).</p> <p>Missed Closing reports are sent if manual arming has not occurred at expiration of closing window.</p> <p>Late Closing reports are sent if system is manually armed after the closing window expires.</p>	

Scheduling Menu Mode

The #80 Scheduling Menu Mode is used to program most of the scheduling and timed-event options. Enter **Installer Code + [#] + [8] + [0]** from the normal operating mode. **NOTE:** Only users with an Installer or Master level user code may enter the #80 mode.

The following can be programmed while in this mode:

- time windows
- open/close schedules to each partition
- holiday schedules
- Time-Driven events (for system functions and relay activation)
- limitation of access schedules

Some scheduling features are programmed in Data Field Programming Mode (**Installer Code + 8 0 0 0**). Some features are programmed in the #93 Menu Mode. The programming scheduling fields are listed below.

System-Wide Fields:	
*04	Enable Random Timers
1*74 –1*75	Relay timeout values
2*01-2*02	Daylight saving time options
2*11	Allow disarming outside window if alarm occurs
Partition-Specific fields:	
1*76	Access control relay for this partition
2*05	Auto-arm delay value
2*06	Auto-arm warning time
2*07	Auto-disarm delay value
2*08	Force-arm enable
2*09	Open/Close Reporting by Exception
2*10	Restrict disarm only during windows
#93 Menu Mode (System Group #3)	
Scheduling related report codes	

Event-driven options are programmed using *Output Programming* in #93 Menu Mode. Relay activation can also be Time-Driven and that those are programmed using the #80 Menu Mode. Refer to the *Time-Driven Event Programming* later in this section for the procedure.

Steps to Program Scheduling Options



This section contains examples of the worksheets only. For complete worksheets, see the *Programming Guide* accompanying this Installation and Setup Guide.

In order to use #80 Scheduling Menu Mode, use the worksheets to do the following:

1. Define time windows (up to 20)
2. Define the daily open/close schedules (one schedule per day, per partition)
3. Define the holidays to be used by the system (up to 16)
4. Define limitation of access times (up to eight schedules)
5. Define the Time-Driven events (up to 20)

NOTE: Temporary schedules are programmed using #81 Menu Mode.

Use #80 Scheduling Menu Mode to perform the following functions:

6. Program the time windows
7. Program the open/close schedules
8. Program the Time-Driven events
9. Program the access schedules

Scheduling Menu Structure

To program schedules, enter Scheduling Program Mode:

Installer Code + [#] + [80]. (Installer or Master level user code.)



Scheduling Program Mode can be entered only when all partitions are disarmed.

Scheduling Menu Prompts

To program schedules, enter Scheduling program mode by pressing **[User Code] + # + 80** to display the first choice of the menu driven programming functions. **NOTE:** Only users with an Installer or Master level user code may enter the #80 mode. Press **0** (NO) or **1** (YES) in response to the displayed menu selection. Pressing **0** will display the next choice in sequence. Menu selections are as follows:

PROMPT	EXPLANATION
Time Window ? 1 = YES 0 = NO 0	For defining up to 20 time windows each with a start and a stop time programmed by entering the hours and minutes.
O/C Schedules ? 1 = YES 0 = NO 0	For defining the daily open and close schedules for the 8 partitions. Each partition can be programmed with an opening and closing window for each day of the week and holidays.
Holidays ? 1 = YES 0 = NO 0	For defining up to 16 holidays for which partitions they apply.
Timed Events ? 1 = YES 0 = NO 0	For defining up to 20 time driven events with the following parameters: <ul style="list-style-type: none"> • Time window • Action desired • Action specifier • Activation time • Days of the week
Access Sched. ? 1 = YES 0 = NO 0	For defining the limitation of access schedules for the user codes. Each schedule can be programmed with two window for each day of the week and holidays
Quit ? 1 = YES 0 = NO 0	Enter 1 to quit #80 Scheduling Menu Mode and return to normal operating mode. Enter 0 to make any changes or review the scheduling programming options. If you press 0 , the "Time Window?" prompt is displayed.

Time Windows

The system provides 20 time windows that are defined with start and stop times. These windows are used for various open/close and access schedules, as well as for output controls, and are the basis of the scheduling system. These windows are shared among all 8 partitions.

Time Windows Worksheet

The following worksheet is an example of the worksheet found in the *Programming Guide*. This worksheet will help you define time windows and scheduling aspects of this system before you program them. Note that time windows **can** span midnight; for example, from 11 PM to 1 AM.

Time Window Number	Start Time (HH:MM)	Stop Time (HH:MM)
1		
2		
3.....20		

A time window must have a start and a stop time.

Time Windows Programming

Enter Scheduling Mode by entering **Installer Code + [#] + [80]**. The keypad displays the *Time Window Programming* prompt.

PROMPT	EXPLANATION
Time Window ? 1 = YES 0 = NO 0	Enter 1 at this main menu prompt to program time windows.
Time Window # ? 01-20, 00 = Quit 01	Enter the 2-digit time window number (01-20) to be programmed. Press [*] to accept the entry. Enter 00 + [*] at the "Time Window #?" prompt to quit time window programming and display the "Quit ?" prompt.

PROMPT	EXPLANATION
01 TIME WINDOW 00:00AM 00:00AM	If you entered a time window number, the cursor is now positioned on the tens of hours digit of the start of window entry. Enter the desired start of window hour and press [*]. The cursor moves to the minutes position. Enter the desired minutes and press [*]. Toggle the AM/PM indication by pressing any key 0-9 while the cursor is under the A/P position and then press [*]. Repeat this to program the stop of window entry. When the entry is completed, the "Time Window #?" prompt is displayed again. Enter the next time window number to be programmed and repeat the procedure.
Quit ? 1 = YES 0 = NO 0	Enter 0 at the Quit ? prompt to return to the main menu choices and continue programming. Enter 1 to quit Scheduling Menu Mode.



Because the time windows are shared among all partitions, it is important to make sure that changing a time window does not adversely affect desired actions in other partitions.

Daily Open/Close Schedules

Each partition can be assigned one daily open/close schedule, plus a holiday schedule. Temporary schedules are programmed separately, using the #81 *Temporary Schedule Menu Mode*. To program additional open/close schedules, see *Time-Driven Events Programming* later in this section for the procedure.

Open/Close Schedule Worksheet

The following worksheet is an example of the worksheet found in the *Programming Guide*. Write the previously defined time window numbers for open and close for each partition.

Part	Mon		Tues		Wed		Thur		Fri		Sat		Sun		Hol	
	Op	Cl	Op	Cl	Op	Cl	Op	Cl	Op	Cl	Op	Cl	Op	Cl	Op	Cl
1																
2																
3...8																

Open/Close Schedule Programming

After entering Scheduling Menu Mode, press [0] until the "O/C Schedules?" prompt appears.

PROMPT	EXPLANATION
O/C Schedules ? 1 = YES 0 = NO 0	Enter 1 to program opening and closing schedules.
Partition # ? 01-08, 00 = Quit 01	Enter the appropriate partition number for which the following open/close schedules will apply. Enter 00 + [*] at the "Partition #?" prompt to quit open/close schedules programming and display the "Quit ?" prompt.
Mon P1 OP WIND.? 00:00 00:00 00	Enter the time window number 01-20 for the displayed day's opening schedule beginning with Monday. Enter 00 if no schedule is desired for a particular day. As the number is keyed in, the actual time that has been stored for that window number is displayed as a programming aid. Press [*] to accept the entry.
Mon P1 CL WIND.? 00:00 00:00 00	Enter the time window number for the displayed day's closing schedule. As the number is keyed in, the actual time that has been stored for the window number is displayed. Press the [*] key to accept the entry.
Tue P1 OP WIND.? 00:00 00:00 00	The keypad now prompts for Tuesday's open/close schedule. Follow the procedure for Monday's prompts. When the last day of the week has been programmed, the holiday opening and closing window prompts are displayed.
Hol P1 OP WIND.? 00:00 00:00 00	Repeat the procedure for the holiday opening and closing time windows. Press the [*] key to accept the entry. When the entries are completed, the "Partition #?" prompt is displayed again. Repeat this procedure for each partition in the system.
Quit ? 1 = YES 0 = NO 0	Enter 0 at the "Quit ?" prompt to return to the main menu choices and continue programming. Enter 1 to quit Scheduling Menu Mode.

Holiday Schedules

A holiday schedule overrides the regular daily open/close schedule on the programmed holidays throughout the year.

The system provides up to 16 holidays that can be assigned for the system. Each holiday can be assigned to any combination of partitions. List the desired holidays in a Month/Day format on the worksheet. Check the partitions for which these holidays apply.

Holiday Schedule Worksheet

The following worksheet is an example of the worksheet found in the *Programming Guide*.

HOL	Partition								
	Month/Day	1	2	3	4	5	6	7	8
1	/								
2	/								
3...16									

Holiday Schedule Programming

After entering Scheduling Menu Mode, press **[0]** until the "Holidays ?" prompt appears.

PROMPT	EXPLANATION
Holidays ? 1 = YES 0 = NO 0	Enter 1 to program holiday schedules.
HOLIDAY NUMBER ? 01-16,00=Quit 01	Enter the 2-digit holiday number (01-16) to be programmed and press [*] to accept entry. Enter 00 + [*] at the "Holiday Number?" prompt to quit the holiday menus and display the "Quit ?" prompt.
01 ENTER DATE 00/00	The cursor is now positioned on the tens of months digit. Enter the appropriate month, then press [*] to proceed to the day field. Enter the appropriate day for the holiday. Press [*] to accept the entry.
Part ? 12345678 Hit 0-8 x x	Holidays can be set for any partition, as follows. Press [0] to turn all partitions on or off, or use keys 1-8 to toggle the letter "x" under the partition to which this holiday will apply. Press the [*] key when all desired partitions have been assigned. The "Holiday Number?" prompt is displayed again. Repeat the procedure for each holiday to be programmed.
Quit ? 1 = YES 0 = NO 0	Enter 0 at the "Quit ?" prompt to return to the main menu choices and continue programming. Enter 1 to quit Scheduling Menu Mode.

Time-Driven Events

These schedules are used to activate outputs, bypass zones, etc. based on time. There are 20 of these schedules that may be programmed for the system, each governed by the previously defined time windows.

The actions that can be programmed to automatically activate at set times are: relay commands, arm/disarm commands, zone bypassing commands, and open/close access conditions.

Time-Driven Events Worksheet

The following worksheet is an example of the worksheet found in the *Programming Guide*. Fill out the worksheet using the steps outlined below.

Automatic Refresh Feature

The system automatically updates the status of all Time-Driven Events upon any of the following occurrences:

- Changing of the time or date via #63 mode
- Exiting #80 Scheduling Menu mode
- Exiting Program mode
- After a disconnect from the downloader
- On a power-up
- At Daylight Saving Time adjustment.

Sched Num.	Time Window	Days								Action Desired	Action Specifier	Activation Time
		M	T	W	T	F	S	S	H			
1												
2												
3...20												

1. **Enter the schedule number (01-20) and time window number (01-20)**, and note the day of the week the action is desired.
2. **Enter the code for the desired action and action specifier.** The action codes represent the events that are to take place when the scheduled time is reached. Each action also requires an action specifier, which defines what the action will affect (relay, relay group, partition, zone list, user group). The action specifier varies, depending on the type of action selected.

The following is a list of the Action Codes (desired actions) used when programming Time-Driven events. Note that these codes are independent of the relay codes programmed during *Output Programming* in the #93 Menu Mode.

Relay Commands

Action Code	Action	Action Specifier
01	Relay On	Relay #
02	Relay Off	Relay #
03	Relay Close for 2 seconds	Relay #
04	Relay Close XX minutes (set in field 1*74)	Relay #
05	Relay Close YY seconds (set in field 1*75)	Relay #
06	Relay Group On	Relay Group #
07	Relay Group Off	Relay Group #
08	Relay Group Close for 2 seconds	Relay Group #
09	Relay Group Close XX minutes (set in field 1*74)	Relay Group #
10	Relay Group Close YY seconds (set in field 1*75)	Relay Group #

Arm/Disarm Commands

Action Code	Action	Action Specifier
20	Arm-STAY	Partition(s)
21	Arm AWAY	Partition(s)
22	Disarm	Partition(s)
23	Force Arm STAY (Auto-bypass faulted zns)	Partition(s)
24	Force Arm AWAY (Auto-bypass faulted zns)	Partition(s)
25	Arm INSTANT	Partition(s)
26	Arm MAXIMUM	Partition(s)



- The auto-arm warning (field 2*06) applies when using Time-Driven events to auto-arm.
- Temporary schedules do not override an auto-arming or auto-disarming programmed in Time-Driven events.
- The auto-arming window cannot be extended using the Installer Code + #82 Mode.

Bypass Commands

Action Code	Action	Action Specifier
30	Auto bypass – Zone list	Zone list #
31	Auto unbypass – Zone list	Zone list #

Open/Close Windows

Action Code	Action	Action Specifier
40	Enable Opening Window by partition	Partition(s)
41	Enable Closing Window by partition	Partition(s)
42	Enable Access Window for access group	Access Group
50	Off-Normal Reminder (starts local keypad beeping if fire or system trouble condition exists)	None

Access Control Commands 55-78 Not Used

3. Enter the desired activation time (when the action is to take place). Select from:

Activation Time	Description
1	Beginning of time window.
2	End of time window.
3	During time window active period only (on at beginning of window, off at end). For example, if bypass is selected to activate during the window, zones in a zone list are bypassed at the beginning of the window and unbypassed at the end of the window.
4	Beginning and end of time window (e.g., a coffee break buzzer). In this example, if relay pulse is selected, the relay pulses for 2 seconds at the beginning of the window, signaling the beginning of the coffee break. At the end of the window it pulses again, signaling the end of coffee break.
5	Random time at the start of the time window (occurs within 30 minutes after the start of the time window). NOTE: Since the randomization for choice "5" occurs within 30 minutes after the start of the window, the time window duration must be at least 30 minutes.
6	Random time at the end of the time window (occurs within 30 minutes after the end of the time window).
7	Random during the time window (begins within 30 minutes after the start of the time window and ends within 30 minutes after the end of the time window). NOTE: Since the randomization for choice "7" occurs within 30 minutes after the start of the window, the time window duration must be at least 30 minutes.

Field *04 must be enabled for randomization. A user must initiate a random schedule by entering one of the following sequences:

- **[User Code] + [#] + [41]**. This will randomize, up to 30 minutes, the activation time of all devices, programmed for randomization, assigned to the partition the sequence is entered in. Enter the sequence again to turn off the random schedule.
- **[User Code] + [#] + [42]**. This is the same as the method above, except the randomization occurs only on devices with activation times within 6 PM and 5 AM. Enter the same sequence again to turn off the random schedule.

UL You must not program Random Scheduling of Time Driven Events for UL installations.

Time-Driven Event Programming

The following menu items must first be programmed in *Output Programming in the #93 Menu Mode*:

Enter Relay No.	(reference identification number)
Output Group	(if applicable)
Restriction (#70)	(Restriction must be set to yes for Commercial Fire installations.)
Output Type	(V-Plex or 4204/4204CF)
Zone No.	(V-Plex)
ECP Address	(4204/4204CF)
Relay No.	(4204/4204CF)

After entering Scheduling Menu Mode, press **[0]** until the "Timed Events ?" prompt appears.

PROMPT	EXPLANATION
Timed Events ? 1 = YES 0 = NO 0	Enter 1 to program timed events.
TIMED EVENT # ? 01-20, 00=Quit 01	Enter the timed event number to be programmed (01-20). Press [*]. The system then prompts the user to enter the desired action to be taken. Enter 00 at the "TIMED EVENT #?" prompt to quit the timed event menus and display the "Quit ?" prompt.
01 ACTION ? none 00	Enter the action code for this timed-event number from the list at the left. This could be an output command, an arming command, or any other Time-Driven event. Press [*] to accept the entry. The prompt for the action specifier appears.

ACTION CODES	EXPLANATION	ACTION SPECIFIER
01=Relay On 02=Relay Off 03=Relay Close for 2 seconds 04=Relay Close XX minutes 05=Relay Close YY seconds	Actions 01-05 If you selected actions 01-05 , the prompt at the right appears. Enter the relay number. Press [*] to accept entry. The "Time Window ?" prompt appears.	<div style="border: 1px solid black; padding: 5px;"> 01 RELAY # ? <div style="text-align: right;">00</div> </div>
06=Relay Group On 07=Relay Group Off 08=Relay Group Close for 2 seconds 09=Relay Group Close XX minutes 10=Relay Group Close YY seconds	Actions 06-10 If you selected actions 06-10 , the prompt at the right appears. Enter the relay group number. Press [*] to accept entry. The "Time Window ?" prompt appears.	<div style="border: 1px solid black; padding: 5px;"> 01 RELAY GRP # ? <div style="text-align: right;">00</div> </div>
20=Arm-STAY 21=Arm AWAY 22=Disarm 23=Force Arm STAY 24=Force Arm AWAY 25=Arm INSTANT 26=Arm MAXIMUM 40=Enable Open Window by Part. 41=Enable Close Window by Part.	Actions 21-26 and 40-41 If you selected actions 21-26 or 40-41 , the prompt at the right appears. Enter the partition to which the action applies. Enter 0 to select all partitions. Enter a partition number again to deselect it. Press [*] to accept entry. The "Time Window ?" prompt appears.	<div style="border: 1px solid black; padding: 5px;"> PART? 12345678 HIT 0-8 X X </div>
30=Auto bypass – Zone list 31=Auto unbypass – Zone list	Actions 30-31 If you selected actions 30-31 , the prompt at the right appears. Enter the zone list number that contains the zones to be bypassed or unbypassed. Press [*] to accept entry. The "Time Window ?" prompt appears.	<div style="border: 1px solid black; padding: 5px;"> 01 ZONE LIST ? ENTER 01-15 <div style="text-align: right;">01</div> </div>
42=Enable Access Window for Access group(s)	Action 42 If you selected action 42 , the prompt at the right appears. Enter the group number to which the time window will apply. Press [*] to accept entry. The "Time Window ?" prompt appears.	<div style="border: 1px solid black; padding: 5px;"> GROUP ? 12345678 HIT 0-8 X </div>
50=Off-Normal Reminder	Action 50 No action specifier is required for this action since the condition that this occurs for are system-wide.	
PROMPT	EXPLANATION	
<div style="border: 1px solid black; padding: 5px;"> 01 Time Window ? 00:00 00:00 01 </div>	Enter the time window number (01-20) for which this timed event is to occur. As the number is keyed in, the actual time that has been stored for the time window number is displayed. Press [*] to accept entry.	
<div style="border: 1px solid black; padding: 5px;"> 01 Active time ? <div style="text-align: right;">0</div> </div>	Enter the activation time from 1-10 (listed below). As the number is keyed in, the activation time is displayed. The choices are: 1: Trigger at the start of the window. 2: Trigger at the end of the window. 3: Take effect only for the duration of the window. 4: Trigger at both the start and the end of the window. Example: coffee break buzzer. 5: Random trigger, up to 30 minutes, after the start of the window. 6: Random trigger, up to 30 minutes, after the end of the window. 7: Take effect only for the duration of the window, but random start and end the window up to 30 minutes. Press [*] to accept entry.	
<div style="border: 1px solid black; padding: 5px;"> Days ? MTWTFSSH Hit 0-8 x x </div>	The system then asks for which days the event is to be activated. Press 0 to toggle all days on or off; or press keys 1-8 to toggle the letter "x" under the day on or off (Monday = 1, Holiday = H = 8). When all entries have been made, the "TIMED EVENT #?" prompt is displayed again. Repeat the procedure for each timed event for the installation.	
<div style="border: 1px solid black; padding: 5px;"> Quit ? 1 = YES 0 = NO <div style="text-align: right;">0</div> </div>	Enter 0 at the "Quit ?" prompt to return to the main menu choices and continue programming. Enter 1 to quit Scheduling Menu Mode.	

Limitation of Access Schedules

Limitation of Access is a means by which a user's access code is limited to working during a certain period of time. The system provides eight Access Schedules, each of which consists of two time windows for each day of the week and two time windows for holidays (typically, one for an opening time window and the second for a closing time window). A user, required to follow a schedule, would be assigned to an access group of the same number (e.g., schedule 1= group 1). The user's access code is assigned to a group when that user is added to the system. If no limitations apply, enter **0**.

Limitation of Access Schedule Worksheet

Enter the appropriate time window numbers for each access schedule.

Acc Sch	Mon		Tues		Wed		Thurs		Fri		Sat		Sun		Hol	
	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2
1																
2																
3...8																

NOTE: The holidays used for the access groups are the same as those defined in the holiday schedule.

Limitation of Access Schedules Programming

To program access schedules enter Scheduling Menu Mode **Installer Code + # 80**. After entering Scheduling Menu Mode, press **[0]** until the "Access Sched. ?" prompt appears.

PROMPT	EXPLANATION
Access Sched. ? 1 = YES 0 = NO 0	Enter 1 to program access schedules.
ACCESS SCHED # ? 01-08, 00 = Quit 01	Enter the access control schedule number between 01 and 08 . Press [*] to accept entry. Enter 00 at the "Access Sched #?" prompt to quit the access control menus and display the Quit ? prompt.
MON A1 Window 1 ? 00:00 00:00 00	Enter the first time-window number (01-20) for this access schedule for the displayed day. As the number is keyed in, the actual time that has been stored for the window is displayed. Press [*] to continue.
MON A1 Window 2 ? 00:00 00:00 00	Enter the second time-window number from 01-20 for this access schedule for the displayed day. As the number is keyed in, the actual time that has been stored for the window is displayed. Press [*] to continue.
TUE A1 Window 1 ? 00:00 00:00 00	Repeat the procedure for the other days of the week. When the last day of the week has been programmed, the windows for holidays may be entered.
Hol A1 Window 1 ? 00:00 00:00 00	Enter the first time-window number for holidays for this access schedule. As the number is keyed in, the actual time that has been stored for the window is displayed. Press [*] to continue.
Hol A1 Window 2 ? 00:00 00:00 00	Enter the second time-window number for holidays for this access schedule. As the number is keyed in, the actual time that has been stored for the window is displayed. Press [*] to continue.
Quit ? 1 = YES 0 = NO 0	Enter 0 at the "Quit ?" prompt to return to the main menu choices and continue programming. Enter 1 to quit Scheduling Menu Mode.

Temporary Schedules

Each partition can be assigned a temporary schedule, which overrides the regular open/close schedule (and the holiday schedule). This schedule takes effect as soon as it is programmed, and remains active for up to one week.

Only users with the authority level of manager or higher can program temporary schedules.

A temporary schedule affects only the partition from which it is entered. Temporary schedules can also be reused at later dates simply by scrolling (pressing [#]) to the "DAYS?" prompt and activating the appropriate days. This should be considered when defining daily time windows.

Temporary Schedule Worksheet

Partition/Windows	Mon	Tue	Wed	Thu	Fri	Sat	Sun
1 Disarm Window							
Start Time HH:MM							
Stop Time HH:MM							
Arm Window							
Start Time HH:MM							
Stop Time HH:MM							
2...8 Disarm Window							
Start Time HH:MM							
Stop Time HH:MM							
Arm Window							
Start Time HH:MM							
Stop Time HH:MM							

Temporary Schedules Programming

Enter **User Code + [#] + 81** to enter this mode.

PROMPT	EXPLANATION
Mon DISARM WIND. 00:00AM 00:00AM	<p>This prompt is for entering the start and end times of the disarm (opening) window for Monday. Upon entry of this mode, the cursor is positioned on the tens of hours digit of the start time of the disarm window. Enter the desired hour.</p> <p>Press [*] to move to the minutes field. The minutes are entered in the same manner.</p> <p>Press [*] to move to the AM/PM position. Pressing any key in the 0-9 range toggles the AM/PM indication. Repeat the procedure for the stop time entry.</p> <p>Press [*] to store the entries and move to the arming (closing) window for Monday. Pressing [#] scrolls you through the prompts without making any changes.</p>
Mon ARM WINDOW 00:00AM 00:00AM	<p>This prompt is for entering the start and end times of the arm (closing) window for Monday. The cursor is positioned on the tens of hours digit of the start time of the arm window. Enter the hour.</p> <p>Press [*] to move to the minutes field. The minutes are entered in the same manner.</p> <p>Press [*] to move to the AM/PM position. Pressing any key in the 0-9 range toggles the AM/PM indication. Repeat the procedure for the stop time entry.</p> <p>After the windows for that day have been completed, the system prompts for disarm and arm time windows for the next day.</p> <p>Press [#] if no changes are desired.</p>
Tue DISARM WIND. 00:00AM 00:00AM	<p>Repeat the procedure described above for all days of the week.</p> <p>When all the windows for all the days have been completed, the system prompts for which days of the schedule are to be activated.</p>
Days ? MTWTFSS Hit 0-7 x x	<p>This is the prompt that actually activates the temporary schedule.</p> <p>To select the days to be activated, enter 1-7 (Monday = 1). An "X" appears under that day, indicating the temporary schedule for that day is active. Entering a day's number again deactivates that day. Pressing 0 toggles all days on/off.</p> <p>The temporary schedule is in effect only for the days highlighted with the letter "x" under them. As the week progresses, the selected days are reset to the inactive state, but all other entries for the temporary schedule remain programmed.</p> <p>Press [*] to store the entries or press [#] to exit the Temporary Schedule Entry Mode without making any changes.</p>

User Scheduling Menu Mode

The system provides up to 20 “timers” available to the end user to control output devices. The output devices themselves are programmed into the system by the installer during *Output Programming* in the #93 Menu Mode. The end user needs only to know the output device number and its alpha descriptor.

The installer may set certain outputs to be “restricted” during *Output Programming* (this prevents the end user from controlling doors, pumps, Notification Appliance Circuits, etc.)

To enter this mode, the user enters **User Code + [#] + 83**.

PROMPT	EXPLANATION
Output Timer # ? 01-20, 00=Quit 01	Enter the output timer number to be programmed (01-20). Press [*] to accept entry and move to the next prompt. Enter 00 to quit and return to normal operating mode.
06 07:00P 11:45P PORCH LITE 04	If that timer number has already been programmed, a summary screen appears. In this example: 06 = Timer # 07:00PM = Start Time 11:45PM = Stop Time PORCH LITE = Descriptor for Output Device # 4 04 = Output Device # affected by this timer Press [*] to continue.
06 ENTER OUTPUT# PORCH LITE 04	Enter the desired output number (01-96). As the number is entered, the descriptor for that output device is displayed. Press [*] to continue.
	Entering 00 as the output number deletes the timer (Timer 06, in this example) and displays an output descriptor of “None.” Output devices are programmed via #93 Menu Mode.
06 ON TIME ? 07:00 PM	The cursor is positioned on the tens of hours digit of the ON time. Enter the desired hour. Press [*] to move to the minutes field. The minutes are entered in the same manner. The AM/PM indication is toggled by hitting any key from 0-9 while the cursor is under the AM/PM position. Press [*] to continue.
06 OFF TIME ? 11:45 PM	The cursor positioned on the tens of hours digit of the OFF time. Enter the desired hour. Press [*] to move to the minutes field. The minutes are entered in the same manner. The AM/PM indication is toggled by hitting any key in the 0-9 range while the cursor is under the AM/PM position. Press [*] to continue.
06 DAYS? MTWTFSS HIT 0-7 x x	To select the days to be activated, enter 1-7 (Monday = 1). An “x” appears under that day, indicating the output for that day is active. Entering a day’s number again deactivates that day. Pressing 0 toggles all days on/off. The outputs are in effect only for the days highlighted with the letter “x” under them. As the week progresses, the selected days are reset to the inactive state, unless the permanent option is selected (next screen prompt). When completed, press [*] to continue.
06 Permanent ? 0 = NO, 1 = YES 0	Selecting “Permanent” (1) means that this schedule will be in effect on a continuous basis. Selecting 0 means that this schedule will be in effect for one week only. The letter “x” under the day is then cleared, but all other entries for the output device remain programmed. Press [*] to accept entry. The system quits User Scheduling Mode and returns to normal operating mode.

#80 and #81 MENU MODE KEY COMMANDS

The following is a list of commands used while in the Menu mode.

#80 or #81	Enters Menu mode
[*]	Serves as ENTER key. Press to have keypad accept entry.
[#]	Backs up to previous screen.
0	Press to answer NO.
1	Press to answer YES.
01-09	All data entries are either 2-digit entries.
00	Exits Menu mode, returns to normal operation mode when entered at the first question for each category.

Scheduling Worksheets

Time Windows Definitions Worksheet. The system provides 20 time windows that are defined with start and stop times. They are programmed in the #80 Menu Mode. Fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.

Time Window Number	Start Time (HH:MM)	Stop Time (HH:MM)
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		

(Keep this worksheet handy, as you will be asked for a given time window number later in this section).



Because the time windows are shared among all partitions, it is important to make sure that changing a time window does not adversely affect desired actions in other partitions.

Daily Open/Close Schedule Worksheet: Using the time windows previously defined, fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.

Part	Mon		Tues		Wed		Thur		Fri		Sat		Sun		Hol	
	Op	Cl	Op	Cl	Op	Cl	Op	Cl	Op	Cl	Op	Cl	Op	Cl	Op	Cl
1																
2																
3																
4																
5																
6																
7																
8																

Holiday Schedule Worksheet: The system provides up to 16 holidays that can be assigned for the system. Each holiday can be assigned to any combination of partitions. Fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.

HOL	Partition								
	Month/Day	1	2	3	4	5	6	7	8
1	/								
2	/								
3	/								
4	/								
5	/								
6	/								
7	/								
8	/								
9	/								
10	/								
11	/								
12	/								
13	/								
14	/								
15	/								
16	/								

Time-Driven Event Worksheet: The system provides up to 20 time-driven events that can be programmed for the system. Fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.

Sched Num.	Time Window	Day(s)									Action Desired	Action Specifier	Activation Time
		M	T	W	T	F	S	S	H				
1													
2													
3													
4													
5													
6													
7													
8													
9													
10													
11													
12													
13													
14													
15													
16													
17													
18													
19													
20													

Automatic Refresh: The system automatically updates the status of all Time-Driven Events upon any of the following occurrences:

- Changing of the time or date via #63 mode
- Exiting #80 Scheduling Menu mode
- Exiting Program mode
- After a disconnect from the downloader
- On a power-up
- At Daylight Saving Time adjustment.

Below is a list of the "Action" codes (desired actions) used when programming time-driven events. Note that these codes are independent of the "relay codes" programmed during the #93 Menu Mode–Output Programming mode. **If using Time Driven Events, the following menu items must first be programmed using #93 Menu Mode - Output Programming:**

Enter Relay No. (reference identification number)	Zone No. (V-Plex)
Relay Group (if applicable)	ECP Address (4204/4204CF)
Restriction	Relay No. (4204/4204CF)
Relay Type (V-Plex or 4204/4204CF)	

Relay commands:

Action Specifier for commands 01-05 is Relay No.; Action Specifier for commands 06-10 is Relay Group No.

- | | |
|--|--|
| 01 = Relay On | 02 = Relay Off |
| 03 = Relay Close for 2 seconds | 04 = Relay Close XX minutes (field 1*74) |
| 05 = Relay Close YY seconds (field 1*75) | 06 = Relay Group On |
| 07 = Relay Group Off | 08 = Relay Group Close for 2 seconds |
| 09 = Relay Group Close XX minutes (field 1*74) | 10 = Relay Group Close YY seconds (field 1*75) |

Arm/Disarm commands:

Action Specifier for commands 20-24 is Partition(s). Activation times 1 (Beginning), 2 (End), 3 (During), 5 (Random Start), 6 (Random End), 7 (Random During) are the only valid choices for auto-arming and disarming functions.

- | | |
|---|---|
| 20 = Arm-Stay | 21 = Arm Away |
| 22 = Disarm | 23 = Force Arm Stay (Auto-bypass faulted zones) |
| 24 = Force Arm Away (Auto-bypass faulted zones) | 25 = Arm Instant |
| 26 = Arm Maximum | |

Bypass commands:

Action Specifier for commands 30-31 is Zone List #, Activation times 1 (Beginning), 2 (End), 3 (During), 5 (Random Start), 6 (Random End), 7 (Random During) are the only valid choices for bypass commands.

- | | |
|------------------------------|--------------------------------|
| 30 = Auto bypass - Zone list | 31 = Auto unbypass - Zone list |
|------------------------------|--------------------------------|

Open/Close Windows:

Action Specifier for commands 40-41 is Partition(s), for 42 is Access Group and for 50 no specifier is programmed.

Activation time 3 (During), 7 (Random During) are the only valid choices for these commands.

- | | | |
|---|----------------------------|---------------------------|
| 40 = Enable Opening Window | 41 = Enable Closing Window | 42 = Enable Access Window |
| 50 = Off-Normal Reminder (Starts local keypad beeping if off-normal condition exists) | | |

Access Control Commands

Action Specifier for commands 55-60 is Access Point, for 61-66 is Group, for 67-72 is Partition, and for 73-74 is Trigger.

- | | |
|--|---|
| 55 = Access Point Grant | 56 = Access Point Grant with Override |
| 57 = Access Point Protect | 58 = Access Point Bypass |
| 59 = Access Point Lock | 60 = Access Point Exit |
| 61 = Access Point Group Grant | 62 = Access Point Group Grant with Override |
| 63 = Access Point Group Protect | 64 = Access Point Group Bypass |
| 65 = Access Point Group Lock | 66 = Access Point Group Exit |
| 67 = Access Point Partition Grant | 68 = Access Point Partition Grant with Override |
| 69 = Access Point Protect by Partition | 70 = Access Point Bypass by Partition |
| 71 = Access Point Lock by Partition | 72 = Access Point Exit by Partition |
| 73 = Access Point Trigger On | 74 = Access Point Trigger Off |

Additional Commands

Action Specifier for command 78 is Group.

- 78 = Access Point Group Disable

Activation time:

Refers to when the action is to take place relative to the time window.

- 1 = Beginning of time window
- 2 = End of time window
- 3 = During time window active period only (On at beginning of window, off at end).
- 4 = Beginning and end of time window
- 5 = Random Start of the time window *
- 6 = Random End of the time window *
- 7 = Random During the time window *

- * The activation time of the window is randomized up to 30 minutes and is initialized by either of two methods:
 - a. **[User Code] + [#] + [41]** – Initiates the random schedule for all devices in the partition.
 - b. **[User Code] + [#] + [42]** – Initiates the random schedule for all devices in the partition with a time window within 6 PM and 5 AM.

Limitation of Access Worksheet The system provides up to 8 Access Schedules that can be programmed for the system. Fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.

Acc Sch	Mon		Tues		Wed		Thurs		Fri		Sat		Sun		Hol	
	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2	W1	W2
1																
2																
3																
4																
5																
6																
7																
8																

Temporary Schedule #81 Menu Mode. The system provides a Temporary Schedule for each partition. Enter the temporary scheduling mode by pressing **[Installer Code] + [#] + [81]**. Fill in the required data on the worksheet below and follow the procedure in the installation instructions as you enter the data during the displays and prompts that appear in sequence.

Partition/Windows		Mon	Tue	Wed	Thu	Fri	Sat	Sun
1	Disarm Window							
	Start Time HH:MM							
	Stop Time HH:MM							
	Arm Window							
	Start Time HH:MM							
	Stop Time HH:MM							
2	Disarm Window							
	Start Time HH:MM							
	Stop Time HH:MM							
	Arm Window							
	Start Time HH:MM							
	Stop Time HH:MM							

Partition/Windows		Mon	Tue	Wed	Thu	Fri	Sat	Sun
3	Disarm Window							
	Start Time HH:MM							
	Stop Time HH:MM							
	Arm Window							
	Start Time HH:MM							
	Stop Time HH:MM							
4	Disarm Window							
	Start Time HH:MM							
	Stop Time HH:MM							
	Arm Window							
	Start Time HH:MM							
	Stop Time HH:MM							
5	Disarm Window							
	Start Time HH:MM							
	Stop Time HH:MM							
	Arm Window							
	Start Time HH:MM							
	Stop Time HH:MM							
6	Disarm Window							
	Start Time HH:MM							
	Stop Time HH:MM							
	Arm Window							
	Start Time HH:MM							
	Stop Time HH:MM							
7	Disarm Window							
	Start Time HH:MM							
	Stop Time HH:MM							
	Arm Window							
	Start Time HH:MM							
	Stop Time HH:MM							
8	Disarm Window							
	Start Time HH:MM							
	Stop Time HH:MM							
	Arm Window							
	Start Time HH:MM							
	Stop Time HH:MM							

NOTES

NOTES

NOTES

NOTES

NOTES

Commercial/Residential Fire and Burglary, Mercantile/Bank Safe and Vault, Local and Police Station, Central Station and Proprietary Protected Premises Control Unit with DACT

FOR DRY, INDOOR USE ONLY

WARNING:

This unit includes a Fire Alarm Verification feature that will result in a delay of the System Alarm Signal from the indicated Fire Alarm circuits. The total delay (Control Unit plus Smoke Detectors) shall not exceed 30 seconds. No other Smoke Detector shall be connected to these circuits unless approved by the local authority having jurisdiction.

Circuit (zone)	Control Unit Delay, Seconds	Smoke Detector Model	Delay, Seconds
Zone 1	8 Seconds		
Zone 2	8 Seconds		
Aux Relay	8 Seconds		

THE DELAY TIME MARKED ON THE INSTALLED DETECTOR(S) IS TO BE USED.

This equipment should be installed in accordance with the National Fire Alarm Code, ANS/NFPA 72 (National Fire Protection Assoc., Batterymarch Park, Quincy, MA, 02169). Printed information describing proper installation, operation, testing, maintenance and repair service is to be provided with this equipment. Additionally, this equipment should be installed in accordance with UL1641 - Installation and Classification of Residential Burglar Alarms Systems.

BATTERY TABS (SEE NOTE 7) BLK - + RED - -

Connect to 12V, 12AH min/94-4AH max lead acid batteries using cables supplied. See instructions for required capacity. Float charging voltage: 13.7VDC. Battery normally need not be replaced for an least 3 yrs.

BELL CIRCUIT SUPERVISION JUMPERS


DO NOT CUT

BELL 1 BELL 2
W1 W4
(WHITE) (WHITE)

Special Application Circuit
Connect Only Fire Keypads to AUX PWR # 2.



KEYPAD PORT #2
J4
J5
Make connections using 4142TR cable (supplied).



NOTES

- The combined standby current drawn from aux power supply must not exceed 1.0A (for Canada, 650mA). The combined alarm current drawn from aux pwr #1, aux pwr #2, polling loop, bell 1 and bell 2 cannot exceed 2.3A (for Canada, 1.93A).
- See instructions on setting addresses & for max # of keypads and wire run length restrictions.
- Use only 14-22 AWG wire.
- No more than one (1) wire per terminal may be connected.
- Maximum Loop Impedance is 1.17 ohms.
- 2k EOLR is Ademco Model EOL20.
- If supervision of the batteries is required, they should be connected to the Battery Sense Module. The Battery Sense Module is then connected to the panel. Refer to the Battery Sense Module instructions for connections.
- The control unit is to be checked by a qualified technician at least every 3 years.

Each output is Class B with Style Y supervision.
FIRE CKTS: Rated 1.7A when utilized as Special Application Pwr (see Installation and Setup Guide).
Polling Loop: Rated 1.7A when utilized as Special Application Pwr (see Installation and Setup Guide).
Supervise using 2k EOLR. Use polarized sounding devices and backup batteries.

BURG CKTS: Supervision is required. May use non polarized devices. 1.7A max. See note 1, see instructions for compatible devices.
Can use No. 702 Stren. or 12V Bell.
For commercial fire, bell timeout must be a minimum of 6 minutes.

ALL CIRCUITS ARE POWER LIMITED EXCEPT THE OUTPUT FROM THE 1451 TRANSFORMER AND BACKUP BATTERIES.
ALL POWER-LIMITED WIRING MUST BE SEPARATED FROM NON-POWER LIMITED AND HIGH VOLTAGE WIRING BY 1/4 INCH (6.4 mm)


TEST BURGLARY SYSTEM WEEKLY

TYPES OF FIRE SIGNALING SERVICE:

Manual fire alarm, automatic fire alarm, sprinkler supervisory and waterflow alarm, DACT, Radio Frequency (RF) and Multiplex. UL Listed local control (non-coded), UL Listed central station and remote station, protected premises unit when used with 5140DLM back-up diater module. Installation limits under jurisdiction of local authority.


J2 VOLTAGE TRIGGERS

- See instructions for trigger use and programming
- OUT 4 (SILENT PANIC/DURESS)
 - OUT 7 (TROUBLE)
 - OUT 8 (SILENT PANIC/DURESS)
 - OUT 3 (SUPERVISORY)
 - OUT 2 (FIRE)
 - OUT 5 (REMOTE KEYPAD SOUNDER)
 - GROUND (ENCLOSURE)
 - GROUND (ENCLOSURE)
 - IN 1 (N.O. LOOP)
 - IN 2 (N.O. LOOP)
 - IN 3 (N.O. LOOP)
 - IN 4 (N.O. LOOP)
 - IN 5 (N.O. LOOP)
 - IN 6 (N.O. LOOP)
 - IN 7 (N.O. LOOP)
 - IN 8 (N.O. LOOP)
 - IN 9 (N.O. LOOP)
 - IN 10 (N.O. LOOP)
 - IN 11 (N.O. LOOP)
 - IN 12 (N.O. LOOP)
 - IN 13 (N.O. LOOP)
 - IN 14 (N.O. LOOP)
 - IN 15 (N.O. LOOP)
 - IN 16 (N.O. LOOP)
 - IN 17 (N.O. LOOP)
 - IN 18 (N.O. LOOP)
 - IN 19 (N.O. LOOP)
 - IN 20 (N.O. LOOP)
 - IN 21 (N.O. LOOP)
 - IN 22 (N.O. LOOP)
 - IN 23 (N.O. LOOP)
 - IN 24 (N.O. LOOP)
 - IN 25 (N.O. LOOP)
 - IN 26 (N.O. LOOP)
 - IN 27 (N.O. LOOP)
 - IN 28 (N.O. LOOP)
 - IN 29 (N.O. LOOP)
 - IN 30 (N.O. LOOP)
 - IN 31 (N.O. LOOP)
 - IN 32 (N.O. LOOP)
 - IN 33 (N.O. LOOP)
 - IN 34 (N.O. LOOP)
 - IN 35 (N.O. LOOP)
 - IN 36 (N.O. LOOP)
 - IN 37 (N.O. LOOP)
 - IN 38 (N.O. LOOP)
 - IN 39 (N.O. LOOP)
 - IN 40 (N.O. LOOP)
 - IN 41 (N.O. LOOP)
 - IN 42 (N.O. LOOP)
 - IN 43 (N.O. LOOP)
 - IN 44 (N.O. LOOP)
 - IN 45 (N.O. LOOP)
 - IN 46 (N.O. LOOP)
 - IN 47 (N.O. LOOP)
 - IN 48 (N.O. LOOP)
 - IN 49 (N.O. LOOP)
 - IN 50 (N.O. LOOP)
 - IN 51 (N.O. LOOP)
 - IN 52 (N.O. LOOP)
 - IN 53 (N.O. LOOP)
 - IN 54 (N.O. LOOP)
 - IN 55 (N.O. LOOP)
 - IN 56 (N.O. LOOP)
 - IN 57 (N.O. LOOP)
 - IN 58 (N.O. LOOP)
 - IN 59 (N.O. LOOP)
 - IN 60 (N.O. LOOP)
 - IN 61 (N.O. LOOP)
 - IN 62 (N.O. LOOP)
 - IN 63 (N.O. LOOP)
 - IN 64 (N.O. LOOP)
 - IN 65 (N.O. LOOP)
 - IN 66 (N.O. LOOP)
 - IN 67 (N.O. LOOP)
 - IN 68 (N.O. LOOP)
 - IN 69 (N.O. LOOP)
 - IN 70 (N.O. LOOP)
 - IN 71 (N.O. LOOP)
 - IN 72 (N.O. LOOP)
 - IN 73 (N.O. LOOP)
 - IN 74 (N.O. LOOP)
 - IN 75 (N.O. LOOP)
 - IN 76 (N.O. LOOP)
 - IN 77 (N.O. LOOP)
 - IN 78 (N.O. LOOP)
 - IN 79 (N.O. LOOP)
 - IN 80 (N.O. LOOP)
 - IN 81 (N.O. LOOP)
 - IN 82 (N.O. LOOP)
 - IN 83 (N.O. LOOP)
 - IN 84 (N.O. LOOP)
 - IN 85 (N.O. LOOP)
 - IN 86 (N.O. LOOP)
 - IN 87 (N.O. LOOP)
 - IN 88 (N.O. LOOP)
 - IN 89 (N.O. LOOP)
 - IN 90 (N.O. LOOP)
 - IN 91 (N.O. LOOP)
 - IN 92 (N.O. LOOP)
 - IN 93 (N.O. LOOP)
 - IN 94 (N.O. LOOP)
 - IN 95 (N.O. LOOP)
 - IN 96 (N.O. LOOP)
 - IN 97 (N.O. LOOP)
 - IN 98 (N.O. LOOP)
 - IN 99 (N.O. LOOP)
 - IN 100 (N.O. LOOP)



VOLTAGE TRIGGERS
(not supervised)
Make connections using 4142TR cable

NOTE: J2 Keyswitch Voltage Triggers are used for fire applications. Trigger Wiring must be run in conduit within 20ft of the Control Panel.
Make connections from J13 using 4142TR cable. Connect to the PC using standard RS-485 Serial Cable with a 9-PIN Connector on the panel end and the appropriate connector for the PC on the other end. IN A CONTACT WITH J14



MAIN DIALER ON HOOK
VOLTAGE THRESHOLD
IN A CONTACT WITH J14

WARNING:
TO PREVENT RISK OF ELECTRICAL SHOCK BEFORE SERVICING THIS PANEL

CAUTION:
TO REDUCE THE RISK OF FIRE USE ONLY No. 26 AWG OR LARGER TELECOMMUNICATION LINE CORD OR EQUIVALENT

EARTH GROUND
See instructions for proper earth ground connections

The impedance at which a ground fault is annunciated is 1,000 ohms

TO OTHER DEVICES
Polling Loop: Class B, Style 3.
Polling Loop Ratings:
• (supervised) 128mA max. See note 1.
• 8-11 VDC
• 20 Ohms Max. Impedance

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

8-11 VDC
20 Ohms Max. Impedance

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.


See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.


See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

VISTA-128FBPT / VISTA-250FBPT SUMMARY OF CONNECTIONS



MAIN PCB SHIELD
See instr. regarding port #2 Use
1. GROUND (to keypad black wire)
2. DATA OUT 2 (to keypad red wire)
3. DATA OUT 1 (to keypad yellow wire)
4. 400mA max. See note 1
5. 10 - 14 VDC
6. 400mA max. See note 1
7. DATA OUT 2 (to keypad yellow wire)
PINS 2, 3, 6, 8 & 9 NOT USED

CONNECTION OF THE FIRE ALARM QUARTERS OR A CENTRAL STATION SHALL BE PERMITTED ONLY WITH THE APPROVAL OF THE LOCAL AUTHORITY. THE BURGLARY ALARM SIGNAL SHALL NOT BE CONNECTED TO A POLICE EMERGENCY NUMBER.



BACK-UP PHONE JACK
The 5140DLM Diater Completes with FCC Rules, Part 68 FCC Registration (see FCC Form 478)

BACK-UP DIALER EARTH
BACK-UP DIALER EARTH (wire to main PCB terminal #30)

OPTIONAL PCB SHIELD
See instr. regarding port #2 Use
1. GROUND (to keypad black wire)
2. DATA OUT 2 (to keypad red wire)
3. DATA OUT 1 (to keypad yellow wire)
4. 400mA max. See note 1
5. 10 - 14 VDC
6. 400mA max. See note 1
7. DATA OUT 2 (to keypad yellow wire)
PINS 2, 3, 6, 8 & 9 NOT USED

CONNECTION OF THE FIRE ALARM QUARTERS OR A CENTRAL STATION SHALL BE PERMITTED ONLY WITH THE APPROVAL OF THE LOCAL AUTHORITY. THE BURGLARY ALARM SIGNAL SHALL NOT BE CONNECTED TO A POLICE EMERGENCY NUMBER.

WARNING:
TO PREVENT RISK OF ELECTRICAL SHOCK BEFORE SERVICING THIS PANEL

CAUTION:
TO REDUCE THE RISK OF FIRE USE ONLY No. 26 AWG OR LARGER TELECOMMUNICATION LINE CORD OR EQUIVALENT

EARTH GROUND
See instructions for proper earth ground connections

The impedance at which a ground fault is annunciated is 1,000 ohms

TO OTHER DEVICES
Polling Loop: Class B, Style 3.
Polling Loop Ratings:
• (supervised) 128mA max. See note 1.
• 8-11 VDC
• 20 Ohms Max. Impedance

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

See instructions for compatible devices and for max wire run length. Fire and Burglary devices must be isolated from each other by use of a 4237 or YSI module. Refer to instructions for specific examples.

Honeywell

2 Corporate Center Drive, Suite 100
P.O. Box 9040, Melville, NY 11747
Copyright © 2011 Honeywell International Inc.



800-09618V1 11/12 Rev. A